



CVE-2017-17151

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

Summary

CVE	CVE-2017-17151
State	PUBLIC
Assigner	psirt@huawei.com
Source Priority	CVE Program / NVD first with legacy fallback
Published	2018-02-15 16:29:00 UTC
Updated	2018-02-22 17:05:00 UTC
Description	Huawei AR100, AR100-S, AR110-S, AR120, AR120-S, AR1200, AR1200-S, AR150, AR150-S, AR160, AR200, AR200-S, /

Risk And Classification

Problem Types: CWE-20

NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware	Huawei	Ar100	-	All	All	All
Hardware	Huawei	Ar100	-	All	All	All
Hardware	Huawei	Ar100-s	-	All	All	All
Hardware	Huawei	Ar100-s	-	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r007c00spca00	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r008c20spc800pwe	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r007c00spca00	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar100-s Firmware	v200r008c20spc800pwe	All	All	All

Operating System	Huawei	Ar100-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar100 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar100 Firmware	v200r008c20spc700pwe	All	All	All
Operating System	Huawei	Ar100 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar100 Firmware	v200r008c20spc800pwe	All	All	All
Operating System	Huawei	Ar100 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar100 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar100 Firmware	v200r008c20spc700pwe	All	All	All
Operating System	Huawei	Ar100 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar100 Firmware	v200r008c20spc800pwe	All	All	All
Operating System	Huawei	Ar100 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar110-s	-	All	All	All
Hardware	Huawei	Ar110-s	-	All	All	All
Operating System	Huawei	Ar110-s Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar110-s Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar110-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar110-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar110-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar110-s Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar110-s Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar110-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar110-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar110-s Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar120	-	All	All	All
Hardware	Huawei	Ar120	-	All	All	All
Hardware	Huawei	Ar120-s	-	All	All	All
Hardware	Huawei	Ar120-s	-	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00spca00	All	All	All

Operating System	Huawei	Ar120-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00spca00	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar1200	-	All	All	All
Hardware	Huawei	Ar1200	-	All	All	All
Hardware	Huawei	Ar1200-s	-	All	All	All
Hardware	Huawei	Ar1200-s	-	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c20spc800pwe	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c30	All	All	All

Operating System	Huawei	Ar1200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c20spc800pwe	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10spc030	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10spc300pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10spc600	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc600pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spca00	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c20spc600	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c20spc700	All	All	All

Operating System	Huawei	Ar1200 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10spc030	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10spc300pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10spc600	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc600pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spca00	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c20spc600	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r006c10spc300pwe	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00pwe	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spc600	All	All	All

Operating System	Huawei	Ar120 Firmware	v200r007c00spc600pwe	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r006c10spc300pwe	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00pwe	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spc600pwe	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar120 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar150	-	All	All	All
Hardware	Huawei	Ar150	-	All	All	All
Hardware	Huawei	Ar150-s	-	All	All	All
Hardware	Huawei	Ar150-s	-	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r007c00spc200	All	All	All

Operating System	Huawei	Ar150 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r006c10spc300pwe	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00pwe	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00spc600pwe	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c02pwe	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar160	-	All	All	All
Hardware	Huawei	Ar160	-	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c10spc100	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c10spc200	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c10spc300pwe	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c10spc600	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c12	All	All	All

Operating System	Huawei	Ar160 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c20spc500t	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c20spc501t	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c20spc600	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c30spc100	All	All	All
Hardware	Huawei	Ar200	-	All	All	All
Hardware	Huawei	Ar200	-	All	All	All
Hardware	Huawei	Ar200-s	-	All	All	All
Hardware	Huawei	Ar200-s	-	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00spc200	All	All	All

Operating System	Huawei	Ar200-s Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10spc100	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10spc300pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc600pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20spc600	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20spc900	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20spc900pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10spc100	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10spc300pwe	All	All	All

Operating System	Huawei	Ar200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc600pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20spc600	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20spc900	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20spc900pwe	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar2200	-	All	All	All
Hardware	Huawei	Ar2200	-	All	All	All
Hardware	Huawei	Ar2200-s	-	All	All	All
Hardware	Huawei	Ar2200-s	-	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20spc800pwe	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r006c10	All	All	All

Operating System	Huawei	Ar2200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20spc800pwe	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10spc300pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10spc600	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c16pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc500	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc600pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spca00	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c20spc600	All	All	All

Operating System	Huawei	Ar2200 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10spc300pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10spc600	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c16pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc500	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc600pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spca00	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c20spc600	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar3200	-	All	All	All
Operating System	Huawei	Ar3200	-	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10spc100	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10spc200	All	All	All

Operating System	Huawei	Ar3200 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10spc300pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10spc600	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c11	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc500	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc510t	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc600pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spca00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spcc00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20b560	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20b570	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20b580	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b010	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b020	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b030	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b050	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b060	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b070	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b080	All	All	All

Operating System	Vendor	Firmware	Version
Operating System	Huawei	Ar3200 Firmware	v200r008c30spc067t	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10spc100	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10spc200	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10spc300pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10spc600	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c11	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc500	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc510t	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc600pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spc900pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spca00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spcb00pwe	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00spcc00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20b560	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20b570	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20b580	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b010	All	All	All

Operating System	Huawei	Ar3200 Firmware	v200r008c30b020	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b030	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b050	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b060	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b070	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30b080	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30spc067t	All	All	All
Hardware	Huawei	Ar510	-	All	All	All
Hardware	Huawei	Ar510	-	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c10spc200	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c12	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c15	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c16	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c17	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc180t	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c10pwe	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c10spc200	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c12	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c15	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c16	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c17	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc180t	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spcb00	All	All	All

Operating System	Huawei	Ar510 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Dp300	-	All	All	All
Hardware	Huawei	Dp300	-	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc100	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc200	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc300	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc400	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc500	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc800	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc100	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc200	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc300	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc400	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc500	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc800	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00spc900	All	All	All
Hardware	Huawei	Netengine16ex	-	All	All	All
Hardware	Huawei	Netengine16ex	-	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r006c10	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c20	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c30	All	All	All

Operating System	Huawei	Netengine16ex Firmware	v200r006c10	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c20	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c20spc700	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c20spc800	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c30	All	All	All
Hardware	Huawei	Rp200	-	All	All	All
Hardware	Huawei	Rp200	-	All	All	All
Operating System	Huawei	Rp200 Firmware	v500r002c00spc200	All	All	All
Operating System	Huawei	Rp200 Firmware	v500r002c00spc200	All	All	All
Hardware	Huawei	Srg1300	-	All	All	All
Hardware	Huawei	Srg1300	-	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00spc600	All	All	All

Operating System	Huawei	Srg1300 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Srg2300	-	All	All	All
Hardware	Huawei	Srg2300	-	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Srg3300	-	All	All	All
Hardware	Huawei	Srg3300	-	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00spc100	All	All	All

Operating System	Huawei	Srg3300 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00spc100	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00spc200	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Te30	-	All	All	All
Hardware	Huawei	Te30	-	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c02spc100	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c02spc200	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10spc100	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10spc300	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10spc600	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10spc800	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc200	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c02spc100	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c02spc200	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10spc100	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10spc300	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10spc600	All	All	All

Operating System	Huawei	Te30 Firmware	v100r001c10spc800	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc200	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spcb00	All	All	All
Hardware	Huawei	Te40	-	All	All	All
Hardware	Huawei	Te40	-	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te40 Firmware	v600r006c00	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te40 Firmware	v600r006c00	All	All	All
Hardware	Huawei	Te50	-	All	All	All
Hardware	Huawei	Te50	-	All	All	All
Operating System	Huawei	Te50 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te50 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te50 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te50 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te50 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te50 Firmware	v500r002c00spcb00	All	All	All
Hardware	Huawei	Te60	-	All	All	All
Hardware	Huawei	Te60	-	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c01spc100	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10b010	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc300	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc400	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc502t	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc600	All	All	All

Operating System	Huawei	Te60 Firmware	v100r001c10spc700	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc800	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc900	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc100	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc200	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc800	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spca00	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te60 Firmware	v600r006c00	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c01spc100	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10b010	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc300	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc400	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc502t	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc600	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc700	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc800	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10spc900	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc100	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc200	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc800	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spca00	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te60 Firmware	v600r006c00	All	All	All
Hardware	Huawei	Tp3106	-	All	All	All
Hardware	Huawei	Tp3106	-	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c01spc100	All	All	All

Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc100	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc100b010	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc100b011	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc100b012	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc200	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc300	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc400	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc500	All	All	All

References

Reference	Source	Link	Tags
Security Advisory - Input Validation Vulnerability in H323 Protocol of Huawei products	CONFIRM	www.huawei.com	Vendor Advisory
CVE Program record	CVE.ORG	www.cve.org	canonical
NVD vulnerability detail	NVD	nvd.nist.gov	canonical, analysis

No vendor comments have been submitted for this CVE.

Legacy QID Mappings

43892 Huawei Router Input Validation Vulnerability (Huawei-SA-20171206-01-h323-en)

© CVE.report 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](#) and the authoritative source of CVE content is [MITRE's CVE web site](#). This site includes MITRE data granted under the following [license](#).

CVE.report and Source URL Uptime Status status.cve.report