



CVE-2017-17252

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

Summary

CVE	CVE-2017-17252
State	PUBLIC
Assigner	psirt@huawei.com
Source Priority	CVE Program / NVD first with legacy fallback
Published	2018-04-24 15:29:00 UTC
Updated	2018-06-04 14:05:00 UTC
Description	Huawei AR120-S V200R006C10, V200R007C00, V200R008C20, V200R008C30, AR1200 V200R006C10, V200R006C13,

Risk And Classification

Problem Types: CWE-125

NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware	Huawei	Ar120-s	-	All	All	All
Hardware	Huawei	Ar120-s	-	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar120-s Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar1200	-	All	All	All
Hardware	Huawei	Ar1200	-	All	All	All
Hardware	Huawei	Ar1200-s	-	All	All	All
Hardware	Huawei	Ar1200-s	-	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c20	All	All	All

Operating System	Huawei	Ar1200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar150	-	All	All	All
Hardware	Huawei	Ar150	-	All	All	All
Hardware	Huawei	Ar150-s	-	All	All	All
Hardware	Huawei	Ar150-s	-	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c02	All	All	All

Operating System	Huawei	Ar150 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar160	-	All	All	All
Hardware	Huawei	Ar160	-	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c12	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c12	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar200	-	All	All	All
Hardware	Huawei	Ar200	-	All	All	All
Hardware	Huawei	Ar200-s	-	All	All	All
Hardware	Huawei	Ar200-s	-	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c20	All	All	All

Operating System	Huawei	Ar200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar2200	-	All	All	All
Hardware	Huawei	Ar2200	-	All	All	All
Hardware	Huawei	Ar2200-s	-	All	All	All
Hardware	Huawei	Ar2200-s	-	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c16pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c16pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c01	All	All	All

Operating System	Huawei	Ar2200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar3200	-	All	All	All
Hardware	Huawei	Ar3200	-	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c11	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c11	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar3600	-	All	All	All
Hardware	Huawei	Ar3600	-	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r008c20	All	All	All
Hardware	Huawei	Ar510	-	All	All	All
Hardware	Huawei	Ar510	-	All	All	All

Operating System	Huawei	Ar510 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c12	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c15	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c16	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c17	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc180t	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c12	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c15	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c16	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c17	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc180t	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Dp300	-	All	All	All
Hardware	Huawei	Dp300	-	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00	All	All	All
Hardware	Huawei	Ips Module	-	All	All	All
Hardware	Huawei	Ips Module	-	All	All	All
Operating System	Huawei	Ips Module Firmware	v100r001c10spc200	All	All	All
Operating System	Huawei	Ips Module Firmware	v100r001c30	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c00	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c30	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c50	All	All	All
Operating System	Huawei	Ips Module Firmware	v100r001c10spc200	All	All	All
Operating System	Huawei	Ips Module Firmware	v100r001c30	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c00	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c30	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c50	All	All	All

Operating System	Huawei	ips module Firmware	v500r001c50	All	All	All
Hardware	Huawei	Netengine16ex	-	All	All	All
Hardware	Huawei	Netengine16ex	-	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r006c10	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c20	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c30	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r006c10	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c20	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ngfw Module	-	All	All	All
Hardware	Huawei	Ngfw Module	-	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c10spc200	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c20	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c30	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r001c00	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r002c00	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r002c10	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c10spc200	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c20	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c30	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r001c00	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r002c00	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r002c10	All	All	All
Hardware	Huawei	Nip6300	-	All	All	All
Hardware	Huawei	Nip6300	-	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c30	All	All	All

Operating System	Huawei	Nip6300 Firmware	v500r001c50	All	All	All
Hardware	Huawei	Nip6600	-	All	All	All
Hardware	Huawei	Nip6600	-	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c50	All	All	All
Hardware	Huawei	Nip6800	-	All	All	All
Hardware	Huawei	Nip6800	-	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c50	All	All	All
Hardware	Huawei	Rse6500	-	All	All	All
Hardware	Huawei	Rse6500	-	All	All	All
Operating System	Huawei	Rse6500 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Rse6500 Firmware	v500r002c00	All	All	All
Hardware	Huawei	Secospace Usg6300	-	All	All	All
Hardware	Huawei	Secospace Usg6300	-	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c20	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c30	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c20	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c30	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c50	All	All	All

Operating System	Huawei	Secospace USG6000 Firmware	v300r001c00	All	All	All
Hardware	Huawei	Semg9811	-	All	All	All
Hardware	Huawei	Semg9811	-	All	All	All
Operating System	Huawei	Semg9811 Firmware	v300r001c01	All	All	All
Operating System	Huawei	Semg9811 Firmware	v300r001c01	All	All	All
Hardware	Huawei	Srg1300	-	All	All	All
Hardware	Huawei	Srg1300	-	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg1300 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Srg2300	-	All	All	All
Hardware	Huawei	Srg2300	-	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Srg3300	-	All	All	All
Hardware	Huawei	Srg3300	-	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c30	All	All	All

Operating System	Huawei	Srg3300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Svn5600	-	All	All	All
Hardware	Huawei	Svn5600	-	All	All	All
Operating System	Huawei	Svn5600 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5600 Firmware	v200r003c10	All	All	All
Operating System	Huawei	Svn5600 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5600 Firmware	v200r003c10	All	All	All
Hardware	Huawei	Svn5800	-	All	All	All
Hardware	Huawei	Svn5800	-	All	All	All
Hardware	Huawei	Svn5800-c	-	All	All	All
Hardware	Huawei	Svn5800-c	-	All	All	All
Operating System	Huawei	Svn5800-c Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5800-c Firmware	v200r003c10	All	All	All
Operating System	Huawei	Svn5800-c Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5800-c Firmware	v200r003c10	All	All	All
Operating System	Huawei	Svn5800 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5800 Firmware	v200r003c10	All	All	All
Operating System	Huawei	Svn5800 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5800 Firmware	v200r003c10	All	All	All
Hardware	Huawei	Te30	-	All	All	All
Hardware	Huawei	Te30	-	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c02	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Te30 Firmware	v600r006c00	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c02	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Te30 Firmware	v600r006c00	All	All	All
Hardware	Huawei	Te40	-	All	All	All
Hardware	Huawei	Te40	-	All	All	All

Operating System	Huawei	Te40 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Te40 Firmware	v600r006c00	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Te40 Firmware	v600r006c00	All	All	All
Hardware	Huawei	Te50	-	All	All	All
Hardware	Huawei	Te50	-	All	All	All
Operating System	Huawei	Te50 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Te50 Firmware	v600r006c00	All	All	All
Operating System	Huawei	Te50 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Te50 Firmware	v600r006c00	All	All	All
Hardware	Huawei	Te60	-	All	All	All
Hardware	Huawei	Te60	-	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c01	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Te60 Firmware	v600r006c00	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c01	All	All	All
Operating System	Huawei	Te60 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Te60 Firmware	v600r006c00	All	All	All
Hardware	Huawei	Tp3106	-	All	All	All
Hardware	Huawei	Tp3106	-	All	All	All
Operating System	Huawei	Tp3106 Firmware	v100r002c00	All	All	All
Operating System	Huawei	Tp3106 Firmware	v100r002c00	All	All	All
Hardware	Huawei	Tp3206	-	All	All	All
Hardware	Huawei	Tp3206	-	All	All	All
Operating System	Huawei	Tp3206 Firmware	v100r002c00	All	All	All
Operating System	Huawei	Tp3206 Firmware	v100r002c10	All	All	All
Operating System	Huawei	Tp3206 Firmware	v100r002c00	All	All	All
Operating System	Huawei	Tp3206 Firmware	v100r002c10	All	All	All
Hardware	Huawei	Usg6000v	-	All	All	All
Hardware	Huawei	Usg6000v	-	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20	All	All	All
Hardware	Huawei	Usg9500	-	All	All	All
Hardware	Huawei	Usg9500	-	All	All	All

Hardware	Manufacturer	Model	Version	OS	Kernel	Architecture
Operating System	Huawei	Usg9500 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c50	All	All	All
Hardware	Huawei	Usg9520	-	All	All	All
Hardware	Huawei	Usg9520	-	All	All	All
Operating System	Huawei	Usg9520 Firmware	v300r001c01	All	All	All
Operating System	Huawei	Usg9520 Firmware	v300r001c20	All	All	All
Operating System	Huawei	Usg9520 Firmware	v300r001c01	All	All	All
Operating System	Huawei	Usg9520 Firmware	v300r001c20	All	All	All
Hardware	Huawei	Usg9560	-	All	All	All
Hardware	Huawei	Usg9560	-	All	All	All
Operating System	Huawei	Usg9560 Firmware	v300r001c01	All	All	All
Operating System	Huawei	Usg9560 Firmware	v300r001c20	All	All	All
Operating System	Huawei	Usg9560 Firmware	v300r001c01	All	All	All
Operating System	Huawei	Usg9560 Firmware	v300r001c20	All	All	All
Hardware	Huawei	Usg9580	-	All	All	All
Hardware	Huawei	Usg9580	-	All	All	All
Operating System	Huawei	Usg9580 Firmware	v300r001c01	All	All	All
Operating System	Huawei	Usg9580 Firmware	v300r001c20	All	All	All
Operating System	Huawei	Usg9580 Firmware	v300r001c01	All	All	All
Operating System	Huawei	Usg9580 Firmware	v300r001c20	All	All	All
Hardware	Huawei	Viewpoint 8660	-	All	All	All
Hardware	Huawei	Viewpoint 8660	-	All	All	All
Operating System	Huawei	Viewpoint 8660 Firmware	v100r008c03	All	All	All
Operating System	Huawei	Viewpoint 8660 Firmware	v100r008c03	All	All	All
Hardware	Huawei	Viewpoint 9030	-	All	All	All
Hardware	Huawei	Viewpoint 9030	-	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c02	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c02	All	All	All

Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03	All	All	All
Hardware	Huawei	Vp9660	-	All	All	All
Hardware	Huawei	Vp9660	-	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c10	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c10	All	All	All

References

Reference	Source	Link	Tags
Security Advisory - Several Vulnerabilities in H323 Protocol of Huawei Products	CONFIRM	www.huawei.com	Vendor Advisory
CVE Program record	CVE.ORG	www.cve.org	canonical
NVD vulnerability detail	NVD	nvd.nist.gov	canonical, analysis

No vendor comments have been submitted for this CVE.

There are currently no legacy QID mappings associated with this CVE.

© [CVE.report](#) 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](#) and the authoritative source of CVE content is [MITRE's CVE web site](#). This site includes MITRE data granted under the following [license](#).

CVE.report and Source URL Uptime Status [status.cve.report](#)