



# CVE-2017-17292

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

## Summary

|                        |   |
|------------------------|---|
| <b>CVE</b>             | CVE-2017-17292  |
| <b>State</b>           | PUBLIC  |
| <b>Assigner</b>        | psirt@huawei.com  |
| <b>Source Priority</b> | CVE Program / NVD first with legacy fallback  |
| <b>Published</b>       | 2018-02-15 16:29:00 UTC   |
| <b>Updated</b>         | 2018-03-01 14:24:00 UTC   |
| <b>Description</b>     | Huawei AR120-S V200R006C10, V200R007C00, V200R008C20, V200R008C30, AR1200 V200R006C10, V200R006C13, |

## Risk And Classification

**Problem Types:** CWE-20

## NVD Known Affected Configurations (CPE 2.3)

| Type             | Vendor | Product           | Version     | Update | Edition | Language |
|------------------|--------|-------------------|-------------|--------|---------|----------|
| Hardware         | Huawei | Ar120-s           | -           | All    | All     | All      |
| Hardware         | Huawei | Ar120-s           | -           | All    | All     | All      |
| Operating System | Huawei | Ar120-s Firmware  | v200r006c10 | All    | All     | All      |
| Operating System | Huawei | Ar120-s Firmware  | v200r007c00 | All    | All     | All      |
| Operating System | Huawei | Ar120-s Firmware  | v200r008c20 | All    | All     | All      |
| Operating System | Huawei | Ar120-s Firmware  | v200r008c30 | All    | All     | All      |
| Operating System | Huawei | Ar120-s Firmware  | v200r006c10 | All    | All     | All      |
| Operating System | Huawei | Ar120-s Firmware  | v200r007c00 | All    | All     | All      |
| Operating System | Huawei | Ar120-s Firmware  | v200r008c20 | All    | All     | All      |
| Operating System | Huawei | Ar120-s Firmware  | v200r008c30 | All    | All     | All      |
| Hardware         | Huawei | Ar1200            | -           | All    | All     | All      |
| Hardware         | Huawei | Ar1200            | -           | All    | All     | All      |
| Hardware         | Huawei | Ar1200-s          | -           | All    | All     | All      |
| Hardware         | Huawei | Ar1200-s          | -           | All    | All     | All      |
| Operating System | Huawei | Ar1200-s Firmware | v200r006c10 | All    | All     | All      |
| Operating System | Huawei | Ar1200-s Firmware | v200r007c00 | All    | All     | All      |
| Operating System | Huawei | Ar1200-s Firmware | v200r008c20 | All    | All     | All      |

|                  |        |                   |             |     |     |     |
|------------------|--------|-------------------|-------------|-----|-----|-----|
| Operating System | Huawei | Ar1200-s Firmware | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar1200-s Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar1200-s Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar1200-s Firmware | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar1200-s Firmware | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r006c13 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r007c02 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r006c13 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r007c02 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar1200 Firmware   | v200r008c30 | All | All | All |
| Hardware         | Huawei | Ar150             | -           | All | All | All |
| Hardware         | Huawei | Ar150             | -           | All | All | All |
| Hardware         | Huawei | Ar150-s           | -           | All | All | All |
| Hardware         | Huawei | Ar150-s           | -           | All | All | All |
| Operating System | Huawei | Ar150-s Firmware  | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar150-s Firmware  | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar150-s Firmware  | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar150-s Firmware  | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar150-s Firmware  | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar150-s Firmware  | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar150-s Firmware  | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar150-s Firmware  | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar150 Firmware    | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar150 Firmware    | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar150 Firmware    | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar150 Firmware    | v200r007c02 | All | All | All |

|                  |        |                  |             |     |     |     |
|------------------|--------|------------------|-------------|-----|-----|-----|
| Operating System | Huawei | Ar150 Firmware   | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar150 Firmware   | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar150 Firmware   | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar150 Firmware   | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar150 Firmware   | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar150 Firmware   | v200r007c02 | All | All | All |
| Operating System | Huawei | Ar150 Firmware   | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar150 Firmware   | v200r008c30 | All | All | All |
| Hardware         | Huawei | Ar160            | -           | All | All | All |
| Hardware         | Huawei | Ar160            | -           | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r006c12 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r007c02 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r006c12 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r007c02 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar160 Firmware   | v200r008c30 | All | All | All |
| Hardware         | Huawei | Ar200            | -           | All | All | All |
| Hardware         | Huawei | Ar200            | -           | All | All | All |
| Hardware         | Huawei | Ar200-s          | -           | All | All | All |
| Hardware         | Huawei | Ar200-s          | -           | All | All | All |
| Operating System | Huawei | Ar200-s Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar200-s Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar200-s Firmware | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar200-s Firmware | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar200-s Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar200-s Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar200-s Firmware | v200r008c20 | All | All | All |

|                  |        |                   |             |     |     |     |
|------------------|--------|-------------------|-------------|-----|-----|-----|
| Operating System | Huawei | Ar200-s Firmware  | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar200 Firmware    | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar200 Firmware    | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar200 Firmware    | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar200 Firmware    | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar200 Firmware    | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar200 Firmware    | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar200 Firmware    | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar200 Firmware    | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar200 Firmware    | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar200 Firmware    | v200r008c30 | All | All | All |
| Hardware         | Huawei | Ar2200            | -           | All | All | All |
| Hardware         | Huawei | Ar2200            | -           | All | All | All |
| Hardware         | Huawei | Ar2200-s          | -           | All | All | All |
| Hardware         | Huawei | Ar2200-s          | -           | All | All | All |
| Operating System | Huawei | Ar2200-s Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar2200-s Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar2200-s Firmware | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar2200-s Firmware | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar2200-s Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar2200-s Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar2200-s Firmware | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar2200-s Firmware | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r006c13 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r006c16 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r007c02 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r006c13 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r006c16 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware   | v200r007c01 | All | All | All |

|                  |        |                 |             |     |     |     |
|------------------|--------|-----------------|-------------|-----|-----|-----|
| Operating System | Huawei | Ar2200 Firmware | v200r007c02 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar2200 Firmware | v200r008c30 | All | All | All |
| Hardware         | Huawei | Ar3200          | -           | All | All | All |
| Hardware         | Huawei | Ar3200          | -           | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r006c11 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r007c02 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r008c00 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r008c10 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r006c11 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r007c02 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r008c00 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r008c10 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar3200 Firmware | v200r008c30 | All | All | All |
| Hardware         | Huawei | Ar3600          | -           | All | All | All |
| Hardware         | Huawei | Ar3600          | -           | All | All | All |
| Operating System | Huawei | Ar3600 Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar3600 Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar3600 Firmware | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar3600 Firmware | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar3600 Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar3600 Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar3600 Firmware | v200r007c01 | All | All | All |
| Operating System | Huawei | Ar3600 Firmware | v200r008c20 | All | All | All |
| Hardware         | Huawei | Ar510           | -           | All | All | All |
| Hardware         | Huawei | Ar510           | -           | All | All | All |

|                  |        |                        |             |     |     |     |
|------------------|--------|------------------------|-------------|-----|-----|-----|
| Operating System | Huawei | Ar510 Firmware         | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r006c12 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r006c13 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r006c15 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r006c16 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r006c17 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r008c30 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r006c10 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r006c12 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r006c13 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r006c15 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r006c16 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r006c17 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r007c00 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r008c20 | All | All | All |
| Operating System | Huawei | Ar510 Firmware         | v200r008c30 | All | All | All |
| Hardware         | Huawei | Dp300                  | -           | All | All | All |
| Hardware         | Huawei | Dp300                  | -           | All | All | All |
| Operating System | Huawei | Dp300 Firmware         | v500r002c00 | All | All | All |
| Operating System | Huawei | Dp300 Firmware         | v500r002c00 | All | All | All |
| Hardware         | Huawei | Max Presence           | -           | All | All | All |
| Hardware         | Huawei | Max Presence           | -           | All | All | All |
| Operating System | Huawei | Max Presence Firmware  | v100r001c00 | All | All | All |
| Operating System | Huawei | Max Presence Firmware  | v100r001c00 | All | All | All |
| Hardware         | Huawei | Netengine16ex          | -           | All | All | All |
| Hardware         | Huawei | Netengine16ex          | -           | All | All | All |
| Operating System | Huawei | Netengine16ex Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Netengine16ex Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Netengine16ex Firmware | v200r008c20 | All | All | All |
| Operating System | Huawei | Netengine16ex Firmware | v200r008c30 | All | All | All |
| Operating System | Huawei | Netengine16ex Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Netengine16ex Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Netengine16ex Firmware | v200r008c20 | All | All | All |
| Operating System | Huawei | Netengine16ex Firmware | v200r008c30 | All | All | All |

|                  |        |                          |             |     |     |     |
|------------------|--------|--------------------------|-------------|-----|-----|-----|
| Operating System | Huawei | inetengine 16ex Firmware | v200r008c30 | All | All | All |
| Hardware         | Huawei | Rp200                    | -           | All | All | All |
| Hardware         | Huawei | Rp200                    | -           | All | All | All |
| Operating System | Huawei | Rp200 Firmware           | v500r002c00 | All | All | All |
| Operating System | Huawei | Rp200 Firmware           | v600r006c00 | All | All | All |
| Operating System | Huawei | Rp200 Firmware           | v500r002c00 | All | All | All |
| Operating System | Huawei | Rp200 Firmware           | v600r006c00 | All | All | All |
| Hardware         | Huawei | Srg1300                  | -           | All | All | All |
| Hardware         | Huawei | Srg1300                  | -           | All | All | All |
| Operating System | Huawei | Srg1300 Firmware         | v200r006c10 | All | All | All |
| Operating System | Huawei | Srg1300 Firmware         | v200r007c00 | All | All | All |
| Operating System | Huawei | Srg1300 Firmware         | v200r007c02 | All | All | All |
| Operating System | Huawei | Srg1300 Firmware         | v200r008c20 | All | All | All |
| Operating System | Huawei | Srg1300 Firmware         | v200r008c30 | All | All | All |
| Operating System | Huawei | Srg1300 Firmware         | v200r006c10 | All | All | All |
| Operating System | Huawei | Srg1300 Firmware         | v200r007c00 | All | All | All |
| Operating System | Huawei | Srg1300 Firmware         | v200r007c02 | All | All | All |
| Operating System | Huawei | Srg1300 Firmware         | v200r008c20 | All | All | All |
| Operating System | Huawei | Srg1300 Firmware         | v200r008c30 | All | All | All |
| Hardware         | Huawei | Srg2300                  | -           | All | All | All |
| Hardware         | Huawei | Srg2300                  | -           | All | All | All |
| Operating System | Huawei | Srg2300 Firmware         | v200r006c10 | All | All | All |
| Operating System | Huawei | Srg2300 Firmware         | v200r007c00 | All | All | All |
| Operating System | Huawei | Srg2300 Firmware         | v200r007c02 | All | All | All |
| Operating System | Huawei | Srg2300 Firmware         | v200r008c20 | All | All | All |
| Operating System | Huawei | Srg2300 Firmware         | v200r008c30 | All | All | All |
| Operating System | Huawei | Srg2300 Firmware         | v200r006c10 | All | All | All |
| Operating System | Huawei | Srg2300 Firmware         | v200r007c00 | All | All | All |
| Operating System | Huawei | Srg2300 Firmware         | v200r007c02 | All | All | All |
| Operating System | Huawei | Srg2300 Firmware         | v200r008c20 | All | All | All |
| Operating System | Huawei | Srg2300 Firmware         | v200r008c30 | All | All | All |
| Hardware         | Huawei | Srg3300                  | -           | All | All | All |
| Hardware         | Huawei | Srg3300                  | -           | All | All | All |
| Operating System | Huawei | Srg3300 Firmware         | v200r006c10 | All | All | All |
| Operating System | Huawei | Srg3300 Firmware         | v200r007c00 | All | All | All |
| Operating System | Huawei | Srg3300 Firmware         | v200r008c20 | All | All | All |

|                  |        |                  |             |     |     |     |
|------------------|--------|------------------|-------------|-----|-----|-----|
| Operating System | Huawei | Srg3300 Firmware | v200r008c30 | All | All | All |
| Operating System | Huawei | Srg3300 Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Srg3300 Firmware | v200r007c00 | All | All | All |
| Operating System | Huawei | Srg3300 Firmware | v200r008c20 | All | All | All |
| Operating System | Huawei | Srg3300 Firmware | v200r008c30 | All | All | All |
| Hardware         | Huawei | Te30             | -           | All | All | All |
| Hardware         | Huawei | Te30             | -           | All | All | All |
| Operating System | Huawei | Te30 Firmware    | v100r001c02 | All | All | All |
| Operating System | Huawei | Te30 Firmware    | v100r001c10 | All | All | All |
| Operating System | Huawei | Te30 Firmware    | v500r002c00 | All | All | All |
| Operating System | Huawei | Te30 Firmware    | v600r006c00 | All | All | All |
| Operating System | Huawei | Te30 Firmware    | v100r001c02 | All | All | All |
| Operating System | Huawei | Te30 Firmware    | v100r001c10 | All | All | All |
| Operating System | Huawei | Te30 Firmware    | v500r002c00 | All | All | All |
| Operating System | Huawei | Te30 Firmware    | v600r006c00 | All | All | All |
| Hardware         | Huawei | Te40             | -           | All | All | All |
| Hardware         | Huawei | Te40             | -           | All | All | All |
| Operating System | Huawei | Te40 Firmware    | v500r002c00 | All | All | All |
| Operating System | Huawei | Te40 Firmware    | v600r006c00 | All | All | All |
| Operating System | Huawei | Te40 Firmware    | v500r002c00 | All | All | All |
| Operating System | Huawei | Te40 Firmware    | v600r006c00 | All | All | All |
| Hardware         | Huawei | Te50             | -           | All | All | All |
| Hardware         | Huawei | Te50             | -           | All | All | All |
| Operating System | Huawei | Te50 Firmware    | v500r002c00 | All | All | All |
| Operating System | Huawei | Te50 Firmware    | v600r006c00 | All | All | All |
| Operating System | Huawei | Te50 Firmware    | v500r002c00 | All | All | All |
| Operating System | Huawei | Te50 Firmware    | v600r006c00 | All | All | All |
| Hardware         | Huawei | Te60             | -           | All | All | All |
| Hardware         | Huawei | Te60             | -           | All | All | All |
| Operating System | Huawei | Te60 Firmware    | v100r001c01 | All | All | All |
| Operating System | Huawei | Te60 Firmware    | v100r001c10 | All | All | All |
| Operating System | Huawei | Te60 Firmware    | v500r002c00 | All | All | All |
| Operating System | Huawei | Te60 Firmware    | v600r006c00 | All | All | All |
| Operating System | Huawei | Te60 Firmware    | v100r001c01 | All | All | All |
| Operating System | Huawei | Te60 Firmware    | v100r001c10 | All | All | All |

|                  |                        |                                 |             |     |     |     |
|------------------|------------------------|---------------------------------|-------------|-----|-----|-----|
| Operating System | <a href="#">Huawei</a> | <a href="#">Te60 Firmware</a>   | v500r002c00 | All | All | All |
| Operating System | <a href="#">Huawei</a> | <a href="#">Te60 Firmware</a>   | v600r006c00 | All | All | All |
| Hardware         | <a href="#">Huawei</a> | <a href="#">Tp3106</a>          | -           | All | All | All |
| Hardware         | <a href="#">Huawei</a> | <a href="#">Tp3106</a>          | -           | All | All | All |
| Operating System | <a href="#">Huawei</a> | <a href="#">Tp3106 Firmware</a> | v100r002c00 | All | All | All |
| Operating System | <a href="#">Huawei</a> | <a href="#">Tp3106 Firmware</a> | v100r002c00 | All | All | All |
| Hardware         | <a href="#">Huawei</a> | <a href="#">Tp3206</a>          | -           | All | All | All |
| Hardware         | <a href="#">Huawei</a> | <a href="#">Tp3206</a>          | -           | All | All | All |
| Operating System | <a href="#">Huawei</a> | <a href="#">Tp3206 Firmware</a> | v100r002c00 | All | All | All |
| Operating System | <a href="#">Huawei</a> | <a href="#">Tp3206 Firmware</a> | v100r002c10 | All | All | All |
| Operating System | <a href="#">Huawei</a> | <a href="#">Tp3206 Firmware</a> | v100r002c00 | All | All | All |
| Operating System | <a href="#">Huawei</a> | <a href="#">Tp3206 Firmware</a> | v100r002c10 | All | All | All |

## References

| Reference  | Source  | Link   | Tags                |
|--|---------|--|---------------------|
| Security Advisory - Multiple Vulnerabilities in Some Huawei Products | CONFIRM | <a href="http://www.huawei.com">www.huawei.com</a> | Vendor Advisory     |
| CVE Program record   | CVE.ORG | <a href="http://www.cve.org">www.cve.org</a>       | canonical           |
| NVD vulnerability detail   | NVD     | <a href="http://nvd.nist.gov">nvd.nist.gov</a>     | canonical, analysis |

No vendor comments have been submitted for this CVE.

## Legacy QID Mappings

43887 Huawei Router Multiple Vulnerabilities (Huawei-SA-20171213-06-xml-en)

© [CVE.report](#) 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](#) and the authoritative source of CVE content is [MITRE's CVE web site](#). This site includes MITRE data granted under the following [license](#).

**CVE.report and Source URL Uptime Status** [status.cve.report](https://status.cve.report)