



CVE-2018-10660

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

Summary

CVE	CVE-2018-10660
State	PUBLIC
Assigner	cve@mitre.org
Source Priority	CVE Program / NVD first with legacy fallback
Published	2018-06-26 18:29:00 UTC
Updated	2019-10-03 00:03:00 UTC
Description	An issue was discovered in multiple models of Axis IP Cameras. There is Shell Command Injection.

Risk And Classification

Problem Types: CWE-78

NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware	Axis	A1001	-	All	All	All
Hardware	Axis	A1001	-	All	All	All
Operating System	Axis	A1001 Firmware	All	All	All	All
Operating System	Axis	A1001 Firmware	All	All	All	All
Hardware	Axis	A8004-v	-	All	All	All
Hardware	Axis	A8004-v	-	All	All	All
Operating System	Axis	A8004-v Firmware	All	All	All	All
Operating System	Axis	A8004-v Firmware	All	All	All	All
Hardware	Axis	A8105-e	-	All	All	All
Hardware	Axis	A8105-e	-	All	All	All
Operating System	Axis	A8105-e Firmware	All	All	All	All
Operating System	Axis	A8105-e Firmware	All	All	All	All
Hardware	Axis	A9161	-	All	All	All
Hardware	Axis	A9161	-	All	All	All
Operating System	Axis	A9161 Firmware	All	All	All	All
Operating System	Axis	A9161 Firmware	All	All	All	All
Hardware	Axis	A9188	-	All	All	All

Hardware	Axis	A9188	-	All	All	All
Hardware	Axis	A9188-v	-	All	All	All
Hardware	Axis	A9188-v	-	All	All	All
Operating System	Axis	A9188-v Firmware	All	All	All	All
Operating System	Axis	A9188-v Firmware	All	All	All	All
Operating System	Axis	A9188 Firmware	All	All	All	All
Operating System	Axis	A9188 Firmware	All	All	All	All
Hardware	Axis	C1004-e	-	All	All	All
Hardware	Axis	C1004-e	-	All	All	All
Operating System	Axis	C1004-e Firmware	All	All	All	All
Operating System	Axis	C1004-e Firmware	All	All	All	All
Hardware	Axis	C2005	-	All	All	All
Hardware	Axis	C2005	-	All	All	All
Operating System	Axis	C2005 Firmware	All	All	All	All
Operating System	Axis	C2005 Firmware	All	All	All	All
Hardware	Axis	C3003-e	-	All	All	All
Hardware	Axis	C3003-e	-	All	All	All
Operating System	Axis	C3003-e Firmware	All	All	All	All
Operating System	Axis	C3003-e Firmware	All	All	All	All
Hardware	Axis	C8033	-	All	All	All
Hardware	Axis	C8033	-	All	All	All
Operating System	Axis	C8033 Firmware	All	All	All	All
Operating System	Axis	C8033 Firmware	All	All	All	All
Hardware	Axis	Companion Bullet Le	-	All	All	All
Hardware	Axis	Companion Bullet Le	-	All	All	All
Operating System	Axis	Companion Bullet Le Firmware	All	All	All	All
Operating System	Axis	Companion Bullet Le Firmware	All	All	All	All
Hardware	Axis	Companion C360	-	All	All	All
Hardware	Axis	Companion C360	-	All	All	All
Operating System	Axis	Companion C360 Firmware	All	All	All	All
Operating System	Axis	Companion C360 Firmware	All	All	All	All
Hardware	Axis	Companion Cube L	-	All	All	All
Hardware	Axis	Companion Cube L	-	All	All	All
Hardware	Axis	Companion Cube Lw	-	All	All	All
Hardware	Axis	Companion Cube Lw	-	All	All	All
Operating System	Axis	Companion Cube Lw Firmware	All	All	All	All

Operating System	Axis	Companion Cube Lw Firmware	All	All	All	All
Operating System	Axis	Companion Cube Lw Firmware	All	All	All	All
Operating System	Axis	Companion Cube L Firmware	All	All	All	All
Operating System	Axis	Companion Cube L Firmware	All	All	All	All
Hardware	Axis	Companion Dome V	-	All	All	All
Hardware	Axis	Companion Dome V	-	All	All	All
Operating System	Axis	Companion Dome V Firmware	All	All	All	All
Operating System	Axis	Companion Dome V Firmware	All	All	All	All
Hardware	Axis	Companion Dome Wv	-	All	All	All
Hardware	Axis	Companion Dome Wv	-	All	All	All
Operating System	Axis	Companion Dome Wv Firmware	All	All	All	All
Operating System	Axis	Companion Dome Wv Firmware	All	All	All	All
Hardware	Axis	Companion Eye L	-	All	All	All
Hardware	Axis	Companion Eye L	-	All	All	All
Hardware	Axis	Companion Eye Lve	-	All	All	All
Hardware	Axis	Companion Eye Lve	-	All	All	All
Operating System	Axis	Companion Eye Lve Firmware	All	All	All	All
Operating System	Axis	Companion Eye Lve Firmware	All	All	All	All
Operating System	Axis	Companion Eye L Firmware	All	All	All	All
Operating System	Axis	Companion Eye L Firmware	All	All	All	All
Hardware	Axis	Companion Recorder 4ch	-	All	All	All
Hardware	Axis	Companion Recorder 4ch	-	All	All	All
Operating System	Axis	Companion Recorder 4ch Firmware	All	All	All	All
Operating System	Axis	Companion Recorder 4ch Firmware	All	All	All	All
Hardware	Axis	Companion Recorder 8ch	-	All	All	All
Hardware	Axis	Companion Recorder 8ch	-	All	All	All
Operating System	Axis	Companion Recorder 8ch Firmware	All	All	All	All
Operating System	Axis	Companion Recorder 8ch Firmware	All	All	All	All
Hardware	Axis	D201-s Xpt Q6055	-	All	All	All
Hardware	Axis	D201-s Xpt Q6055	-	All	All	All
Operating System	Axis	D201-s Xpt Q6055 Firmware	All	All	All	All
Operating System	Axis	D201-s Xpt Q6055 Firmware	All	All	All	All
Hardware	Axis	D2050-ve	-	All	All	All
Hardware	Axis	D2050-ve	-	All	All	All
Operating System	Axis	D2050-ve Firmware	All	All	All	All
Operating System	Axis	D2050-ve Firmware	All	All	All	All

Hardware	Axis	F34 Main Unit	-	All	All	All
Hardware	Axis	F34 Main Unit	-	All	All	All
Operating System	Axis	F34 Main Unit Firmware	All	All	All	All
Operating System	Axis	F34 Main Unit Firmware	All	All	All	All
Hardware	Axis	F41 Main Unit	-	All	All	All
Hardware	Axis	F41 Main Unit	-	All	All	All
Operating System	Axis	F41 Main Unit Firmware	All	All	All	All
Operating System	Axis	F41 Main Unit Firmware	All	All	All	All
Hardware	Axis	F44 Dual Audio Input	-	All	All	All
Hardware	Axis	F44 Dual Audio Input	-	All	All	All
Operating System	Axis	F44 Dual Audio Input Firmware	All	All	All	All
Operating System	Axis	F44 Dual Audio Input Firmware	All	All	All	All
Hardware	Axis	F44 Main Unit	-	All	All	All
Hardware	Axis	F44 Main Unit	-	All	All	All
Operating System	Axis	F44 Main Unit Firmware	All	All	All	All
Operating System	Axis	F44 Main Unit Firmware	All	All	All	All
Hardware	Axis	Fa54 Main Unit	-	All	All	All
Hardware	Axis	Fa54 Main Unit	-	All	All	All
Operating System	Axis	Fa54 Main Unit Firmware	All	All	All	All
Operating System	Axis	Fa54 Main Unit Firmware	All	All	All	All
Hardware	Axis	M1004-w	-	All	All	All
Hardware	Axis	M1004-w	-	All	All	All
Operating System	Axis	M1004-w Firmware	All	All	All	All
Operating System	Axis	M1004-w Firmware	All	All	All	All
Hardware	Axis	M1013	-	All	All	All
Hardware	Axis	M1013	-	All	All	All
Operating System	Axis	M1013 Firmware	All	All	All	All
Operating System	Axis	M1013 Firmware	All	All	All	All
Hardware	Axis	M1014	-	All	All	All
Hardware	Axis	M1014	-	All	All	All
Operating System	Axis	M1014 Firmware	All	All	All	All
Operating System	Axis	M1014 Firmware	All	All	All	All
Hardware	Axis	M1025	-	All	All	All
Hardware	Axis	M1025	-	All	All	All
Operating System	Axis	M1025 Firmware	All	All	All	All

Operating System	Axis	M1025 Firmware	All	All	All	All
Hardware	Axis	M1033-w	-	All	All	All
Hardware	Axis	M1033-w	-	All	All	All
Operating System	Axis	M1033-w Firmware	All	All	All	All
Operating System	Axis	M1033-w Firmware	All	All	All	All
Hardware	Axis	M1034-w	-	All	All	All
Hardware	Axis	M1034-w	-	All	All	All
Operating System	Axis	M1034-w Firmware	All	All	All	All
Operating System	Axis	M1034-w Firmware	All	All	All	All
Hardware	Axis	M1045-lw	-	All	All	All
Hardware	Axis	M1045-lw	-	All	All	All
Operating System	Axis	M1045-lw Firmware	All	All	All	All
Operating System	Axis	M1045-lw Firmware	All	All	All	All
Hardware	Axis	M1054	-	All	All	All
Hardware	Axis	M1054	-	All	All	All
Operating System	Axis	M1054 Firmware	All	All	All	All
Operating System	Axis	M1054 Firmware	All	All	All	All
Hardware	Axis	M1065-l	-	All	All	All
Hardware	Axis	M1065-l	-	All	All	All
Hardware	Axis	M1065-lw	-	All	All	All
Hardware	Axis	M1065-lw	-	All	All	All
Operating System	Axis	M1065-lw Firmware	All	All	All	All
Operating System	Axis	M1065-lw Firmware	All	All	All	All
Operating System	Axis	M1065-l Firmware	All	All	All	All
Operating System	Axis	M1065-l Firmware	All	All	All	All
Hardware	Axis	M1103	-	All	All	All
Hardware	Axis	M1103	-	All	All	All
Operating System	Axis	M1103 Firmware	All	All	All	All
Operating System	Axis	M1103 Firmware	All	All	All	All
Hardware	Axis	M1104	-	All	All	All
Hardware	Axis	M1104	-	All	All	All
Operating System	Axis	M1104 Firmware	All	All	All	All
Operating System	Axis	M1104 Firmware	All	All	All	All
Hardware	Axis	M1113	-	All	All	All
Hardware	Axis	M1113	-	All	All	All
Hardware	Axis	M1113-2	-	All	All	All

Hardware	Axis	M1113-e	-	All	All	All
Hardware	Axis	M1113-e	-	All	All	All
Operating System	Axis	M1113-e Firmware	All	All	All	All
Operating System	Axis	M1113-e Firmware	All	All	All	All
Operating System	Axis	M1113 Firmware	All	All	All	All
Operating System	Axis	M1113 Firmware	All	All	All	All
Hardware	Axis	M1114	-	All	All	All
Hardware	Axis	M1114	-	All	All	All
Hardware	Axis	M1114-e	-	All	All	All
Hardware	Axis	M1114-e	-	All	All	All
Operating System	Axis	M1114-e Firmware	All	All	All	All
Operating System	Axis	M1114-e Firmware	All	All	All	All
Operating System	Axis	M1114 Firmware	All	All	All	All
Operating System	Axis	M1114 Firmware	All	All	All	All
Hardware	Axis	M1124	-	All	All	All
Hardware	Axis	M1124	-	All	All	All
Hardware	Axis	M1124-e	-	All	All	All
Hardware	Axis	M1124-e	-	All	All	All
Operating System	Axis	M1124-e Firmware	All	All	All	All
Operating System	Axis	M1124-e Firmware	All	All	All	All
Operating System	Axis	M1124 Firmware	All	All	All	All
Operating System	Axis	M1124 Firmware	All	All	All	All
Hardware	Axis	M1125	-	All	All	All
Hardware	Axis	M1125	-	All	All	All
Hardware	Axis	M1125-e	-	All	All	All
Hardware	Axis	M1125-e	-	All	All	All
Operating System	Axis	M1125-e Firmware	All	All	All	All
Operating System	Axis	M1125-e Firmware	All	All	All	All
Operating System	Axis	M1125 Firmware	All	All	All	All
Operating System	Axis	M1125 Firmware	All	All	All	All
Hardware	Axis	M1143-l	-	All	All	All
Hardware	Axis	M1143-l	-	All	All	All
Operating System	Axis	M1143-l Firmware	All	All	All	All
Operating System	Axis	M1143-l Firmware	All	All	All	All
Hardware	Axis	M1144-l	-	All	All	All
Hardware	Axis	M1144-l	-	All	All	All

Operating System	Axis	M1144-I Firmware	All	All	All	All
Operating System	Axis	M1144-I Firmware	All	All	All	All
Hardware	Axis	M1145	-	All	All	All
Hardware	Axis	M1145	-	All	All	All
Hardware	Axis	M1145-I	-	All	All	All
Hardware	Axis	M1145-I	-	All	All	All
Operating System	Axis	M1145-I Firmware	All	All	All	All
Operating System	Axis	M1145-I Firmware	All	All	All	All
Operating System	Axis	M1145 Firmware	All	All	All	All
Operating System	Axis	M1145 Firmware	All	All	All	All
Hardware	Axis	M2014-e	-	All	All	All
Hardware	Axis	M2014-e	-	All	All	All
Operating System	Axis	M2014-e Firmware	All	All	All	All
Operating System	Axis	M2014-e Firmware	All	All	All	All
Hardware	Axis	M2025-le	-	All	All	All
Hardware	Axis	M2025-le	-	All	All	All
Operating System	Axis	M2025-le Firmware	All	All	All	All
Operating System	Axis	M2025-le Firmware	All	All	All	All
Hardware	Axis	M2026-le	-	All	All	All
Hardware	Axis	M2026-le	-	All	All	All
Operating System	Axis	M2026-le Firmware	All	All	All	All
Operating System	Axis	M2026-le Firmware	All	All	All	All
Hardware	Axis	M2026-le Mk li	-	All	All	All
Hardware	Axis	M2026-le Mk li	-	All	All	All
Operating System	Axis	M2026-le Mk li Firmware	All	All	All	All
Operating System	Axis	M2026-le Mk li Firmware	All	All	All	All
Hardware	Axis	M3004-v	-	All	All	All
Hardware	Axis	M3004-v	-	All	All	All
Operating System	Axis	M3004-v Firmware	All	All	All	All
Operating System	Axis	M3004-v Firmware	All	All	All	All
Hardware	Axis	M3005-v	-	All	All	All
Hardware	Axis	M3005-v	-	All	All	All
Operating System	Axis	M3005-v Firmware	All	All	All	All
Operating System	Axis	M3005-v Firmware	All	All	All	All
Hardware	Axis	M3006-v	-	All	All	All

Hardware	Axis	M3006-v	-	All	All	All
Operating System	Axis	M3006-v Firmware	All	All	All	All
Operating System	Axis	M3006-v Firmware	All	All	All	All
Hardware	Axis	M3007-p	-	All	All	All
Hardware	Axis	M3007-p	-	All	All	All
Hardware	Axis	M3007-pv	-	All	All	All
Hardware	Axis	M3007-pv	-	All	All	All
Operating System	Axis	M3007-pv Firmware	All	All	All	All
Operating System	Axis	M3007-pv Firmware	All	All	All	All
Operating System	Axis	M3007-p Firmware	All	All	All	All
Operating System	Axis	M3007-p Firmware	All	All	All	All
Hardware	Axis	M3014	-	All	All	All
Hardware	Axis	M3014	-	All	All	All
Operating System	Axis	M3014 Firmware	All	All	All	All
Operating System	Axis	M3014 Firmware	All	All	All	All
Hardware	Axis	M3015	-	All	All	All
Hardware	Axis	M3015	-	All	All	All
Operating System	Axis	M3015 Firmware	All	All	All	All
Operating System	Axis	M3015 Firmware	All	All	All	All
Hardware	Axis	M3016	-	All	All	All
Hardware	Axis	M3016	-	All	All	All
Operating System	Axis	M3016 Firmware	All	All	All	All
Operating System	Axis	M3016 Firmware	All	All	All	All
Hardware	Axis	M3024-lve	-	All	All	All
Hardware	Axis	M3024-lve	-	All	All	All
Operating System	Axis	M3024-lve Firmware	All	All	All	All
Operating System	Axis	M3024-lve Firmware	All	All	All	All
Hardware	Axis	M3025-ve	-	All	All	All
Hardware	Axis	M3025-ve	-	All	All	All
Operating System	Axis	M3025-ve Firmware	All	All	All	All
Operating System	Axis	M3025-ve Firmware	All	All	All	All
Hardware	Axis	M3026-ve	-	All	All	All
Hardware	Axis	M3026-ve	-	All	All	All
Operating System	Axis	M3026-ve Firmware	All	All	All	All
Operating System	Axis	M3026-ve Firmware	All	All	All	All
Hardware	Axis	M3027-nve	-	All	All	All

Hardware	Axis	M3027-pve	-	All	All	All
Hardware	Axis	M3027-pve	-	All	All	All
Operating System	Axis	M3027-pve Firmware	All	All	All	All
Operating System	Axis	M3027-pve Firmware	All	All	All	All
Hardware	Axis	M3037-pve	-	All	All	All
Hardware	Axis	M3037-pve	-	All	All	All
Operating System	Axis	M3037-pve Firmware	All	All	All	All
Operating System	Axis	M3037-pve Firmware	All	All	All	All
Hardware	Axis	M3044-v	-	All	All	All
Hardware	Axis	M3044-v	-	All	All	All
Operating System	Axis	M3044-v Firmware	All	All	All	All
Operating System	Axis	M3044-v Firmware	All	All	All	All
Hardware	Axis	M3044-wv	-	All	All	All
Hardware	Axis	M3044-wv	-	All	All	All
Operating System	Axis	M3044-wv Firmware	All	All	All	All
Operating System	Axis	M3044-wv Firmware	All	All	All	All
Hardware	Axis	M3045-v	-	All	All	All
Hardware	Axis	M3045-v	-	All	All	All
Operating System	Axis	M3045-v Firmware	All	All	All	All
Operating System	Axis	M3045-v Firmware	All	All	All	All
Hardware	Axis	M3045-wv	-	All	All	All
Hardware	Axis	M3045-wv	-	All	All	All
Operating System	Axis	M3045-wv Firmware	All	All	All	All
Operating System	Axis	M3045-wv Firmware	All	All	All	All
Hardware	Axis	M3046-v	-	All	All	All
Hardware	Axis	M3046-v	-	All	All	All
Hardware	Axis	M3046-v 1.8mm	-	All	All	All
Hardware	Axis	M3046-v 1.8mm	-	All	All	All
Operating System	Axis	M3046-v 1.8mm Firmware	All	All	All	All
Operating System	Axis	M3046-v 1.8mm Firmware	All	All	All	All
Operating System	Axis	M3046-v Firmware	All	All	All	All
Operating System	Axis	M3046-v Firmware	All	All	All	All
Hardware	Axis	M3047-p	-	All	All	All
Hardware	Axis	M3047-p	-	All	All	All
Operating System	Axis	M3047-p Firmware	All	All	All	All
Operating System	Axis	M3047-p Firmware	All	All	All	All

Hardware	Axis	M3048-p	-	All	All	All
Hardware	Axis	M3048-p	-	All	All	All
Operating System	Axis	M3048-p Firmware	All	All	All	All
Operating System	Axis	M3048-p Firmware	All	All	All	All
Hardware	Axis	M3104-l	-	All	All	All
Hardware	Axis	M3104-l	-	All	All	All
Hardware	Axis	M3104-lve	-	All	All	All
Hardware	Axis	M3104-lve	-	All	All	All
Operating System	Axis	M3104-lve Firmware	All	All	All	All
Operating System	Axis	M3104-lve Firmware	All	All	All	All
Operating System	Axis	M3104-l Firmware	All	All	All	All
Operating System	Axis	M3104-l Firmware	All	All	All	All
Hardware	Axis	M3105-l	-	All	All	All
Hardware	Axis	M3105-l	-	All	All	All
Hardware	Axis	M3105-lve	-	All	All	All
Hardware	Axis	M3105-lve	-	All	All	All
Operating System	Axis	M3105-lve Firmware	All	All	All	All
Operating System	Axis	M3105-lve Firmware	All	All	All	All
Operating System	Axis	M3105-l Firmware	All	All	All	All
Operating System	Axis	M3105-l Firmware	All	All	All	All
Hardware	Axis	M3106-l	-	All	All	All
Hardware	Axis	M3106-l	-	All	All	All
Hardware	Axis	M3106-lve	-	All	All	All
Hardware	Axis	M3106-lve	-	All	All	All
Operating System	Axis	M3106-lve Firmware	All	All	All	All
Operating System	Axis	M3106-lve Firmware	All	All	All	All
Hardware	Axis	M3106-lve Mk li	-	All	All	All
Hardware	Axis	M3106-lve Mk li	-	All	All	All
Operating System	Axis	M3106-lve Mk li Firmware	All	All	All	All
Operating System	Axis	M3106-lve Mk li Firmware	All	All	All	All
Operating System	Axis	M3106-l Firmware	All	All	All	All
Operating System	Axis	M3106-l Firmware	All	All	All	All
Hardware	Axis	M3106-l Mk li	-	All	All	All
Hardware	Axis	M3106-l Mk li	-	All	All	All
Operating System	Axis	M3106-l Mk li Firmware	All	All	All	All

Operating System	Axis	M3106-I Mk II Firmware	All	All	All	All
Hardware	Axis	M3113-r	-	All	All	All
Hardware	Axis	M3113-r	-	All	All	All
Operating System	Axis	M3113-r Firmware	All	All	All	All
Operating System	Axis	M3113-r Firmware	All	All	All	All
Hardware	Axis	M3113-ve	-	All	All	All
Hardware	Axis	M3113-ve	-	All	All	All
Operating System	Axis	M3113-ve Firmware	All	All	All	All
Operating System	Axis	M3113-ve Firmware	All	All	All	All
Hardware	Axis	M3114-r	-	All	All	All
Hardware	Axis	M3114-r	-	All	All	All
Operating System	Axis	M3114-r Firmware	All	All	All	All
Operating System	Axis	M3114-r Firmware	All	All	All	All
Hardware	Axis	M3114-ve	-	All	All	All
Hardware	Axis	M3114-ve	-	All	All	All
Operating System	Axis	M3114-ve Firmware	All	All	All	All
Operating System	Axis	M3114-ve Firmware	All	All	All	All
Hardware	Axis	M3203	-	All	All	All
Hardware	Axis	M3203	-	All	All	All
Hardware	Axis	M3203-v	-	All	All	All
Hardware	Axis	M3203-v	-	All	All	All
Operating System	Axis	M3203-v Firmware	All	All	All	All
Operating System	Axis	M3203-v Firmware	All	All	All	All
Operating System	Axis	M3203 Firmware	All	All	All	All
Operating System	Axis	M3203 Firmware	All	All	All	All
Hardware	Axis	M3204	-	All	All	All
Hardware	Axis	M3204	-	All	All	All
Hardware	Axis	M3204-v	-	All	All	All
Hardware	Axis	M3204-v	-	All	All	All
Operating System	Axis	M3204-v Firmware	All	All	All	All
Operating System	Axis	M3204-v Firmware	All	All	All	All
Operating System	Axis	M3204 Firmware	All	All	All	All
Operating System	Axis	M3204 Firmware	All	All	All	All
Hardware	Axis	M5013	-	All	All	All
Hardware	Axis	M5013	-	All	All	All
Hardware	Axis	M5013-v	-	All	All	All

Hardware	Axis	M5013-v	-	All	All	All
Operating System	Axis	M5013-v Firmware	All	All	All	All
Operating System	Axis	M5013-v Firmware	All	All	All	All
Operating System	Axis	M5013 Firmware	All	All	All	All
Operating System	Axis	M5013 Firmware	All	All	All	All
Hardware	Axis	M5014	-	All	All	All
Hardware	Axis	M5014	-	All	All	All
Hardware	Axis	M5014-v	-	All	All	All
Hardware	Axis	M5014-v	-	All	All	All
Operating System	Axis	M5014-v Firmware	All	All	All	All
Operating System	Axis	M5014-v Firmware	All	All	All	All
Operating System	Axis	M5014 Firmware	All	All	All	All
Operating System	Axis	M5014 Firmware	All	All	All	All
Hardware	Axis	M5054	-	All	All	All
Hardware	Axis	M5054	-	All	All	All
Operating System	Axis	M5054 Firmware	All	All	All	All
Operating System	Axis	M5054 Firmware	All	All	All	All
Hardware	Axis	M5055	-	All	All	All
Hardware	Axis	M5055	-	All	All	All
Operating System	Axis	M5055 Firmware	All	All	All	All
Operating System	Axis	M5055 Firmware	All	All	All	All
Hardware	Axis	M5065	-	All	All	All
Hardware	Axis	M5065	-	All	All	All
Operating System	Axis	M5065 Firmware	All	All	All	All
Operating System	Axis	M5065 Firmware	All	All	All	All
Hardware	Axis	M5525-e	-	All	All	All
Hardware	Axis	M5525-e	-	All	All	All
Operating System	Axis	M5525-e Firmware	All	All	All	All
Operating System	Axis	M5525-e Firmware	All	All	All	All
Hardware	Axis	M7010	-	All	All	All
Hardware	Axis	M7010	-	All	All	All
Operating System	Axis	M7010 Firmware	All	All	All	All
Operating System	Axis	M7010 Firmware	All	All	All	All
Hardware	Axis	M7011	-	All	All	All
Hardware	Axis	M7011	-	All	All	All

Operating System	Axis	M7011 Firmware	All	All	All	All
Operating System	Axis	M7011 Firmware	All	All	All	All
Hardware	Axis	M7014	-	All	All	All
Hardware	Axis	M7014	-	All	All	All
Operating System	Axis	M7014 Firmware	All	All	All	All
Operating System	Axis	M7014 Firmware	All	All	All	All
Hardware	Axis	M7016	-	All	All	All
Hardware	Axis	M7016	-	All	All	All
Operating System	Axis	M7016 Firmware	All	All	All	All
Operating System	Axis	M7016 Firmware	All	All	All	All
Hardware	Axis	P1125-z	-	All	All	All
Hardware	Axis	P1125-z	-	All	All	All
Hardware	Axis	P1125-zl	-	All	All	All
Hardware	Axis	P1125-zl	-	All	All	All
Operating System	Axis	P1125-zl Firmware	All	All	All	All
Operating System	Axis	P1125-zl Firmware	All	All	All	All
Operating System	Axis	P1125-z Firmware	All	All	All	All
Operating System	Axis	P1125-z Firmware	All	All	All	All
Hardware	Axis	P1126-z	-	All	All	All
Hardware	Axis	P1126-z	-	All	All	All
Hardware	Axis	P1126-zl	-	All	All	All
Hardware	Axis	P1126-zl	-	All	All	All
Operating System	Axis	P1126-zl Firmware	All	All	All	All
Operating System	Axis	P1126-zl Firmware	All	All	All	All
Operating System	Axis	P1126-z Firmware	All	All	All	All
Operating System	Axis	P1126-z Firmware	All	All	All	All
Hardware	Axis	P1204	-	All	All	All
Hardware	Axis	P1204	-	All	All	All
Operating System	Axis	P1204 Firmware	All	All	All	All
Operating System	Axis	P1204 Firmware	All	All	All	All
Hardware	Axis	P1214	-	All	All	All
Hardware	Axis	P1214	-	All	All	All
Hardware	Axis	P1214-e	-	All	All	All
Hardware	Axis	P1214-e	-	All	All	All
Operating System	Axis	P1214-e Firmware	All	All	All	All

Operating System	Axis	P1214-e Firmware	All	All	All	All
Operating System	Axis	P1214 Firmware	All	All	All	All
Operating System	Axis	P1214 Firmware	All	All	All	All
Hardware	Axis	P1224-e	-	All	All	All
Hardware	Axis	P1224-e	-	All	All	All
Operating System	Axis	P1224-e Firmware	All	All	All	All
Operating System	Axis	P1224-e Firmware	All	All	All	All
Hardware	Axis	P1244	-	All	All	All
Hardware	Axis	P1244	-	All	All	All
Operating System	Axis	P1244 Firmware	All	All	All	All
Operating System	Axis	P1244 Firmware	All	All	All	All
Hardware	Axis	P1245	-	All	All	All
Hardware	Axis	P1245	-	All	All	All
Operating System	Axis	P1245 Firmware	All	All	All	All
Operating System	Axis	P1245 Firmware	All	All	All	All
Hardware	Axis	P1254	-	All	All	All
Hardware	Axis	P1254	-	All	All	All
Operating System	Axis	P1254 Firmware	All	All	All	All
Operating System	Axis	P1254 Firmware	All	All	All	All
Hardware	Axis	P1264	-	All	All	All
Hardware	Axis	P1264	-	All	All	All
Operating System	Axis	P1264 Firmware	All	All	All	All
Operating System	Axis	P1264 Firmware	All	All	All	All
Hardware	Axis	P1265	-	All	All	All
Hardware	Axis	P1265	-	All	All	All
Operating System	Axis	P1265 Firmware	All	All	All	All
Operating System	Axis	P1265 Firmware	All	All	All	All
Hardware	Axis	P1275	-	All	All	All
Hardware	Axis	P1275	-	All	All	All
Operating System	Axis	P1275 Firmware	All	All	All	All
Operating System	Axis	P1275 Firmware	All	All	All	All
Hardware	Axis	P1280	-	All	All	All
Hardware	Axis	P1280	-	All	All	All
Operating System	Axis	P1280 Firmware	All	All	All	All
Operating System	Axis	P1280 Firmware	All	All	All	All
Hardware	Axis	P1290	-	All	All	All

Hardware	Axis	P1290	-	All	All	All
Operating System	Axis	P1290 Firmware	All	All	All	All
Operating System	Axis	P1290 Firmware	All	All	All	All
Hardware	Axis	P1325-z	-	All	All	All
Hardware	Axis	P1325-z	-	All	All	All
Operating System	Axis	P1325-z Firmware	7.10.1.1	All	All	All
Operating System	Axis	P1325-z Firmware	7.10.1.1	All	All	All
Hardware	Axis	P1343	-	All	All	All
Hardware	Axis	P1343	-	All	All	All
Hardware	Axis	P1343-e	-	All	All	All
Hardware	Axis	P1343-e	-	All	All	All
Operating System	Axis	P1343-e Firmware	All	All	All	All
Operating System	Axis	P1343-e Firmware	All	All	All	All
Operating System	Axis	P1343 Firmware	All	All	All	All
Operating System	Axis	P1343 Firmware	All	All	All	All
Hardware	Axis	P1344	-	All	All	All
Hardware	Axis	P1344	-	All	All	All
Hardware	Axis	P1344-e	-	All	All	All
Hardware	Axis	P1344-e	-	All	All	All
Operating System	Axis	P1344-e Firmware	All	All	All	All
Operating System	Axis	P1344-e Firmware	All	All	All	All
Operating System	Axis	P1344 Firmware	All	All	All	All
Operating System	Axis	P1344 Firmware	All	All	All	All
Hardware	Axis	P1346	-	All	All	All
Hardware	Axis	P1346	-	All	All	All
Hardware	Axis	P1346-e	-	All	All	All
Hardware	Axis	P1346-e	-	All	All	All
Operating System	Axis	P1346-e Firmware	All	All	All	All
Operating System	Axis	P1346-e Firmware	All	All	All	All
Operating System	Axis	P1346 Firmware	All	All	All	All
Operating System	Axis	P1346 Firmware	All	All	All	All
Hardware	Axis	P1347	-	All	All	All
Hardware	Axis	P1347	-	All	All	All
Hardware	Axis	P1347-e	-	All	All	All
Hardware	Axis	P1347-e	-	All	All	All

Operating System	Axis	P1347-e Firmware	All	All	All	All
Operating System	Axis	P1347-e Firmware	All	All	All	All
Operating System	Axis	P1347 Firmware	All	All	All	All
Operating System	Axis	P1347 Firmware	All	All	All	All
Hardware	Axis	P1353	-	All	All	All
Hardware	Axis	P1353	-	All	All	All
Hardware	Axis	P1353-e	-	All	All	All
Hardware	Axis	P1353-e	-	All	All	All
Operating System	Axis	P1353-e Firmware	All	All	All	All
Operating System	Axis	P1353-e Firmware	All	All	All	All
Operating System	Axis	P1353 Firmware	All	All	All	All
Operating System	Axis	P1353 Firmware	All	All	All	All
Hardware	Axis	P1354	-	All	All	All
Hardware	Axis	P1354	-	All	All	All
Hardware	Axis	P1354-e	-	All	All	All
Hardware	Axis	P1354-e	-	All	All	All
Operating System	Axis	P1354-e Firmware	All	All	All	All
Operating System	Axis	P1354-e Firmware	All	All	All	All
Operating System	Axis	P1354 Firmware	All	All	All	All
Operating System	Axis	P1354 Firmware	All	All	All	All
Hardware	Axis	P1355	-	All	All	All
Hardware	Axis	P1355	-	All	All	All
Hardware	Axis	P1355-e	-	All	All	All
Hardware	Axis	P1355-e	-	All	All	All
Operating System	Axis	P1355-e Firmware	All	All	All	All
Operating System	Axis	P1355-e Firmware	All	All	All	All
Operating System	Axis	P1355 Firmware	All	All	All	All
Operating System	Axis	P1355 Firmware	All	All	All	All
Hardware	Axis	P1357	-	All	All	All
Hardware	Axis	P1357	-	All	All	All
Hardware	Axis	P1357-e	-	All	All	All
Hardware	Axis	P1357-e	-	All	All	All
Operating System	Axis	P1357-e Firmware	All	All	All	All
Operating System	Axis	P1357-e Firmware	All	All	All	All
Operating System	Axis	P1357 Firmware	All	All	All	All

Operating System	Axis	P1357 Firmware	All	All	All	All
Hardware	Axis	P1364	-	All	All	All
Hardware	Axis	P1364	-	All	All	All
Hardware	Axis	P1364-e	-	All	All	All
Hardware	Axis	P1364-e	-	All	All	All
Operating System	Axis	P1364-e Firmware	All	All	All	All
Operating System	Axis	P1364-e Firmware	All	All	All	All
Operating System	Axis	P1364 Firmware	All	All	All	All
Operating System	Axis	P1364 Firmware	All	All	All	All
Hardware	Axis	P1365	-	All	All	All
Hardware	Axis	P1365	-	All	All	All
Hardware	Axis	P1365-e	-	All	All	All
Hardware	Axis	P1365-e	-	All	All	All
Operating System	Axis	P1365-e Firmware	All	All	All	All
Operating System	Axis	P1365-e Firmware	All	All	All	All
Hardware	Axis	P1365-e Mk li	-	All	All	All
Hardware	Axis	P1365-e Mk li	-	All	All	All
Operating System	Axis	P1365-e Mk li Firmware	All	All	All	All
Operating System	Axis	P1365-e Mk li Firmware	All	All	All	All
Operating System	Axis	P1365 Firmware	All	All	All	All
Operating System	Axis	P1365 Firmware	All	All	All	All
Hardware	Axis	P1365 Mk li	-	All	All	All
Hardware	Axis	P1365 Mk li	-	All	All	All
Operating System	Axis	P1365 Mk li Firmware	All	All	All	All
Operating System	Axis	P1365 Mk li Firmware	All	All	All	All
Hardware	Axis	P1367	-	All	All	All
Hardware	Axis	P1367	-	All	All	All
Hardware	Axis	P1367-e	-	All	All	All
Hardware	Axis	P1367-e	-	All	All	All
Operating System	Axis	P1367-e Firmware	All	All	All	All
Operating System	Axis	P1367-e Firmware	All	All	All	All
Operating System	Axis	P1367 Firmware	All	All	All	All
Operating System	Axis	P1367 Firmware	All	All	All	All
Hardware	Axis	P1368-e	-	All	All	All
Hardware	Axis	P1368-e	-	All	All	All
Operating System	Axis	P1368-e Firmware	All	All	All	All

Operating System	Axis	P1368-e Firmware	All	All	All	All
Hardware	Axis	P1405-e	-	All	All	All
Hardware	Axis	P1405-e	-	All	All	All
Operating System	Axis	P1405-e Firmware	All	All	All	All
Operating System	Axis	P1405-e Firmware	All	All	All	All
Hardware	Axis	P1405-le	-	All	All	All
Hardware	Axis	P1405-le	-	All	All	All
Operating System	Axis	P1405-le Firmware	All	All	All	All
Operating System	Axis	P1405-le Firmware	All	All	All	All
Hardware	Axis	P1405-le Mk li	-	All	All	All
Hardware	Axis	P1405-le Mk li	-	All	All	All
Operating System	Axis	P1405-le Mk li Firmware	All	All	All	All
Operating System	Axis	P1405-le Mk li Firmware	All	All	All	All
Hardware	Axis	P1425-e	-	All	All	All
Hardware	Axis	P1425-e	-	All	All	All
Operating System	Axis	P1425-e Firmware	All	All	All	All
Operating System	Axis	P1425-e Firmware	All	All	All	All
Hardware	Axis	P1425-le	-	All	All	All
Hardware	Axis	P1425-le	-	All	All	All
Operating System	Axis	P1425-le Firmware	All	All	All	All
Operating System	Axis	P1425-le Firmware	All	All	All	All
Hardware	Axis	P1425-le Mk li	-	All	All	All
Hardware	Axis	P1425-le Mk li	-	All	All	All
Operating System	Axis	P1425-le Mk li Firmware	All	All	All	All
Operating System	Axis	P1425-le Mk li Firmware	All	All	All	All
Hardware	Axis	P1427-e	-	All	All	All
Hardware	Axis	P1427-e	-	All	All	All
Operating System	Axis	P1427-e Firmware	All	All	All	All
Operating System	Axis	P1427-e Firmware	All	All	All	All
Hardware	Axis	P1427-le	-	All	All	All
Hardware	Axis	P1427-le	-	All	All	All
Operating System	Axis	P1427-le Firmware	All	All	All	All
Operating System	Axis	P1427-le Firmware	All	All	All	All
Hardware	Axis	P1428-e	-	All	All	All
Hardware	Axis	P1428-e	-	All	All	All

Operating System	Axis	P1428-e Firmware	All	All	All	All
Operating System	Axis	P1428-e Firmware	All	All	All	All
Hardware	Axis	P1435-e	-	All	All	All
Hardware	Axis	P1435-e	-	All	All	All
Operating System	Axis	P1435-e Firmware	All	All	All	All
Operating System	Axis	P1435-e Firmware	All	All	All	All
Hardware	Axis	P1435-le	-	All	All	All
Hardware	Axis	P1435-le	-	All	All	All
Operating System	Axis	P1435-le Firmware	All	All	All	All
Operating System	Axis	P1435-le Firmware	All	All	All	All
Hardware	Axis	P1447-le	-	All	All	All
Hardware	Axis	P1447-le	-	All	All	All
Operating System	Axis	P1447-le Firmware	All	All	All	All
Operating System	Axis	P1447-le Firmware	All	All	All	All
Hardware	Axis	P1448-le	-	All	All	All
Hardware	Axis	P1448-le	-	All	All	All
Operating System	Axis	P1448-le Firmware	All	All	All	All
Operating System	Axis	P1448-le Firmware	All	All	All	All
Hardware	Axis	P3114-i	-	All	All	All
Hardware	Axis	P3114-i	-	All	All	All
Operating System	Axis	P3114-i Firmware	All	All	All	All
Operating System	Axis	P3114-i Firmware	All	All	All	All
Hardware	Axis	P3114-z	-	All	All	All
Hardware	Axis	P3114-z	-	All	All	All
Operating System	Axis	P3114-z Firmware	All	All	All	All
Operating System	Axis	P3114-z Firmware	All	All	All	All
Hardware	Axis	P3115-i	-	All	All	All
Hardware	Axis	P3115-i	-	All	All	All
Operating System	Axis	P3115-i Firmware	All	All	All	All
Operating System	Axis	P3115-i Firmware	All	All	All	All
Hardware	Axis	P3115-z	-	All	All	All
Hardware	Axis	P3115-z	-	All	All	All
Operating System	Axis	P3115-z Firmware	All	All	All	All
Operating System	Axis	P3115-z Firmware	All	All	All	All
Hardware	Axis	P3125-z	-	All	All	All
Hardware	Axis	P3125-z	-	All	All	All

Hardware	Axis	P3125-z	-	All	All	All
Operating System	Axis	P3125-z Firmware	All	All	All	All
Operating System	Axis	P3125-z Firmware	All	All	All	All
Hardware	Axis	P3214-v	-	All	All	All
Hardware	Axis	P3214-v	-	All	All	All
Hardware	Axis	P3214-ve	-	All	All	All
Hardware	Axis	P3214-ve	-	All	All	All
Operating System	Axis	P3214-ve Firmware	All	All	All	All
Operating System	Axis	P3214-ve Firmware	All	All	All	All
Operating System	Axis	P3214-v Firmware	All	All	All	All
Operating System	Axis	P3214-v Firmware	All	All	All	All
Hardware	Axis	P3215-v	-	All	All	All
Hardware	Axis	P3215-v	-	All	All	All
Hardware	Axis	P3215-ve	-	All	All	All
Hardware	Axis	P3215-ve	-	All	All	All
Operating System	Axis	P3215-ve Firmware	All	All	All	All
Operating System	Axis	P3215-ve Firmware	All	All	All	All
Operating System	Axis	P3215-v Firmware	All	All	All	All
Operating System	Axis	P3215-v Firmware	All	All	All	All
Hardware	Axis	P3224-lv	-	All	All	All
Hardware	Axis	P3224-lv	-	All	All	All
Hardware	Axis	P3224-lve	-	All	All	All
Hardware	Axis	P3224-lve	-	All	All	All
Operating System	Axis	P3224-lve Firmware	All	All	All	All
Operating System	Axis	P3224-lve Firmware	All	All	All	All
Hardware	Axis	P3224-lve Mk li	-	All	All	All
Hardware	Axis	P3224-lve Mk li	-	All	All	All
Operating System	Axis	P3224-lve Mk li Firmware	All	All	All	All
Operating System	Axis	P3224-lve Mk li Firmware	All	All	All	All
Operating System	Axis	P3224-lv Firmware	All	All	All	All
Operating System	Axis	P3224-lv Firmware	All	All	All	All
Hardware	Axis	P3224-lv Mk li	-	All	All	All
Hardware	Axis	P3224-lv Mk li	-	All	All	All
Operating System	Axis	P3224-lv Mk li Firmware	All	All	All	All
Operating System	Axis	P3224-lv Mk li Firmware	All	All	All	All
Hardware	Axis	P3224-ve Mk li	-	All	All	All

Hardware	Axis	P3224-ve Mk li	-	All	All	All
Operating System	Axis	P3224-ve Mk li Firmware	All	All	All	All
Operating System	Axis	P3224-ve Mk li Firmware	All	All	All	All
Hardware	Axis	P3224-v Mk li	-	All	All	All
Hardware	Axis	P3224-v Mk li	-	All	All	All
Operating System	Axis	P3224-v Mk li Firmware	All	All	All	All
Operating System	Axis	P3224-v Mk li Firmware	All	All	All	All
Hardware	Axis	P3225-lv	-	All	All	All
Hardware	Axis	P3225-lv	-	All	All	All
Hardware	Axis	P3225-lve	-	All	All	All
Hardware	Axis	P3225-lve	-	All	All	All
Operating System	Axis	P3225-lve Firmware	All	All	All	All
Operating System	Axis	P3225-lve Firmware	All	All	All	All
Hardware	Axis	P3225-lve Mk li	-	All	All	All
Hardware	Axis	P3225-lve Mk li	-	All	All	All
Operating System	Axis	P3225-lve Mk li Firmware	All	All	All	All
Operating System	Axis	P3225-lve Mk li Firmware	All	All	All	All
Operating System	Axis	P3225-lv Firmware	All	All	All	All
Operating System	Axis	P3225-lv Firmware	All	All	All	All
Hardware	Axis	P3225-lv Mk li	-	All	All	All
Hardware	Axis	P3225-lv Mk li	-	All	All	All
Operating System	Axis	P3225-lv Mk li Firmware	All	All	All	All
Operating System	Axis	P3225-lv Mk li Firmware	All	All	All	All
Hardware	Axis	P3225-ve Mk li	-	All	All	All
Hardware	Axis	P3225-ve Mk li	-	All	All	All
Operating System	Axis	P3225-ve Mk li Firmware	All	All	All	All
Operating System	Axis	P3225-ve Mk li Firmware	All	All	All	All
Hardware	Axis	P3225-v Mk li	-	All	All	All
Hardware	Axis	P3225-v Mk li	-	All	All	All
Operating System	Axis	P3225-v Mk li Firmware	All	All	All	All
Operating System	Axis	P3225-v Mk li Firmware	All	All	All	All
Hardware	Axis	P3227-lv	-	All	All	All
Hardware	Axis	P3227-lv	-	All	All	All
Hardware	Axis	P3227-lve	-	All	All	All
Hardware	Axis	P3227-lve	-	All	All	All

Operating System	Axis	P3227-lve Firmware	All	All	All	All
Operating System	Axis	P3227-lve Firmware	All	All	All	All
Operating System	Axis	P3227-lv Firmware	All	All	All	All
Operating System	Axis	P3227-lv Firmware	All	All	All	All
Hardware	Axis	P3228-lv	-	All	All	All
Hardware	Axis	P3228-lv	-	All	All	All
Hardware	Axis	P3228-lve	-	All	All	All
Hardware	Axis	P3228-lve	-	All	All	All
Operating System	Axis	P3228-lve Firmware	All	All	All	All
Operating System	Axis	P3228-lve Firmware	All	All	All	All
Operating System	Axis	P3228-lv Firmware	All	All	All	All
Operating System	Axis	P3228-lv Firmware	All	All	All	All
Hardware	Axis	P3301	-	All	All	All
Hardware	Axis	P3301	-	All	All	All
Hardware	Axis	P3301-v	-	All	All	All
Hardware	Axis	P3301-v	-	All	All	All
Operating System	Axis	P3301-v Firmware	All	All	All	All
Operating System	Axis	P3301-v Firmware	All	All	All	All
Operating System	Axis	P3301 Firmware	All	All	All	All
Operating System	Axis	P3301 Firmware	All	All	All	All
Hardware	Axis	P3304	-	All	All	All
Hardware	Axis	P3304	-	All	All	All
Hardware	Axis	P3304-v	-	All	All	All
Hardware	Axis	P3304-v	-	All	All	All
Operating System	Axis	P3304-v Firmware	All	All	All	All
Operating System	Axis	P3304-v Firmware	All	All	All	All
Operating System	Axis	P3304 Firmware	All	All	All	All
Operating System	Axis	P3304 Firmware	All	All	All	All
Hardware	Axis	P3314-z	-	All	All	All
Hardware	Axis	P3314-z	-	All	All	All
Hardware	Axis	P3314-zl	-	All	All	All
Hardware	Axis	P3314-zl	-	All	All	All
Operating System	Axis	P3314-zl Firmware	All	All	All	All
Operating System	Axis	P3314-zl Firmware	All	All	All	All
Operating System	Axis	P3314-z Firmware	All	All	All	All
Operating System	Axis	P3314-z Firmware	All	All	All	All

Operating System	Axis	P3314-z Firmware	All	All	All	All
Hardware	Axis	P3315-z	-	All	All	All
Hardware	Axis	P3315-z	-	All	All	All
Hardware	Axis	P3315-zl	-	All	All	All
Hardware	Axis	P3315-zl	-	All	All	All
Operating System	Axis	P3315-zl Firmware	All	All	All	All
Operating System	Axis	P3315-zl Firmware	All	All	All	All
Operating System	Axis	P3315-z Firmware	All	All	All	All
Operating System	Axis	P3315-z Firmware	All	All	All	All
Hardware	Axis	P3343	-	All	All	All
Hardware	Axis	P3343	-	All	All	All
Hardware	Axis	P3343-v	-	All	All	All
Hardware	Axis	P3343-v	-	All	All	All
Hardware	Axis	P3343-ve	-	All	All	All
Hardware	Axis	P3343-ve	-	All	All	All
Operating System	Axis	P3343-ve Firmware	All	All	All	All
Operating System	Axis	P3343-ve Firmware	All	All	All	All
Operating System	Axis	P3343-v Firmware	All	All	All	All
Operating System	Axis	P3343-v Firmware	All	All	All	All
Operating System	Axis	P3343 Firmware	All	All	All	All
Operating System	Axis	P3343 Firmware	All	All	All	All
Hardware	Axis	P3344	-	All	All	All
Hardware	Axis	P3344	-	All	All	All
Hardware	Axis	P3344-v	-	All	All	All
Hardware	Axis	P3344-v	-	All	All	All
Hardware	Axis	P3344-ve	-	All	All	All
Hardware	Axis	P3344-ve	-	All	All	All
Operating System	Axis	P3344-ve Firmware	All	All	All	All
Operating System	Axis	P3344-ve Firmware	All	All	All	All
Operating System	Axis	P3344-v Firmware	All	All	All	All
Operating System	Axis	P3344-v Firmware	All	All	All	All
Operating System	Axis	P3344 Firmware	All	All	All	All
Operating System	Axis	P3344 Firmware	All	All	All	All
Hardware	Axis	P3346	-	All	All	All
Hardware	Axis	P3346	-	All	All	All
Hardware	Axis	P3346-v	-	All	All	All

Hardware	Axis	P3346-v	-	All	All	All
Hardware	Axis	P3346-ve	-	All	All	All
Hardware	Axis	P3346-ve	-	All	All	All
Operating System	Axis	P3346-ve Firmware	All	All	All	All
Operating System	Axis	P3346-ve Firmware	All	All	All	All
Operating System	Axis	P3346-v Firmware	All	All	All	All
Operating System	Axis	P3346-v Firmware	All	All	All	All
Operating System	Axis	P3346 Firmware	All	All	All	All
Operating System	Axis	P3346 Firmware	All	All	All	All
Hardware	Axis	P3353	-	All	All	All
Hardware	Axis	P3353	-	All	All	All
Operating System	Axis	P3353 Firmware	All	All	All	All
Operating System	Axis	P3353 Firmware	All	All	All	All
Hardware	Axis	P3354	-	All	All	All
Hardware	Axis	P3354	-	All	All	All
Operating System	Axis	P3354 Firmware	All	All	All	All
Operating System	Axis	P3354 Firmware	All	All	All	All
Hardware	Axis	P3363-v	-	All	All	All
Hardware	Axis	P3363-v	-	All	All	All
Hardware	Axis	P3363-ve	-	All	All	All
Hardware	Axis	P3363-ve	-	All	All	All
Operating System	Axis	P3363-ve Firmware	All	All	All	All
Operating System	Axis	P3363-ve Firmware	All	All	All	All
Operating System	Axis	P3363-v Firmware	All	All	All	All
Operating System	Axis	P3363-v Firmware	All	All	All	All
Hardware	Axis	P3364-lv	-	All	All	All
Hardware	Axis	P3364-lv	-	All	All	All
Hardware	Axis	P3364-lve	-	All	All	All
Hardware	Axis	P3364-lve	-	All	All	All
Operating System	Axis	P3364-lve Firmware	All	All	All	All
Operating System	Axis	P3364-lve Firmware	All	All	All	All
Operating System	Axis	P3364-lv Firmware	All	All	All	All
Operating System	Axis	P3364-lv Firmware	All	All	All	All
Hardware	Axis	P3364-v	-	All	All	All
Hardware	Axis	P3364-v	-	All	All	All

Hardware	Axis	P3364-ve	-	All	All	All
Hardware	Axis	P3364-ve	-	All	All	All
Operating System	Axis	P3364-ve Firmware	All	All	All	All
Operating System	Axis	P3364-ve Firmware	All	All	All	All
Operating System	Axis	P3364-v Firmware	All	All	All	All
Operating System	Axis	P3364-v Firmware	All	All	All	All
Hardware	Axis	P3365-v	-	All	All	All
Hardware	Axis	P3365-v	-	All	All	All
Hardware	Axis	P3365-ve	-	All	All	All
Hardware	Axis	P3365-ve	-	All	All	All
Operating System	Axis	P3365-ve Firmware	All	All	All	All
Operating System	Axis	P3365-ve Firmware	All	All	All	All
Operating System	Axis	P3365-v Firmware	All	All	All	All
Operating System	Axis	P3365-v Firmware	All	All	All	All
Hardware	Axis	P3367-v	-	All	All	All
Hardware	Axis	P3367-v	-	All	All	All
Hardware	Axis	P3367-ve	-	All	All	All
Hardware	Axis	P3367-ve	-	All	All	All
Operating System	Axis	P3367-ve Firmware	All	All	All	All
Operating System	Axis	P3367-ve Firmware	All	All	All	All
Operating System	Axis	P3367-v Firmware	All	All	All	All
Operating System	Axis	P3367-v Firmware	All	All	All	All
Hardware	Axis	P3374-lv	-	All	All	All
Hardware	Axis	P3374-lv	-	All	All	All
Operating System	Axis	P3374-lv Firmware	All	All	All	All
Operating System	Axis	P3374-lv Firmware	All	All	All	All
Hardware	Axis	P3374-v	-	All	All	All
Hardware	Axis	P3374-v	-	All	All	All
Operating System	Axis	P3374-v Firmware	All	All	All	All
Operating System	Axis	P3374-v Firmware	All	All	All	All
Hardware	Axis	P3375-lv	-	All	All	All
Hardware	Axis	P3375-lv	-	All	All	All
Hardware	Axis	P3375-lve	-	All	All	All
Hardware	Axis	P3375-lve	-	All	All	All
Operating System	Axis	P3375-lve Firmware	All	All	All	All
Operating System	Axis	P3375-lve Firmware	All	All	All	All

Operating System	Axis	P3375-lv Firmware	All	All	All	All
Operating System	Axis	P3375-lv Firmware	All	All	All	All
Operating System	Axis	P3375-lv Firmware	All	All	All	All
Hardware	Axis	P3375-v	-	All	All	All
Hardware	Axis	P3375-v	-	All	All	All
Hardware	Axis	P3375-ve	-	All	All	All
Hardware	Axis	P3375-ve	-	All	All	All
Operating System	Axis	P3375-ve Firmware	All	All	All	All
Operating System	Axis	P3375-ve Firmware	All	All	All	All
Operating System	Axis	P3375-v Firmware	All	All	All	All
Operating System	Axis	P3375-v Firmware	All	All	All	All
Hardware	Axis	P3384-v	-	All	All	All
Hardware	Axis	P3384-v	-	All	All	All
Hardware	Axis	P3384-ve	-	All	All	All
Hardware	Axis	P3384-ve	-	All	All	All
Operating System	Axis	P3384-ve Firmware	All	All	All	All
Operating System	Axis	P3384-ve Firmware	All	All	All	All
Operating System	Axis	P3384-v Firmware	All	All	All	All
Operating System	Axis	P3384-v Firmware	All	All	All	All
Hardware	Axis	P3705-z	-	All	All	All
Hardware	Axis	P3705-z	-	All	All	All
Operating System	Axis	P3705-z Firmware	All	All	All	All
Operating System	Axis	P3705-z Firmware	All	All	All	All
Hardware	Axis	P3706-z	-	All	All	All
Hardware	Axis	P3706-z	-	All	All	All
Operating System	Axis	P3706-z Firmware	All	All	All	All
Operating System	Axis	P3706-z Firmware	All	All	All	All
Hardware	Axis	P3707-pe	-	All	All	All
Hardware	Axis	P3707-pe	-	All	All	All
Operating System	Axis	P3707-pe Firmware	All	All	All	All
Operating System	Axis	P3707-pe Firmware	All	All	All	All
Hardware	Axis	P3904-r	-	All	All	All
Hardware	Axis	P3904-r	-	All	All	All
Operating System	Axis	P3904-r Firmware	All	All	All	All
Operating System	Axis	P3904-r Firmware	All	All	All	All
Hardware	Axis	P3904-r Mk li	-	All	All	All

Hardware	Axis	P3904-r Mk li	-	All	All	All
Operating System	Axis	P3904-r Mk li Firmware	All	All	All	All
Operating System	Axis	P3904-r Mk li Firmware	All	All	All	All
Hardware	Axis	P3905-r	-	All	All	All
Hardware	Axis	P3905-r	-	All	All	All
Hardware	Axis	P3905-re	-	All	All	All
Hardware	Axis	P3905-re	-	All	All	All
Operating System	Axis	P3905-re Firmware	All	All	All	All
Operating System	Axis	P3905-re Firmware	All	All	All	All
Operating System	Axis	P3905-r Firmware	All	All	All	All
Operating System	Axis	P3905-r Firmware	All	All	All	All
Hardware	Axis	P3905-r Mk li	-	All	All	All
Hardware	Axis	P3905-r Mk li	-	All	All	All
Operating System	Axis	P3905-r Mk li Firmware	All	All	All	All
Operating System	Axis	P3905-r Mk li Firmware	All	All	All	All
Hardware	Axis	P3915-r	-	All	All	All
Hardware	Axis	P3915-r	-	All	All	All
Operating System	Axis	P3915-r Firmware	All	All	All	All
Operating System	Axis	P3915-r Firmware	All	All	All	All
Hardware	Axis	P3915-r Mk li	-	All	All	All
Hardware	Axis	P3915-r Mk li	-	All	All	All
Operating System	Axis	P3915-r Mk li Firmware	All	All	All	All
Operating System	Axis	P3915-r Mk li Firmware	All	All	All	All
Hardware	Axis	P5414-e	-	All	All	All
Hardware	Axis	P5414-e	-	All	All	All
Operating System	Axis	P5414-e Firmware	All	All	All	All
Operating System	Axis	P5414-e Firmware	All	All	All	All
Hardware	Axis	P5415-e	-	All	All	All
Hardware	Axis	P5415-e	-	All	All	All
Operating System	Axis	P5415-e Firmware	All	All	All	All
Operating System	Axis	P5415-e Firmware	All	All	All	All
Hardware	Axis	P5512	-	All	All	All
Hardware	Axis	P5512	-	All	All	All
Hardware	Axis	P5512-e	-	All	All	All
Hardware	Axis	P5512-e	-	All	All	All

Operating System	Axis	P5512-e Firmware	All	All	All	All
Operating System	Axis	P5512-e Firmware	All	All	All	All
Operating System	Axis	P5512 Firmware	All	All	All	All
Operating System	Axis	P5512 Firmware	All	All	All	All
Hardware	Axis	P5514	-	All	All	All
Hardware	Axis	P5514	-	All	All	All
Hardware	Axis	P5514-e	-	All	All	All
Hardware	Axis	P5514-e	-	All	All	All
Operating System	Axis	P5514-e Firmware	All	All	All	All
Operating System	Axis	P5514-e Firmware	All	All	All	All
Operating System	Axis	P5514 Firmware	All	All	All	All
Operating System	Axis	P5514 Firmware	All	All	All	All
Hardware	Axis	P5515	-	All	All	All
Hardware	Axis	P5515	-	All	All	All
Hardware	Axis	P5515-e	-	All	All	All
Hardware	Axis	P5515-e	-	All	All	All
Operating System	Axis	P5515-e Firmware	All	All	All	All
Operating System	Axis	P5515-e Firmware	All	All	All	All
Operating System	Axis	P5515 Firmware	All	All	All	All
Operating System	Axis	P5515 Firmware	All	All	All	All
Hardware	Axis	P5522	-	All	All	All
Hardware	Axis	P5522	-	All	All	All
Hardware	Axis	P5522-e	-	All	All	All
Hardware	Axis	P5522-e	-	All	All	All
Operating System	Axis	P5522-e Firmware	All	All	All	All
Operating System	Axis	P5522-e Firmware	All	All	All	All
Operating System	Axis	P5522 Firmware	All	All	All	All
Operating System	Axis	P5522 Firmware	All	All	All	All
Hardware	Axis	P5532	-	All	All	All
Hardware	Axis	P5532	-	All	All	All
Hardware	Axis	P5532-e	-	All	All	All
Hardware	Axis	P5532-e	-	All	All	All
Operating System	Axis	P5532-e Firmware	All	All	All	All
Operating System	Axis	P5532-e Firmware	All	All	All	All
Operating System	Axis	P5532 Firmware	All	All	All	All
Operatina Svstem	Axis	P5532 Firmware	All	All	All	All

Operating System	Axis	Firmware
Hardware	Axis	P5534	-	All	All	All
Hardware	Axis	P5534	-	All	All	All
Hardware	Axis	P5534-e	-	All	All	All
Hardware	Axis	P5534-e	-	All	All	All
Operating System	Axis	P5534-e Firmware	All	All	All	All
Operating System	Axis	P5534-e Firmware	All	All	All	All
Operating System	Axis	P5534 Firmware	All	All	All	All
Operating System	Axis	P5534 Firmware	All	All	All	All
Hardware	Axis	P5544	-	All	All	All
Hardware	Axis	P5544	-	All	All	All
Operating System	Axis	P5544 Firmware	All	All	All	All
Operating System	Axis	P5544 Firmware	All	All	All	All
Hardware	Axis	P5624-e	-	All	All	All
Hardware	Axis	P5624-e	-	All	All	All
Operating System	Axis	P5624-e Firmware	All	All	All	All
Operating System	Axis	P5624-e Firmware	All	All	All	All
Hardware	Axis	P5624-e Mk li	-	All	All	All
Hardware	Axis	P5624-e Mk li	-	All	All	All
Operating System	Axis	P5624-e Mk li Firmware	All	All	All	All
Operating System	Axis	P5624-e Mk li Firmware	All	All	All	All
Hardware	Axis	P5635-e	-	All	All	All
Hardware	Axis	P5635-e	-	All	All	All
Operating System	Axis	P5635-e Firmware	All	All	All	All
Operating System	Axis	P5635-e Firmware	All	All	All	All
Hardware	Axis	P5635-e Mk li	-	All	All	All
Hardware	Axis	P5635-e Mk li	-	All	All	All
Operating System	Axis	P5635-e Mk li Firmware	All	All	All	All
Operating System	Axis	P5635-e Mk li Firmware	All	All	All	All
Hardware	Axis	P5635-ze	-	All	All	All
Hardware	Axis	P5635-ze	-	All	All	All
Operating System	Axis	P5635-ze Firmware	All	All	All	All
Operating System	Axis	P5635-ze Firmware	All	All	All	All
Hardware	Axis	P7210	-	All	All	All
Hardware	Axis	P7210	-	All	All	All
Operating System	Axis	P7210 Firmware	All	All	All	All

Operating System	Axis	P7210 Firmware	All	All	All	All
Hardware	Axis	P7214	-	All	All	All
Hardware	Axis	P7214	-	All	All	All
Operating System	Axis	P7214 Firmware	All	All	All	All
Operating System	Axis	P7214 Firmware	All	All	All	All
Hardware	Axis	P7216	-	All	All	All
Hardware	Axis	P7216	-	All	All	All
Operating System	Axis	P7216 Firmware	All	All	All	All
Operating System	Axis	P7216 Firmware	All	All	All	All
Hardware	Axis	P7224 Blade	-	All	All	All
Hardware	Axis	P7224 Blade	-	All	All	All
Operating System	Axis	P7224 Blade Firmware	All	All	All	All
Operating System	Axis	P7224 Blade Firmware	All	All	All	All
Hardware	Axis	P8513	-	All	All	All
Hardware	Axis	P8513	-	All	All	All
Operating System	Axis	P8513 Firmware	All	All	All	All
Operating System	Axis	P8513 Firmware	All	All	All	All
Hardware	Axis	P8514	-	All	All	All
Hardware	Axis	P8514	-	All	All	All
Operating System	Axis	P8514 Firmware	All	All	All	All
Operating System	Axis	P8514 Firmware	All	All	All	All
Hardware	Axis	P8524	-	All	All	All
Hardware	Axis	P8524	-	All	All	All
Operating System	Axis	P8524 Firmware	All	All	All	All
Operating System	Axis	P8524 Firmware	All	All	All	All
Hardware	Axis	Q1602	-	All	All	All
Hardware	Axis	Q1602	-	All	All	All
Hardware	Axis	Q1602-e	-	All	All	All
Hardware	Axis	Q1602-e	-	All	All	All
Operating System	Axis	Q1602-e Firmware	All	All	All	All
Operating System	Axis	Q1602-e Firmware	All	All	All	All
Operating System	Axis	Q1602 Firmware	All	All	All	All
Operating System	Axis	Q1602 Firmware	All	All	All	All
Hardware	Axis	Q1604	-	All	All	All
Hardware	Axis	Q1604	-	All	All	All

Hardware	Axis	Q1604-e	-	All	All	All
Hardware	Axis	Q1604-e	-	All	All	All
Operating System	Axis	Q1604-e Firmware	All	All	All	All
Operating System	Axis	Q1604-e Firmware	All	All	All	All
Operating System	Axis	Q1604 Firmware	All	All	All	All
Operating System	Axis	Q1604 Firmware	All	All	All	All
Hardware	Axis	Q1605-z	-	All	All	All
Hardware	Axis	Q1605-z	-	All	All	All
Operating System	Axis	Q1605-z Firmware	All	All	All	All
Operating System	Axis	Q1605-z Firmware	All	All	All	All
Hardware	Axis	Q1614	-	All	All	All
Hardware	Axis	Q1614	-	All	All	All
Hardware	Axis	Q1614-e	-	All	All	All
Hardware	Axis	Q1614-e	-	All	All	All
Operating System	Axis	Q1614-e Firmware	All	All	All	All
Operating System	Axis	Q1614-e Firmware	All	All	All	All
Operating System	Axis	Q1614 Firmware	All	All	All	All
Operating System	Axis	Q1614 Firmware	All	All	All	All
Hardware	Axis	Q1615	-	All	All	All
Hardware	Axis	Q1615	-	All	All	All
Hardware	Axis	Q1615-e	-	All	All	All
Hardware	Axis	Q1615-e	-	All	All	All
Operating System	Axis	Q1615-e Firmware	All	All	All	All
Operating System	Axis	Q1615-e Firmware	All	All	All	All
Hardware	Axis	Q1615-e Mk li	-	All	All	All
Hardware	Axis	Q1615-e Mk li	-	All	All	All
Operating System	Axis	Q1615-e Mk li Firmware	All	All	All	All
Operating System	Axis	Q1615-e Mk li Firmware	All	All	All	All
Operating System	Axis	Q1615 Firmware	All	All	All	All
Operating System	Axis	Q1615 Firmware	All	All	All	All
Hardware	Axis	Q1615 Mk li	-	All	All	All
Hardware	Axis	Q1615 Mk li	-	All	All	All
Operating System	Axis	Q1615 Mk li Firmware	All	All	All	All
Operating System	Axis	Q1615 Mk li Firmware	All	All	All	All
Hardware	Axis	Q1635	-	All	All	All
Hardware	Axis	Q1635	-	All	All	All

Hardware	Axis	Q1635-e	-	All	All	All
Hardware	Axis	Q1635-e	-	All	All	All
Operating System	Axis	Q1635-e Firmware	All	All	All	All
Operating System	Axis	Q1635-e Firmware	All	All	All	All
Hardware	Axis	Q1635-z	-	All	All	All
Hardware	Axis	Q1635-z	-	All	All	All
Operating System	Axis	Q1635-z Firmware	All	All	All	All
Operating System	Axis	Q1635-z Firmware	All	All	All	All
Operating System	Axis	Q1635 Firmware	All	All	All	All
Operating System	Axis	Q1635 Firmware	All	All	All	All
Hardware	Axis	Q1645	-	All	All	All
Hardware	Axis	Q1645	-	All	All	All
Operating System	Axis	Q1645 Firmware	All	All	All	All
Operating System	Axis	Q1645 Firmware	All	All	All	All
Hardware	Axis	Q1647	-	All	All	All
Hardware	Axis	Q1647	-	All	All	All
Operating System	Axis	Q1647 Firmware	All	All	All	All
Operating System	Axis	Q1647 Firmware	All	All	All	All
Hardware	Axis	Q1659	-	All	All	All
Hardware	Axis	Q1659	-	All	All	All
Operating System	Axis	Q1659 Firmware	All	All	All	All
Operating System	Axis	Q1659 Firmware	All	All	All	All
Hardware	Axis	Q1755	-	All	All	All
Hardware	Axis	Q1755	-	All	All	All
Hardware	Axis	Q1755-e	-	All	All	All
Hardware	Axis	Q1755-e	-	All	All	All
Operating System	Axis	Q1755-e Firmware	All	All	All	All
Operating System	Axis	Q1755-e Firmware	All	All	All	All
Operating System	Axis	Q1755 Firmware	All	All	All	All
Operating System	Axis	Q1755 Firmware	All	All	All	All
Hardware	Axis	Q1765-le	-	All	All	All
Hardware	Axis	Q1765-le	-	All	All	All
Operating System	Axis	Q1765-le Firmware	All	All	All	All
Operating System	Axis	Q1765-le Firmware	All	All	All	All
Hardware	Axis	Q1765-le Pt Mount	-	All	All	All

Hardware	Axis	Q1765-le Pt Mount	-	All	All	All
Operating System	Axis	Q1765-le Pt Mount Firmware	All	All	All	All
Operating System	Axis	Q1765-le Pt Mount Firmware	All	All	All	All
Hardware	Axis	Q1775	-	All	All	All
Hardware	Axis	Q1775	-	All	All	All
Hardware	Axis	Q1775-e	-	All	All	All
Hardware	Axis	Q1775-e	-	All	All	All
Operating System	Axis	Q1775-e Firmware	All	All	All	All
Operating System	Axis	Q1775-e Firmware	All	All	All	All
Operating System	Axis	Q1775 Firmware	All	All	All	All
Operating System	Axis	Q1775 Firmware	All	All	All	All
Hardware	Axis	Q1910	-	All	All	All
Hardware	Axis	Q1910	-	All	All	All
Hardware	Axis	Q1910-e	-	All	All	All
Hardware	Axis	Q1910-e	-	All	All	All
Operating System	Axis	Q1910-e Firmware	5.51.5	All	All	All
Operating System	Axis	Q1910-e Firmware	5.51.5	All	All	All
Operating System	Axis	Q1910 Firmware	All	All	All	All
Operating System	Axis	Q1910 Firmware	All	All	All	All
Hardware	Axis	Q1921	-	All	All	All
Hardware	Axis	Q1921	-	All	All	All
Hardware	Axis	Q1921-e	-	All	All	All
Hardware	Axis	Q1921-e	-	All	All	All
Operating System	Axis	Q1921-e Firmware	All	All	All	All
Operating System	Axis	Q1921-e Firmware	All	All	All	All
Operating System	Axis	Q1921 Firmware	All	All	All	All
Operating System	Axis	Q1921 Firmware	All	All	All	All
Hardware	Axis	Q1922	-	All	All	All
Hardware	Axis	Q1922	-	All	All	All
Hardware	Axis	Q1922-e	-	All	All	All
Hardware	Axis	Q1922-e	-	All	All	All
Operating System	Axis	Q1922-e Firmware	All	All	All	All
Operating System	Axis	Q1922-e Firmware	All	All	All	All
Operating System	Axis	Q1922 Firmware	All	All	All	All
Operating System	Axis	Q1922 Firmware	All	All	All	All

Hardware	Axis	Q1931-e	-	All	All	All
Hardware	Axis	Q1931-e	-	All	All	All
Operating System	Axis	Q1931-e Firmware	All	All	All	All
Operating System	Axis	Q1931-e Firmware	All	All	All	All
Hardware	Axis	Q1931-e Pt Mount	-	All	All	All
Hardware	Axis	Q1931-e Pt Mount	-	All	All	All
Operating System	Axis	Q1931-e Pt Mount Firmware	All	All	All	All
Operating System	Axis	Q1931-e Pt Mount Firmware	All	All	All	All
Hardware	Axis	Q1932-e	-	All	All	All
Hardware	Axis	Q1932-e	-	All	All	All
Operating System	Axis	Q1932-e Firmware	All	All	All	All
Operating System	Axis	Q1932-e Firmware	All	All	All	All
Hardware	Axis	Q1932-e Pt Mount	-	All	All	All
Hardware	Axis	Q1932-e Pt Mount	-	All	All	All
Operating System	Axis	Q1932-e Pt Mount Firmware	All	All	All	All
Operating System	Axis	Q1932-e Pt Mount Firmware	All	All	All	All
Hardware	Axis	Q1941-e	-	All	All	All
Hardware	Axis	Q1941-e	-	All	All	All
Operating System	Axis	Q1941-e Firmware	All	All	All	All
Operating System	Axis	Q1941-e Firmware	All	All	All	All
Hardware	Axis	Q1941-e Pt Mount	-	All	All	All
Hardware	Axis	Q1941-e Pt Mount	-	All	All	All
Operating System	Axis	Q1941-e Pt Mount Firmware	All	All	All	All
Operating System	Axis	Q1941-e Pt Mount Firmware	All	All	All	All
Hardware	Axis	Q1942-e	-	All	All	All
Hardware	Axis	Q1942-e	-	All	All	All
Operating System	Axis	Q1942-e Firmware	All	All	All	All
Operating System	Axis	Q1942-e Firmware	All	All	All	All
Hardware	Axis	Q1942-e Pt Mount	-	All	All	All
Hardware	Axis	Q1942-e Pt Mount	-	All	All	All
Operating System	Axis	Q1942-e Pt Mount Firmware	All	All	All	All
Operating System	Axis	Q1942-e Pt Mount Firmware	All	All	All	All
Hardware	Axis	Q2901-e	-	All	All	All
Hardware	Axis	Q2901-e	-	All	All	All
Operating System	Axis	Q2901-e Firmware	All	All	All	All
Operating System	Axis	Q2901-e Firmware	All	All	All	All

Hardware	Axis	Q2901-e Pt Mount	-	All	All	All
Hardware	Axis	Q2901-e Pt Mount	-	All	All	All
Operating System	Axis	Q2901-e Pt Mount Firmware	All	All	All	All
Operating System	Axis	Q2901-e Pt Mount Firmware	All	All	All	All
Hardware	Axis	Q3504-v	-	All	All	All
Hardware	Axis	Q3504-v	-	All	All	All
Hardware	Axis	Q3504-ve	-	All	All	All
Hardware	Axis	Q3504-ve	-	All	All	All
Operating System	Axis	Q3504-ve Firmware	All	All	All	All
Operating System	Axis	Q3504-ve Firmware	All	All	All	All
Operating System	Axis	Q3504-v Firmware	All	All	All	All
Operating System	Axis	Q3504-v Firmware	All	All	All	All
Hardware	Axis	Q3505-sve Mk li	-	All	All	All
Hardware	Axis	Q3505-sve Mk li	-	All	All	All
Operating System	Axis	Q3505-sve Mk li Firmware	All	All	All	All
Operating System	Axis	Q3505-sve Mk li Firmware	All	All	All	All
Hardware	Axis	Q3505-v	-	All	All	All
Hardware	Axis	Q3505-v	-	All	All	All
Hardware	Axis	Q3505-ve	-	All	All	All
Hardware	Axis	Q3505-ve	-	All	All	All
Operating System	Axis	Q3505-ve Firmware	All	All	All	All
Operating System	Axis	Q3505-ve Firmware	All	All	All	All
Hardware	Axis	Q3505-ve Mk li	-	All	All	All
Hardware	Axis	Q3505-ve Mk li	-	All	All	All
Operating System	Axis	Q3505-ve Mk li Firmware	All	All	All	All
Operating System	Axis	Q3505-ve Mk li Firmware	All	All	All	All
Operating System	Axis	Q3505-v Firmware	All	All	All	All
Operating System	Axis	Q3505-v Firmware	All	All	All	All
Hardware	Axis	Q3505-v Mk li	-	All	All	All
Hardware	Axis	Q3505-v Mk li	-	All	All	All
Operating System	Axis	Q3505-v Mk li Firmware	All	All	All	All
Operating System	Axis	Q3505-v Mk li Firmware	All	All	All	All
Hardware	Axis	Q3515-lv	-	All	All	All
Hardware	Axis	Q3515-lv	-	All	All	All
Hardware	Axis	Q3515-lve	-	All	All	All

Hardware	Axis	Q3515-lve	-	All	All	All
Operating System	Axis	Q3515-lve Firmware	All	All	All	All
Operating System	Axis	Q3515-lve Firmware	All	All	All	All
Operating System	Axis	Q3515-lv Firmware	All	All	All	All
Operating System	Axis	Q3515-lv Firmware	All	All	All	All
Hardware	Axis	Q3517-lv	-	All	All	All
Hardware	Axis	Q3517-lv	-	All	All	All
Hardware	Axis	Q3517-lve	-	All	All	All
Hardware	Axis	Q3517-lve	-	All	All	All
Operating System	Axis	Q3517-lve Firmware	All	All	All	All
Operating System	Axis	Q3517-lve Firmware	All	All	All	All
Operating System	Axis	Q3517-lv Firmware	All	All	All	All
Operating System	Axis	Q3517-lv Firmware	All	All	All	All
Hardware	Axis	Q3615-ve	-	All	All	All
Hardware	Axis	Q3615-ve	-	All	All	All
Operating System	Axis	Q3615-ve Firmware	All	All	All	All
Operating System	Axis	Q3615-ve Firmware	All	All	All	All
Hardware	Axis	Q3617-ve	-	All	All	All
Hardware	Axis	Q3617-ve	-	All	All	All
Operating System	Axis	Q3617-ve Firmware	All	All	All	All
Operating System	Axis	Q3617-ve Firmware	All	All	All	All
Hardware	Axis	Q3708-pve	-	All	All	All
Hardware	Axis	Q3708-pve	-	All	All	All
Operating System	Axis	Q3708-pve Firmware	All	All	All	All
Operating System	Axis	Q3708-pve Firmware	All	All	All	All
Hardware	Axis	Q3709-pve	-	All	All	All
Hardware	Axis	Q3709-pve	-	All	All	All
Operating System	Axis	Q3709-pve Firmware	All	All	All	All
Operating System	Axis	Q3709-pve Firmware	All	All	All	All
Hardware	Axis	Q6000-e	-	All	All	All
Hardware	Axis	Q6000-e	-	All	All	All
Operating System	Axis	Q6000-e Firmware	All	All	All	All
Operating System	Axis	Q6000-e Firmware	All	All	All	All
Hardware	Axis	Q6000-e Mk li	-	All	All	All
Hardware	Axis	Q6000-e Mk li	-	All	All	All
Operating System	Axis	Q6000-e Mk li Firmware	All	All	All	All

Operating System	Axis	Q6000-e Mk II Firmware	All	All	All	All
Operating System	Axis	Q6000-e Mk II Firmware	All	All	All	All
Hardware	Axis	Q6032	-	All	All	All
Hardware	Axis	Q6032	-	All	All	All
Hardware	Axis	Q6032-c	-	All	All	All
Hardware	Axis	Q6032-c	-	All	All	All
Operating System	Axis	Q6032-c Firmware	All	All	All	All
Operating System	Axis	Q6032-c Firmware	All	All	All	All
Hardware	Axis	Q6032-e	-	All	All	All
Hardware	Axis	Q6032-e	-	All	All	All
Operating System	Axis	Q6032-e Firmware	All	All	All	All
Operating System	Axis	Q6032-e Firmware	All	All	All	All
Operating System	Axis	Q6032 Firmware	All	All	All	All
Operating System	Axis	Q6032 Firmware	All	All	All	All
Hardware	Axis	Q6034	-	All	All	All
Hardware	Axis	Q6034	-	All	All	All
Hardware	Axis	Q6034-c	-	All	All	All
Hardware	Axis	Q6034-c	-	All	All	All
Operating System	Axis	Q6034-c Firmware	All	All	All	All
Operating System	Axis	Q6034-c Firmware	All	All	All	All
Hardware	Axis	Q6034-e	-	All	All	All
Hardware	Axis	Q6034-e	-	All	All	All
Operating System	Axis	Q6034-e Firmware	All	All	All	All
Operating System	Axis	Q6034-e Firmware	All	All	All	All
Operating System	Axis	Q6034 Firmware	All	All	All	All
Operating System	Axis	Q6034 Firmware	All	All	All	All
Hardware	Axis	Q6035	-	All	All	All
Hardware	Axis	Q6035	-	All	All	All
Hardware	Axis	Q6035-c	-	All	All	All
Hardware	Axis	Q6035-c	-	All	All	All
Operating System	Axis	Q6035-c Firmware	All	All	All	All
Operating System	Axis	Q6035-c Firmware	All	All	All	All
Hardware	Axis	Q6035-e	-	All	All	All
Hardware	Axis	Q6035-e	-	All	All	All
Operating System	Axis	Q6035-e Firmware	All	All	All	All
Operating System	Axis	Q6035-e Firmware	All	All	All	All

Operating System	Axis	Q6035 Firmware	All	All	All	All
Operating System	Axis	Q6035 Firmware	All	All	All	All
Hardware	Axis	Q6042	-	All	All	All
Hardware	Axis	Q6042	-	All	All	All
Hardware	Axis	Q6042-c	-	All	All	All
Hardware	Axis	Q6042-c	-	All	All	All
Operating System	Axis	Q6042-c Firmware	All	All	All	All
Operating System	Axis	Q6042-c Firmware	All	All	All	All
Hardware	Axis	Q6042-e	-	All	All	All
Hardware	Axis	Q6042-e	-	All	All	All
Operating System	Axis	Q6042-e Firmware	All	All	All	All
Operating System	Axis	Q6042-e Firmware	All	All	All	All
Hardware	Axis	Q6042-s	-	All	All	All
Hardware	Axis	Q6042-s	-	All	All	All
Operating System	Axis	Q6042-s Firmware	All	All	All	All
Operating System	Axis	Q6042-s Firmware	All	All	All	All
Operating System	Axis	Q6042 Firmware	All	All	All	All
Operating System	Axis	Q6042 Firmware	All	All	All	All
Hardware	Axis	Q6044	-	All	All	All
Hardware	Axis	Q6044	-	All	All	All
Hardware	Axis	Q6044-c	-	All	All	All
Hardware	Axis	Q6044-c	-	All	All	All
Operating System	Axis	Q6044-c Firmware	All	All	All	All
Operating System	Axis	Q6044-c Firmware	All	All	All	All
Hardware	Axis	Q6044-e	-	All	All	All
Hardware	Axis	Q6044-e	-	All	All	All
Operating System	Axis	Q6044-e Firmware	All	All	All	All
Operating System	Axis	Q6044-e Firmware	All	All	All	All
Hardware	Axis	Q6044-s	-	All	All	All
Hardware	Axis	Q6044-s	-	All	All	All
Operating System	Axis	Q6044-s Firmware	All	All	All	All
Operating System	Axis	Q6044-s Firmware	All	All	All	All
Operating System	Axis	Q6044 Firmware	All	All	All	All
Operating System	Axis	Q6044 Firmware	All	All	All	All
Hardware	Axis	Q6045	-	All	All	All

Hardware	Axis	Q6045	-	All	All	All
Hardware	Axis	Q6045-c	-	All	All	All
Hardware	Axis	Q6045-c	-	All	All	All
Operating System	Axis	Q6045-c Firmware	All	All	All	All
Operating System	Axis	Q6045-c Firmware	All	All	All	All
Hardware	Axis	Q6045-c Mk II	-	All	All	All
Hardware	Axis	Q6045-c Mk II	-	All	All	All
Operating System	Axis	Q6045-c Mk II Firmware	All	All	All	All
Operating System	Axis	Q6045-c Mk II Firmware	All	All	All	All
Hardware	Axis	Q6045-e	-	All	All	All
Hardware	Axis	Q6045-e	-	All	All	All
Operating System	Axis	Q6045-e Firmware	All	All	All	All
Operating System	Axis	Q6045-e Firmware	All	All	All	All
Hardware	Axis	Q6045-e Mk II	-	All	All	All
Hardware	Axis	Q6045-e Mk II	-	All	All	All
Operating System	Axis	Q6045-e Mk II Firmware	All	All	All	All
Operating System	Axis	Q6045-e Mk II Firmware	All	All	All	All
Hardware	Axis	Q6045-s	-	All	All	All
Hardware	Axis	Q6045-s	-	All	All	All
Operating System	Axis	Q6045-s Firmware	All	All	All	All
Operating System	Axis	Q6045-s Firmware	All	All	All	All
Hardware	Axis	Q6045-s Mk II	-	All	All	All
Hardware	Axis	Q6045-s Mk II	-	All	All	All
Operating System	Axis	Q6045-s Mk II Firmware	All	All	All	All
Operating System	Axis	Q6045-s Mk II Firmware	All	All	All	All
Operating System	Axis	Q6045 Firmware	All	All	All	All
Operating System	Axis	Q6045 Firmware	All	All	All	All
Hardware	Axis	Q6045 Mk II	-	All	All	All
Hardware	Axis	Q6045 Mk II	-	All	All	All
Operating System	Axis	Q6045 Mk II Firmware	All	All	All	All
Operating System	Axis	Q6045 Mk II Firmware	All	All	All	All
Hardware	Axis	Q6052	-	All	All	All
Hardware	Axis	Q6052	-	All	All	All
Hardware	Axis	Q6052-e	-	All	All	All
Hardware	Axis	Q6052-e	-	All	All	All
Operating System	Axis	Q6052-e Firmware	All	All	All	All

Operating System	Axis	Q6052-e Firmware	All	All	All	All
Operating System	Axis	Q6052-e Firmware	All	All	All	All
Operating System	Axis	Q6052 Firmware	All	All	All	All
Operating System	Axis	Q6052 Firmware	All	All	All	All
Hardware	Axis	Q6054	-	All	All	All
Hardware	Axis	Q6054	-	All	All	All
Hardware	Axis	Q6054-e	-	All	All	All
Hardware	Axis	Q6054-e	-	All	All	All
Operating System	Axis	Q6054-e Firmware	All	All	All	All
Operating System	Axis	Q6054-e Firmware	All	All	All	All
Hardware	Axis	Q6054-e Mk II	-	All	All	All
Hardware	Axis	Q6054-e Mk II	-	All	All	All
Operating System	Axis	Q6054-e Mk II Firmware	All	All	All	All
Operating System	Axis	Q6054-e Mk II Firmware	All	All	All	All
Operating System	Axis	Q6054 Firmware	All	All	All	All
Operating System	Axis	Q6054 Firmware	All	All	All	All
Hardware	Axis	Q6054 Mk II	-	All	All	All
Hardware	Axis	Q6054 Mk II	-	All	All	All
Operating System	Axis	Q6054 Mk II Firmware	All	All	All	All
Operating System	Axis	Q6054 Mk II Firmware	All	All	All	All
Hardware	Axis	Q6055	-	All	All	All
Hardware	Axis	Q6055	-	All	All	All
Hardware	Axis	Q6055-c	-	All	All	All
Hardware	Axis	Q6055-c	-	All	All	All
Operating System	Axis	Q6055-c Firmware	All	All	All	All
Operating System	Axis	Q6055-c Firmware	All	All	All	All
Hardware	Axis	Q6055-e	-	All	All	All
Hardware	Axis	Q6055-e	-	All	All	All
Operating System	Axis	Q6055-e Firmware	All	All	All	All
Operating System	Axis	Q6055-e Firmware	All	All	All	All
Hardware	Axis	Q6055-s	-	All	All	All
Hardware	Axis	Q6055-s	-	All	All	All
Operating System	Axis	Q6055-s Firmware	All	All	All	All
Operating System	Axis	Q6055-s Firmware	All	All	All	All
Operating System	Axis	Q6055 Firmware	All	All	All	All
Operating System	Axis	Q6055 Firmware	All	All	All	All

Hardware	Axis	Q6114-e	-	All	All	All
Hardware	Axis	Q6114-e	-	All	All	All
Operating System	Axis	Q6114-e Firmware	All	All	All	All
Operating System	Axis	Q6114-e Firmware	All	All	All	All
Hardware	Axis	Q6115-e	-	All	All	All
Hardware	Axis	Q6115-e	-	All	All	All
Operating System	Axis	Q6115-e Firmware	All	All	All	All
Operating System	Axis	Q6115-e Firmware	All	All	All	All
Hardware	Axis	Q6124-e	-	All	All	All
Hardware	Axis	Q6124-e	-	All	All	All
Operating System	Axis	Q6124-e Firmware	All	All	All	All
Operating System	Axis	Q6124-e Firmware	All	All	All	All
Hardware	Axis	Q6125-le	-	All	All	All
Hardware	Axis	Q6125-le	-	All	All	All
Operating System	Axis	Q6125-le Firmware	All	All	All	All
Operating System	Axis	Q6125-le Firmware	All	All	All	All
Hardware	Axis	Q6128-e	-	All	All	All
Hardware	Axis	Q6128-e	-	All	All	All
Operating System	Axis	Q6128-e Firmware	All	All	All	All
Operating System	Axis	Q6128-e Firmware	All	All	All	All
Hardware	Axis	Q6155-e	-	All	All	All
Hardware	Axis	Q6155-e	-	All	All	All
Operating System	Axis	Q6155-e Firmware	All	All	All	All
Operating System	Axis	Q6155-e Firmware	All	All	All	All
Hardware	Axis	Q7401	-	All	All	All
Hardware	Axis	Q7401	-	All	All	All
Operating System	Axis	Q7401 Firmware	All	All	All	All
Operating System	Axis	Q7401 Firmware	All	All	All	All
Hardware	Axis	Q7404	-	All	All	All
Hardware	Axis	Q7404	-	All	All	All
Operating System	Axis	Q7404 Firmware	All	All	All	All
Operating System	Axis	Q7404 Firmware	All	All	All	All
Hardware	Axis	Q7406 Blade	-	All	All	All
Hardware	Axis	Q7406 Blade	-	All	All	All
Operating System	Axis	Q7406 Blade Firmware	All	All	All	All

Operating System	Axis	Q7406 Blade Firmware	All	All	All	All
Hardware	Axis	Q7411	-	All	All	All
Hardware	Axis	Q7411	-	All	All	All
Operating System	Axis	Q7411 Firmware	All	All	All	All
Operating System	Axis	Q7411 Firmware	All	All	All	All
Hardware	Axis	Q7414 Blade	-	All	All	All
Hardware	Axis	Q7414 Blade	-	All	All	All
Operating System	Axis	Q7414 Blade Firmware	All	All	All	All
Operating System	Axis	Q7414 Blade Firmware	All	All	All	All
Hardware	Axis	Q7424-r	-	All	All	All
Hardware	Axis	Q7424-r	-	All	All	All
Operating System	Axis	Q7424-r Firmware	All	All	All	All
Operating System	Axis	Q7424-r Firmware	All	All	All	All
Hardware	Axis	Q7424-r Mk li	-	All	All	All
Hardware	Axis	Q7424-r Mk li	-	All	All	All
Operating System	Axis	Q7424-r Mk li Firmware	All	All	All	All
Operating System	Axis	Q7424-r Mk li Firmware	All	All	All	All
Hardware	Axis	Q7436 Blade	-	All	All	All
Hardware	Axis	Q7436 Blade	-	All	All	All
Operating System	Axis	Q7436 Blade Firmware	All	All	All	All
Operating System	Axis	Q7436 Blade Firmware	All	All	All	All
Hardware	Axis	Q8414-lvs	-	All	All	All
Hardware	Axis	Q8414-lvs	-	All	All	All
Operating System	Axis	Q8414-lvs Firmware	All	All	All	All
Operating System	Axis	Q8414-lvs Firmware	All	All	All	All
Hardware	Axis	Q8631-e	-	All	All	All
Hardware	Axis	Q8631-e	-	All	All	All
Operating System	Axis	Q8631-e Firmware	All	All	All	All
Operating System	Axis	Q8631-e Firmware	All	All	All	All
Hardware	Axis	Q8632-e	-	All	All	All
Hardware	Axis	Q8632-e	-	All	All	All
Operating System	Axis	Q8632-e Firmware	All	All	All	All
Operating System	Axis	Q8632-e Firmware	All	All	All	All
Hardware	Axis	Q8641-e	-	All	All	All
Hardware	Axis	Q8641-e	-	All	All	All
Operating System	Axis	Q8641-e Firmware	All	All	All	All

Operating System	Axis	Q8641-e Firmware	All	All	All	All
Operating System	Axis	Q8641-e Firmware	All	All	All	All
Hardware	Axis	Q8642-e	-	All	All	All
Hardware	Axis	Q8642-e	-	All	All	All
Operating System	Axis	Q8642-e Firmware	All	All	All	All
Operating System	Axis	Q8642-e Firmware	All	All	All	All
Hardware	Axis	Q8655-zle	-	All	All	All
Hardware	Axis	Q8655-zle	-	All	All	All
Operating System	Axis	Q8655-zle Firmware	All	All	All	All
Operating System	Axis	Q8655-zle Firmware	All	All	All	All
Hardware	Axis	Q8665-e	-	All	All	All
Hardware	Axis	Q8665-e	-	All	All	All
Operating System	Axis	Q8665-e Firmware	All	All	All	All
Operating System	Axis	Q8665-e Firmware	All	All	All	All
Hardware	Axis	Q8665-le	-	All	All	All
Hardware	Axis	Q8665-le	-	All	All	All
Operating System	Axis	Q8665-le Firmware	All	All	All	All
Operating System	Axis	Q8665-le Firmware	All	All	All	All
Hardware	Axis	Q8675-ze	-	All	All	All
Hardware	Axis	Q8675-ze	-	All	All	All
Operating System	Axis	Q8675-ze Firmware	All	All	All	All
Operating System	Axis	Q8675-ze Firmware	All	All	All	All
Hardware	Axis	Q8685-e	-	All	All	All
Hardware	Axis	Q8685-e	-	All	All	All
Operating System	Axis	Q8685-e Firmware	All	All	All	All
Operating System	Axis	Q8685-e Firmware	All	All	All	All
Hardware	Axis	Q8685-le	-	All	All	All
Hardware	Axis	Q8685-le	-	All	All	All
Operating System	Axis	Q8685-le Firmware	All	All	All	All
Operating System	Axis	Q8685-le Firmware	All	All	All	All
Hardware	Axis	Q8721-e	-	All	All	All
Hardware	Axis	Q8721-e	-	All	All	All
Operating System	Axis	Q8721-e Firmware	All	All	All	All
Operating System	Axis	Q8721-e Firmware	All	All	All	All
Hardware	Axis	Q8722-e	-	All	All	All
Hardware	Axis	Q8722-e	-	All	All	All

Operating System	Axis	Q8722-e Firmware	All	All	All	All
Operating System	Axis	Q8722-e Firmware	All	All	All	All
Hardware	Axis	Q8741-e	-	All	All	All
Hardware	Axis	Q8741-e	-	All	All	All
Operating System	Axis	Q8741-e Firmware	All	All	All	All
Operating System	Axis	Q8741-e Firmware	All	All	All	All
Hardware	Axis	Q8741-le	-	All	All	All
Hardware	Axis	Q8741-le	-	All	All	All
Operating System	Axis	Q8741-le Firmware	All	All	All	All
Operating System	Axis	Q8741-le Firmware	All	All	All	All
Hardware	Axis	Q8742-e	-	All	All	All
Hardware	Axis	Q8742-e	-	All	All	All
Operating System	Axis	Q8742-e Firmware	All	All	All	All
Operating System	Axis	Q8742-e Firmware	All	All	All	All
Hardware	Axis	Q8742-e Zoom	-	All	All	All
Hardware	Axis	Q8742-e Zoom	-	All	All	All
Operating System	Axis	Q8742-e Zoom Firmware	All	All	All	All
Operating System	Axis	Q8742-e Zoom Firmware	All	All	All	All
Hardware	Axis	Q8742-le	-	All	All	All
Hardware	Axis	Q8742-le	-	All	All	All
Operating System	Axis	Q8742-le Firmware	All	All	All	All
Operating System	Axis	Q8742-le Firmware	All	All	All	All
Hardware	Axis	Q8742-le Zoom	-	All	All	All
Hardware	Axis	Q8742-le Zoom	-	All	All	All
Operating System	Axis	Q8742-le Zoom Firmware	All	All	All	All
Operating System	Axis	Q8742-le Zoom Firmware	All	All	All	All
Hardware	Axis	V5914	-	All	All	All
Hardware	Axis	V5914	-	All	All	All
Operating System	Axis	V5914 Firmware	All	All	All	All
Operating System	Axis	V5914 Firmware	All	All	All	All
Hardware	Axis	V5915	-	All	All	All
Hardware	Axis	V5915	-	All	All	All
Operating System	Axis	V5915 Firmware	All	All	All	All
Operating System	Axis	V5915 Firmware	All	All	All	All
Hardware	Axis	Xf40-q1765	-	All	All	All

Hardware	Axis	Xf40-q1765	-	All	All	All
Operating System	Axis	Xf40-q1765 Firmware	All	All	All	All
Operating System	Axis	Xf40-q1765 Firmware	All	All	All	All
Hardware	Axis	Xf40-q2901	-	All	All	All
Hardware	Axis	Xf40-q2901	-	All	All	All
Operating System	Axis	Xf40-q2901 Firmware	All	All	All	All
Operating System	Axis	Xf40-q2901 Firmware	All	All	All	All
Hardware	Axis	Xf60-q2901	-	All	All	All
Hardware	Axis	Xf60-q2901	-	All	All	All
Operating System	Axis	Xf60-q2901 Firmware	All	All	All	All
Operating System	Axis	Xf60-q2901 Firmware	All	All	All	All
Hardware	Axis	Xp40-q1765	-	All	All	All
Hardware	Axis	Xp40-q1765	-	All	All	All
Operating System	Axis	Xp40-q1765 Firmware	All	All	All	All
Operating System	Axis	Xp40-q1765 Firmware	All	All	All	All
Hardware	Axis	Xp40-q1942	-	All	All	All
Hardware	Axis	Xp40-q1942	-	All	All	All
Operating System	Axis	Xp40-q1942 Firmware	All	All	All	All
Operating System	Axis	Xp40-q1942 Firmware	All	All	All	All
Hardware	Axis	Xp60-q1765	-	All	All	All
Hardware	Axis	Xp60-q1765	-	All	All	All
Operating System	Axis	Xp60-q1765 Firmware	All	All	All	All
Operating System	Axis	Xp60-q1765 Firmware	All	All	All	All

References

Reference	Source	Link	T
www.axis.com/files/faq/Advisory_ACV-128401.pdf	CONFIRM	www.axis.com	V
www.axis.com/files/sales/ACV-128401_Affected_Product_List.pdf	CONFIRM	www.axis.com	V
Axis Network Camera - .srv to parhand Remote Code Execution (Metasploit) - Linux remote Exploit	EXPLOIT-DB	www.exploit-db.com	E
VDOO Discovers Significant Vulnerabilities in Axis Cameras – VDOO	MISC	blog.vdoo.com	E
CVE Program record	CVE.ORG	www.cve.org	c
NVD vulnerability detail	NVD	nvd.nist.gov	c

No vendor comments have been submitted for this CVE.

There are currently no legacy QID mappings associated with this CVE.

© [CVE.report](#) 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](#) and the authoritative source of CVE content is [MITRE's CVE web site](#). This site includes MITRE data granted under the following [license](#).

CVE.report and Source URL Uptime Status [status.cve.report](#)