




CVE-2018-7827

Published on: 05/22/2019 12:00:00 AM UTC

Last Modified on: 03/23/2021 11:24:37 PM UTC

CVE-2018-7827

[Source: Mitre](#)[Source: NIST](#)[CVE.ORG](#)[Print: PDF](#) 

Certain versions of [D6220](#) from [Schneider-electric](#) contain the following vulnerability:

A Cross-Site Scripting (XSS) vulnerability exists in the 1st Gen. Pelco Sarix Enhanced Camera and Spectra Enhanced PTZ Camera which a remote attacker can execute arbitrary HTML and script code in a user's browser session.

CVE-2018-7827 has been assigned by [cybersecurity@schneider-electric.com](#) to track the vulnerability - currently rated as **MEDIUM** severity.

CVSS3 Score: **5.4 - MEDIUM**

Attack Vector	Attack Complexity	Privileges Required	User Interaction
NETWORK	LOW	LOW	REQUIRED
Scope	Confidentiality Impact	Integrity Impact	Availability Impact
CHANGED	LOW	LOW	NONE

CVSS2 Score: **3.5 - LOW**

Access Vector	Access Complexity	Authentication
NETWORK	MEDIUM	SINGLE
Confidentiality Impact	Integrity Impact	Availability Impact
NONE	PARTIAL	NONE

CVE References

Description	Tags	Link
Security Notification - Pelco Sarix Enhanced and Spectra Enhanced Schneider Electric	Vendor Advisory www.schneider-electric.com text/html	MISC www.schneider-electric.com/en/download/document/SEVD-2019-045-03/

By selecting these links, you may be leaving CVEreport webspace. We have provided these links to other websites because they may have information that would be of interest to you. No inferences should be drawn on account of other sites being referenced, or not, from this page. There may be other websites that are more appropriate for your purpose. CVEreport does not necessarily endorse the views expressed, or concur with the facts presented on these sites. Further, CVEreport does not endorse any commercial products that may be mentioned on these sites. Please address comments about any linked pages to comment@cve.report.

There are currently no QIDs associated with this CVE

Known Affected Configurations (CPE V2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware 	Schneider-electric	D6220	-	All	All	All
Hardware 	Schneider-electric	D6220	-	All	All	All
Hardware 	Schneider-electric	D6220I	-	All	All	All
Hardware 	Schneider-electric	D6220I	-	All	All	All
Operating System	Schneider-electric	D6220I Firmware	All	All	All	All
Operating System	Schneider-electric	D6220I Firmware	All	All	All	All
Operating System	Schneider-electric	D6220 Firmware	All	All	All	All
Operating System	Schneider-electric	D6220 Firmware	All	All	All	All
Hardware 	Schneider-electric	D6230	-	All	All	All
Hardware 	Schneider-electric	D6230	-	All	All	All
Hardware 	Schneider-electric	D6230I	-	All	All	All
Hardware 	Schneider-electric	D6230I	-	All	All	All
Operating System	Schneider-electric	D6230I Firmware	All	All	All	All
Operating System	Schneider-electric	D6230I Firmware	All	All	All	All
Operating System	Schneider-electric	D6230 Firmware	All	All	All	All
Operating System	Schneider-electric	D6230 Firmware	All	All	All	All
Hardware 	Schneider-electric	Ime119-1ei	-	All	All	All
Hardware 	Schneider-electric	Ime119-1ei	-	All	All	All
Operating System	Schneider-electric	Ime119-1ei Firmware	All	All	All	All
Operating System	Schneider-electric	Ime119-1ei Firmware	All	All	All	All
Hardware 	Schneider-electric	Ime119-1ep	-	All	All	All

Hardware  	Schneider-electric	lme119-1ep	-	All	All	All
Operating System	Schneider-electric	lme119-1ep Firmware	All	All	All	All
Operating System	Schneider-electric	lme119-1ep Firmware	All	All	All	All
Hardware  	Schneider-electric	lme119-1es	-	All	All	All
Hardware  	Schneider-electric	lme119-1es	-	All	All	All
Operating System	Schneider-electric	lme119-1es Firmware	All	All	All	All
Operating System	Schneider-electric	lme119-1es Firmware	All	All	All	All
Hardware  	Schneider-electric	lme119-1i	-	All	All	All
Hardware  	Schneider-electric	lme119-1i	-	All	All	All
Operating System	Schneider-electric	lme119-1i Firmware	All	All	All	All
Operating System	Schneider-electric	lme119-1i Firmware	All	All	All	All
Hardware  	Schneider-electric	lme119-1p	-	All	All	All
Hardware  	Schneider-electric	lme119-1p	-	All	All	All
Operating System	Schneider-electric	lme119-1p Firmware	All	All	All	All
Operating System	Schneider-electric	lme119-1p Firmware	All	All	All	All
Hardware  	Schneider-electric	lme119-1s	-	All	All	All
Hardware  	Schneider-electric	lme119-1s	-	All	All	All
Operating System	Schneider-electric	lme119-1s Firmware	All	All	All	All
Operating System	Schneider-electric	lme119-1s Firmware	All	All	All	All
Hardware  	Schneider-electric	lme119-1vi	-	All	All	All
Hardware  	Schneider-electric	lme119-1vi	-	All	All	All
Operating System	Schneider-electric	lme119-1vi Firmware	All	All	All	All
Operating System	Schneider-electric	lme119-1vi Firmware	All	All	All	All
Hardware  	Schneider-electric	lme119-1vp	-	All	All	All
Hardware  	Schneider-electric	lme119-1vp	-	All	All	All
Operating System	Schneider-electric	lme119-1vp Firmware	All	All	All	All
Operating System	Schneider-electric	lme119-1vp Firmware	All	All	All	All

Operating System	Schneider-electric	lme119-1vs Firmware	All	All	All	All
Hardware  	Schneider-electric	lme119-1vs	-	All	All	All
Hardware  	Schneider-electric	lme119-1vs	-	All	All	All
Operating System	Schneider-electric	lme119-1vs Firmware	All	All	All	All
Operating System	Schneider-electric	lme119-1vs Firmware	All	All	All	All
Hardware  	Schneider-electric	lme219-1ei	-	All	All	All
Hardware  	Schneider-electric	lme219-1ei	-	All	All	All
Operating System	Schneider-electric	lme219-1ei Firmware	All	All	All	All
Operating System	Schneider-electric	lme219-1ei Firmware	All	All	All	All
Hardware  	Schneider-electric	lme219-1ep	-	All	All	All
Hardware  	Schneider-electric	lme219-1ep	-	All	All	All
Operating System	Schneider-electric	lme219-1ep Firmware	All	All	All	All
Operating System	Schneider-electric	lme219-1ep Firmware	All	All	All	All
Hardware  	Schneider-electric	lme219-1es	-	All	All	All
Hardware  	Schneider-electric	lme219-1es	-	All	All	All
Operating System	Schneider-electric	lme219-1es Firmware	All	All	All	All
Operating System	Schneider-electric	lme219-1es Firmware	All	All	All	All
Hardware  	Schneider-electric	lme219-1i	-	All	All	All
Hardware  	Schneider-electric	lme219-1i	-	All	All	All
Operating System	Schneider-electric	lme219-1i Firmware	All	All	All	All
Operating System	Schneider-electric	lme219-1i Firmware	All	All	All	All
Hardware  	Schneider-electric	lme219-1p	-	All	All	All
Hardware  	Schneider-electric	lme219-1p	-	All	All	All
Operating System	Schneider-electric	lme219-1p Firmware	All	All	All	All
Operating System	Schneider-electric	lme219-1p Firmware	All	All	All	All
Hardware  	Schneider-electric	lme219-1s	-	All	All	All
Hardware  	Schneider-electric	lme219-1s	-	All	All	All

Operating System	Schneider-electric	lme219-1s Firmware	All	All	All	All
Operating System	Schneider-electric	lme219-1s Firmware	All	All	All	All
Hardware 	Schneider-electric	lme219-1vi	-	All	All	All
Hardware 	Schneider-electric	lme219-1vi	-	All	All	All
Operating System	Schneider-electric	lme219-1vi Firmware	All	All	All	All
Operating System	Schneider-electric	lme219-1vi Firmware	All	All	All	All
Hardware 	Schneider-electric	lme219-1vp	-	All	All	All
Hardware 	Schneider-electric	lme219-1vp	-	All	All	All
Operating System	Schneider-electric	lme219-1vp Firmware	All	All	All	All
Operating System	Schneider-electric	lme219-1vp Firmware	All	All	All	All
Hardware 	Schneider-electric	lme219-1vs	-	All	All	All
Hardware 	Schneider-electric	lme219-1vs	-	All	All	All
Operating System	Schneider-electric	lme219-1vs Firmware	All	All	All	All
Operating System	Schneider-electric	lme219-1vs Firmware	All	All	All	All
Hardware 	Schneider-electric	lme3122-1ei	-	All	All	All
Hardware 	Schneider-electric	lme3122-1ei	-	All	All	All
Operating System	Schneider-electric	lme3122-1ei Firmware	All	All	All	All
Operating System	Schneider-electric	lme3122-1ei Firmware	All	All	All	All
Hardware 	Schneider-electric	lme3122-1ep	-	All	All	All
Hardware 	Schneider-electric	lme3122-1ep	-	All	All	All
Operating System	Schneider-electric	lme3122-1ep Firmware	All	All	All	All
Operating System	Schneider-electric	lme3122-1ep Firmware	All	All	All	All
Hardware 	Schneider-electric	lme3122-1es	-	All	All	All
Hardware 	Schneider-electric	lme3122-1es	-	All	All	All
Operating System	Schneider-electric	lme3122-1es Firmware	All	All	All	All
Operating System	Schneider-electric	lme3122-1es Firmware	All	All	All	All

Hardware  	Schneider-electric	lme3122-1i	-	All	All	All
Hardware  	Schneider-electric	lme3122-1i	-	All	All	All
Operating System	Schneider-electric	lme3122-1i Firmware	All	All	All	All
Operating System	Schneider-electric	lme3122-1i Firmware	All	All	All	All
Hardware  	Schneider-electric	lme3122-1p	-	All	All	All
Hardware  	Schneider-electric	lme3122-1p	-	All	All	All
Operating System	Schneider-electric	lme3122-1p Firmware	All	All	All	All
Operating System	Schneider-electric	lme3122-1p Firmware	All	All	All	All
Hardware  	Schneider-electric	lme3122-1s	-	All	All	All
Hardware  	Schneider-electric	lme3122-1s	-	All	All	All
Operating System	Schneider-electric	lme3122-1s Firmware	All	All	All	All
Operating System	Schneider-electric	lme3122-1s Firmware	All	All	All	All
Hardware  	Schneider-electric	lme3122-1vi	-	All	All	All
Hardware  	Schneider-electric	lme3122-1vi	-	All	All	All
Operating System	Schneider-electric	lme3122-1vi Firmware	All	All	All	All
Operating System	Schneider-electric	lme3122-1vi Firmware	All	All	All	All
Hardware  	Schneider-electric	lme3122-1vp	-	All	All	All
Hardware  	Schneider-electric	lme3122-1vp	-	All	All	All
Operating System	Schneider-electric	lme3122-1vp Firmware	All	All	All	All
Operating System	Schneider-electric	lme3122-1vp Firmware	All	All	All	All
Hardware  	Schneider-electric	lme3122-1vs	-	All	All	All
Hardware  	Schneider-electric	lme3122-1vs	-	All	All	All
Operating System	Schneider-electric	lme3122-1vs Firmware	All	All	All	All
Operating System	Schneider-electric	lme3122-1vs Firmware	All	All	All	All
Hardware  	Schneider-electric	lme3122-b1i	-	All	All	All
Hardware  	Schneider-electric	lme3122-b1i	-	All	All	All
Operating System	Schneider-electric	lme3122-b1i Firmware	All	All	All	All

System						
Operating System	Schneider-electric	lme3122-b1i Firmware	All	All	All	All
Hardware 	Schneider-electric	lme3122-b1p	-	All	All	All
Hardware 	Schneider-electric	lme3122-b1p	-	All	All	All
Operating System	Schneider-electric	lme3122-b1p Firmware	All	All	All	All
Operating System	Schneider-electric	lme3122-b1p Firmware	All	All	All	All
Hardware 	Schneider-electric	lme3122-b1s	-	All	All	All
Hardware 	Schneider-electric	lme3122-b1s	-	All	All	All
Operating System	Schneider-electric	lme3122-b1s Firmware	All	All	All	All
Operating System	Schneider-electric	lme3122-b1s Firmware	All	All	All	All
Hardware 	Schneider-electric	lme319-1ei	-	All	All	All
Hardware 	Schneider-electric	lme319-1ei	-	All	All	All
Operating System	Schneider-electric	lme319-1ei Firmware	All	All	All	All
Operating System	Schneider-electric	lme319-1ei Firmware	All	All	All	All
Hardware 	Schneider-electric	lme319-1ep	-	All	All	All
Hardware 	Schneider-electric	lme319-1ep	-	All	All	All
Operating System	Schneider-electric	lme319-1ep Firmware	All	All	All	All
Operating System	Schneider-electric	lme319-1ep Firmware	All	All	All	All
Hardware 	Schneider-electric	lme319-1es	-	All	All	All
Hardware 	Schneider-electric	lme319-1es	-	All	All	All
Operating System	Schneider-electric	lme319-1es Firmware	All	All	All	All
Operating System	Schneider-electric	lme319-1es Firmware	All	All	All	All
Hardware 	Schneider-electric	lme319-1i	-	All	All	All
Hardware 	Schneider-electric	lme319-1i	-	All	All	All
Operating System	Schneider-electric	lme319-1i Firmware	All	All	All	All
Operating System	Schneider-electric	lme319-1i Firmware	All	All	All	All
Hardware 	Schneider-electric	lme319-1p	-	All	All	All

Hardware  	Schneider-electric	lme319-1p	-	All	All	All
Operating System	Schneider-electric	lme319-1p Firmware	All	All	All	All
Operating System	Schneider-electric	lme319-1p Firmware	All	All	All	All
Hardware  	Schneider-electric	lme319-1s	-	All	All	All
Hardware  	Schneider-electric	lme319-1s	-	All	All	All
Operating System	Schneider-electric	lme319-1s Firmware	All	All	All	All
Operating System	Schneider-electric	lme319-1s Firmware	All	All	All	All
Hardware  	Schneider-electric	lme319-1vi	-	All	All	All
Hardware  	Schneider-electric	lme319-1vi	-	All	All	All
Operating System	Schneider-electric	lme319-1vi Firmware	All	All	All	All
Operating System	Schneider-electric	lme319-1vi Firmware	All	All	All	All
Hardware  	Schneider-electric	lme319-1vp	-	All	All	All
Hardware  	Schneider-electric	lme319-1vp	-	All	All	All
Operating System	Schneider-electric	lme319-1vp Firmware	All	All	All	All
Operating System	Schneider-electric	lme319-1vp Firmware	All	All	All	All
Hardware  	Schneider-electric	lme319-1vs	-	All	All	All
Hardware  	Schneider-electric	lme319-1vs	-	All	All	All
Operating System	Schneider-electric	lme319-1vs Firmware	All	All	All	All
Operating System	Schneider-electric	lme319-1vs Firmware	All	All	All	All
Hardware  	Schneider-electric	lme319-b1i	-	All	All	All
Hardware  	Schneider-electric	lme319-b1i	-	All	All	All
Operating System	Schneider-electric	lme319-b1i Firmware	All	All	All	All
Operating System	Schneider-electric	lme319-b1i Firmware	All	All	All	All
Hardware  	Schneider-electric	lme319-b1p	-	All	All	All
Hardware  	Schneider-electric	lme319-b1p	-	All	All	All
Operating System	Schneider-electric	lme319-b1p Firmware	All	All	All	All
Operating	Schneider-electric	lme319-b1p Firmware	All	All	All	All

System						
Hardware  	Schneider-electric	lme319-b1s	-	All	All	All
Hardware  	Schneider-electric	lme319-b1s	-	All	All	All
Operating System	Schneider-electric	lme319-b1s Firmware	All	All	All	All
Operating System	Schneider-electric	lme319-b1s Firmware	All	All	All	All
Hardware  	Schneider-electric	lmes19-1ei	-	All	All	All
Hardware  	Schneider-electric	lmes19-1ei	-	All	All	All
Operating System	Schneider-electric	lmes19-1ei Firmware	All	All	All	All
Operating System	Schneider-electric	lmes19-1ei Firmware	All	All	All	All
Hardware  	Schneider-electric	lmes19-1ep	-	All	All	All
Hardware  	Schneider-electric	lmes19-1ep	-	All	All	All
Operating System	Schneider-electric	lmes19-1ep Firmware	All	All	All	All
Operating System	Schneider-electric	lmes19-1ep Firmware	All	All	All	All
Hardware  	Schneider-electric	lmes19-1es	-	All	All	All
Hardware  	Schneider-electric	lmes19-1es	-	All	All	All
Operating System	Schneider-electric	lmes19-1es Firmware	All	All	All	All
Operating System	Schneider-electric	lmes19-1es Firmware	All	All	All	All
Hardware  	Schneider-electric	lmes19-1i	-	All	All	All
Hardware  	Schneider-electric	lmes19-1i	-	All	All	All
Operating System	Schneider-electric	lmes19-1i Firmware	All	All	All	All
Operating System	Schneider-electric	lmes19-1i Firmware	All	All	All	All
Hardware  	Schneider-electric	lmes19-1p	-	All	All	All
Hardware  	Schneider-electric	lmes19-1p	-	All	All	All
Operating System	Schneider-electric	lmes19-1p Firmware	All	All	All	All
Operating System	Schneider-electric	lmes19-1p Firmware	All	All	All	All
Hardware  	Schneider-electric	lmes19-1s	-	All	All	All
Hardware  	Schneider-electric	lmes19-1s	-	All	All	All

Operating System	Schneider-electric	Imes19-1s Firmware	All	All	All	All
Operating System	Schneider-electric	Imes19-1s Firmware	All	All	All	All
Hardware 	Schneider-electric	Imes19-1vi	-	All	All	All
Hardware 	Schneider-electric	Imes19-1vi	-	All	All	All
Operating System	Schneider-electric	Imes19-1vi Firmware	All	All	All	All
Operating System	Schneider-electric	Imes19-1vi Firmware	All	All	All	All
Hardware 	Schneider-electric	Imes19-1vp	-	All	All	All
Hardware 	Schneider-electric	Imes19-1vp	-	All	All	All
Operating System	Schneider-electric	Imes19-1vp Firmware	All	All	All	All
Operating System	Schneider-electric	Imes19-1vp Firmware	All	All	All	All
Hardware 	Schneider-electric	Imes19-1vs	-	All	All	All
Hardware 	Schneider-electric	Imes19-1vs	-	All	All	All
Operating System	Schneider-electric	Imes19-1vs Firmware	All	All	All	All
Operating System	Schneider-electric	Imes19-1vs Firmware	All	All	All	All
Hardware 	Schneider-electric	Ixe11	-	All	All	All
Hardware 	Schneider-electric	Ixe11	-	All	All	All
Operating System	Schneider-electric	Ixe11 Firmware	All	All	All	All
Operating System	Schneider-electric	Ixe11 Firmware	All	All	All	All
Hardware 	Schneider-electric	Ixe21	-	All	All	All
Hardware 	Schneider-electric	Ixe21	-	All	All	All
Operating System	Schneider-electric	Ixe21 Firmware	All	All	All	All
Operating System	Schneider-electric	Ixe21 Firmware	All	All	All	All
Hardware 	Schneider-electric	Ixe31	-	All	All	All
Hardware 	Schneider-electric	Ixe31	-	All	All	All
Operating System	Schneider-electric	Ixe31 Firmware	All	All	All	All
Operating System	Schneider-electric	Ixe31 Firmware	All	All	All	All

Hardware	Schneider-electric	Ixes1	-	All	All	All
Hardware	Schneider-electric	Ixes1	-	All	All	All
Operating System	Schneider-electric	Ixes1 Firmware	All	All	All	All
Operating System	Schneider-electric	Ixes1 Firmware	All	All	All	All
cpe:2.3:h:schneider-electric:d6220:-:*:*:*:*:*:						
cpe:2.3:h:schneider-electric:d6220:-:*:*:*:*:*:						
cpe:2.3:h:schneider-electric:d6220l:-:*:*:*:*:*:						
cpe:2.3:h:schneider-electric:d6220l:-:*:*:*:*:*:						
cpe:2.3:o:schneider-electric:d6220l_firmware:*:*:*:*:*:						
cpe:2.3:o:schneider-electric:d6220l_firmware:*:*:*:*:*:						
cpe:2.3:o:schneider-electric:d6220_firmware:*:*:*:*:*:						
cpe:2.3:o:schneider-electric:d6220_firmware:*:*:*:*:*:						
cpe:2.3:h:schneider-electric:d6230:-:*:*:*:*:*:						
cpe:2.3:h:schneider-electric:d6230:-:*:*:*:*::~:						
cpe:2.3:h:schneider-electric:d6230l:-:*:*:*:*::~:						
cpe:2.3:h:schneider-electric:d6230l:-:*:*:*:*::~:						
cpe:2.3:o:schneider-electric:d6230l_firmware:*:*:*:*::~:						
cpe:2.3:o:schneider-electric:d6230l_firmware:*:*:*:*::~:						
cpe:2.3:o:schneider-electric:d6230_firmware:*:*:*:*::~:						
cpe:2.3:o:schneider-electric:d6230_firmware:*:*:*:*::~:						
cpe:2.3:h:schneider-electric:ime119-1ei:-:*:*:*:*::~:						
cpe:2.3:h:schneider-electric:ime119-1ei:-:*:*:*:*::~:						
cpe:2.3:o:schneider-electric:ime119-1ei_firmware:*:*:*:*::~:						
cpe:2.3:o:schneider-electric:ime119-1ei_firmware:*:*:*:*::~:						
cpe:2.3:h:schneider-electric:ime119-1ep:-:*:*:*:*::~:						
cpe:2.3:h:schneider-electric:ime119-1ep:-:*:*:*:*::~:						
cpe:2.3:o:schneider-electric:ime119-1ep_firmware:*:*:*:*::~:						
cpe:2.3:o:schneider-electric:ime119-1ep_firmware:*:*:*:*::~:						

cpe:2.3:h:schneider-electric:ime119-1es:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1es:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime119-1es_firmware:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ime119-1es_firmware:*:*:*:*:*.*
```

cpe:2.3:h:schneider-electric:ime119-1i:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1i:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime119-1i_firmware:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime119-1i_firmware:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1p:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1p:-:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ime119-1p_firmware:*:*:*:*:*:*:
```

cpe:2.3:o:schneider-electric:ime119-1p_firmware:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1s:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1s:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime119-1s_firmware:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime119-1s_firmware:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1vi:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1vi:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime119-1vi_firmware:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime119-1vi_firmware:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1vp:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1vp:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime119-1vp_firmware:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime119-1vp_firmware:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1vs:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime119-1vs:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime119-1vs_firmware:*:*:*:*:*.*

cpe:2.3:o:schneider-electric:ime119-1vs_firmware:*. *.*.*.*.*.*.*.*.*.*

cpe:2.3:h:schneider-electric:ime219-1ei:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime219-1ei:-:*:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ime219-1ei_firmware:*.***.***.***
```

```
cpe:2.3:o:schneider-electric:ime219-1ei_firmware:*:*:*:*:*.*
```

cpe:2.3:h:schneider-electric:ime219-1ep:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime219-1ep:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime219-1ep_firmware:*.*.*.*.*.*.*

cpe:2.3:o:schneider-electric:ime219-1ep_firmware:*:*:*:*:*.*

cpe:2.3:h:schneider-electric:ime219-1es:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime219-1es:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime219-1es_firmware:*.~*~*~*~*~*~*

cpe:2.3:o:schneider-electric:ime219-1es_firmware:*.:*:*:*:*:*.*

cpe:2.3:h:schneider-electric:ime219-1i:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime219-1i:-:*:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ime219-1i_firmware:*.:.:.:.:.:.:
```

```
cpe:2.3:o:schneider-electric:ime219-1i_firmware:*.:.:.:.:.:.:
```

cpe:2.3:h:schneider-electric:ime219-1p:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime219-1p:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime219-1p_firmware:*:*:*:*:*.*

cpe:2.3:o:schneider-electric:ime219-1p_firmware:*.*.*.*.*.*.*.*

cpe:2.3:h:schneider-electric:ime219-1s:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime219-1s:-:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime219-1s_firmware:*.:*:*:*:*:*.*

```
cpe:2.3:o:schneider-electric:ime219-1s_firmware:*:*:*:*:*.*
```

cpe:2.3:h:schneider-electric:ime219-1vi:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime219-1vi:-:*:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ime219-1vi_firmware:*:*:*:*:*.*
```

cpe:2.3:o:schneider-electric:ime219-1vi_firmware:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime219-1vp:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime219-1vp:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime219-1vp_firmware:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime219-1vp_firmware:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime219-1vs:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime219-1vs:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime219-1vs_firmware:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime219-1vs_firmware:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-1ei:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-1ei:-:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime3122-1ei_firmware:*:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ime3122-1ei_firmware:*:*:*:*:*:*:
```

cpe:2.3:h:schneider-electric:ime3122-1ep:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-1ep:-:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime3122-1ep_firmware:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime3122-1ep_firmware:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-1es:-.*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-1es:-.*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime3122-1es_firmware:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime3122-1es_firmware:*:*:*:*:*.*

cpe:2.3:h:schneider-electric:ime3122-1i:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-1i:-:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime3122-1i_firmware:*:*:*:*:*:*

cpe:2.3:o:schneider-electric:ime3122-1i_firmware:*:*:*:*:*:*

cpe:2.3:h:schneider-electric:ime3122-1p:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-1p:-:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ime3122-1p firmware:*.*.*.*.*.*.*.*
```

cpe:2.3:o:schneider-electric:ime3122-1p_firmware:*:*:*:*:*.*

cpe:2.3:h:schneider-electric:ime3122-1s:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-1s:-:*:*:*:*:*:*

.....

```
cpe:2.3:o:schneider-electric:ime3122-1s_firmware:*.*.*.*.*.*.*.*
```

```
cpe:2.3:o:schneider-electric:ime3122-1s_firmware:*:*:*:*:*.*
```

cpe:2.3:h:schneider-electric:ime3122-1vi:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-1vi:-:*:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ime3122-1vi_firmware:*.*.*.*.*.*.*.*
```

cpe:2.3:o:schneider-electric:ime3122-1vi_firmware:*:*:*:*:*.*

cpe:2.3:h:schneider-electric:ime3122-1 vp:-:~::~~::~~::~~::~~::~~::

cpe:2.3:h:schneider-electric:ime3122-1 vp:-:*:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ime3122-1vp_firmware:*.*.*.*.*.*.*.*
```

```
cpe:2.3:o:schneider-electric:ime3122-1vp_firmware:*.*.*.*.*.*.*.*.*.*
```

cpe:2.3:h:schneider-electric:ime3122-1 vs:-:~::~~::~~::~~::~~::~~::~::

cpe:2.3:h:schneider-electric:ime3122-1vs:-:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime3122-1vs_firmware:*:*:*:*:*:*

cpe:2.3:o:schneider-electric:ime3122-1vs_firmware:*:*:*:*:*:*

cpe:2.3:h:schneider-electric:ime3122-b1j:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-b1j:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime3122-b1i_firmware:*:*:*:*:*.*

cpe:2.3:o:schneider-electric:ime3122-b1i_firmware:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-b1p:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-b1p:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime3122-b1p_firmware:*.*.*.*.*.*.*.*

cpe:2.3:o:schneider-electric:ime3122-b1p_firmware:*.*.*.*.*.*.*.*.*.*

cpe:2.3:h:schneider-electric:ime3122-b1s:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime3122-b1s:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime3122-b1s_firmware:*.*.*.*.*.*.*.*.*

cpe:2.3:o:schneider-electric:ime3122-b1s_firmware:*.*.*.*.*.*.*.*

cpe:2.3:h:schneider-electric:ime319-1ei:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime319-1ei:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime319-1ei_firmware:*.*.*.*.*.*.*.*

cpe:2.3:o:schneider-electric:ime319-1ei_firmware:*.*.*.*.*.*.*.*

cpe:2.3:h:schneider-electric:ime319-1ep:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime319-1ep:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime319-1ep_firmware:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime319-1ep_firmware:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime319-1es:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime319-1es:-:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime319-1es_firmware:*:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ime319-1es_firmware:*:*:*:*:*:
```

cpe:2.3:h:schneider-electric:ime319-1i:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime319-1i:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime319-1i_firmware:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime319-1i_firmware:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime319-1p:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime319-1p:-:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime319-1p_firmware:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime319-1p_firmware:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime319-1s:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime319-1s:-:*:*:*:*:*:

cpe:2.3:o:schneider-electric:ime319-1s_firmware:*.:*:*:*:*:*

cpe:2.3:o:schneider-electric:ime319-1s_firmware:*.*.*.*.*.*.*.*

cpe:2.3:h:schneider-electric:ime319-1vi:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime319-1vi:-:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ime319-1vi_firmware:*:*:*:*:*.*
```

cpe:2.3:o:schneider-electric:ime319-1vi_firmware:*.*.*.*.*.*.*.*

cpe:2.3:h:schneider-electric:ime319-1vp:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ime319-1vp:-:*:*:*:*:*:

```
ans=0;for each index element ans+=ans*(1+sqrt(5));end
```


cpe:2.3:o:schneider-electric:ime319-1vp_firmware:*****:
cpe:2.3:o:schneider-electric:ime319-1vp_firmware:*****:
cpe:2.3:h:schneider-electric:ime319-1vs:-*****:
cpe:2.3:h:schneider-electric:ime319-1vs:-*****:
cpe:2.3:o:schneider-electric:ime319-1vs_firmware:*****:
cpe:2.3:o:schneider-electric:ime319-1vs_firmware:*****:
cpe:2.3:h:schneider-electric:ime319-b1i:-*****:
cpe:2.3:h:schneider-electric:ime319-b1i:-*****:
cpe:2.3:o:schneider-electric:ime319-b1i_firmware:*****:
cpe:2.3:o:schneider-electric:ime319-b1i_firmware:*****:
cpe:2.3:h:schneider-electric:ime319-b1p:-*****:
cpe:2.3:h:schneider-electric:ime319-b1p:-*****:
cpe:2.3:o:schneider-electric:ime319-b1p_firmware:*****:
cpe:2.3:o:schneider-electric:ime319-b1p_firmware:*****:
cpe:2.3:h:schneider-electric:ime319-b1s:-*****:
cpe:2.3:h:schneider-electric:ime319-b1s:-*****:
cpe:2.3:o:schneider-electric:ime319-b1s_firmware:*****:
cpe:2.3:o:schneider-electric:ime319-b1s_firmware:*****:
cpe:2.3:h:schneider-electric:imes19-1ei:-*****:
cpe:2.3:h:schneider-electric:imes19-1ei:-*****:
cpe:2.3:o:schneider-electric:imes19-1ei_firmware:*****:
cpe:2.3:o:schneider-electric:imes19-1ei_firmware:*****:
cpe:2.3:h:schneider-electric:imes19-1ep:-*****:
cpe:2.3:h:schneider-electric:imes19-1ep:-*****:
cpe:2.3:o:schneider-electric:imes19-1ep_firmware:*****:
cpe:2.3:o:schneider-electric:imes19-1ep_firmware:*****:
cpe:2.3:h:schneider-electric:imes19-1es:-*****:
cpe:2.3:h:schneider-electric:imes19-1es:-*****:
cpe:2.3:o:schneider-electric:imes19-1es_firmware:*****:

cpe:2.3:o:schneider-electric:imes19-1es_firmware:*:*:*:*:*:

cpe:2.3:h:schneider-electric:imes19-1i:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:imes19-1i:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:imes19-1i_firmware:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:imes19-1i_firmware:*:*:*:*:*:

cpe:2.3:h:schneider-electric:imes19-1p:-:*:*:*:*:*:

cpe:2.3:h:schneider-electric:imes19-1p:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:imes19-1p_firmware:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:imes19-1p_firmware:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:imes19-1s:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:imes19-1s:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:imes19-1s_firmware:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:imes19-1s_firmware:*.:.:.:.:.:.:

```
cpe:2.3:h:schneider-electric:imes19-1vi:-:*:*:*:*:*:*:
```

cpe:2.3:h:schneider-electric:imes19-1vi:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:imes19-1vi_firmware:*:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:imes19-1vi_firmware:*:*:*:*:*.*
```

cpe:2.3:h:schneider-electric:imes19-1vp:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:imes19-1vp:-:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:imes19-1vp_firmware:*:*:*:*:*:*:

cpe:2.3:o:schneider-electric:imes19-1vp_firmware:*.*.*.*.*.*.*.*

cpe:2.3:h:schneider-electric:imes19-1vs:-:~::~~::~~::~~::~~::~~::

cpe:2.3:h:schneider-electric:imes19-1 vs:-:~::~~::~~::~~::~~::~~::~::

```
cpe:2.3:o:schneider-electric:imes19-1vs_firmware:*.*.*.*.*.*.*.*
```

cpe:2.3:o:schneider-electric:imes19-1vs_firmware:*.*.*.*.*.*.*.*

cpe:2.3:h:schneider-electric:ixe11:-:*:*:*:*:*:*:

cpe:2.3:h:schneider-electric:ixe11:-:*:*:*:*:*:*:

```
cpe:2.3:o:schneider-electric:ixe11_firmware:*:*:*:*:*:*
```

