



CVE-2019-16650

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

Summary

CVE	CVE-2019-16650
State	PUBLIC
Assigner	cve@mitre.org
Source Priority	CVE Program / NVD first with legacy fallback
Published	2019-09-21 02:15:00 UTC
Updated	2020-08-24 17:37:00 UTC
Description	On Supermicro X10 and X11 products, a client's access privileges may be transferred to a different client that later has the

Risk And Classification

Problem Types: NVD-CWE-noinfo

NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware	Supermicro	A1sa2-2750f	-	All	All	All
Hardware	Supermicro	A1sa2-2750f	-	All	All	All
Operating System	Supermicro	A1sa2-2750f Firmware	3.83	All	All	All
Operating System	Supermicro	A1sa2-2750f Firmware	3.83	All	All	All
Hardware	Supermicro	A1sai-2550f	-	All	All	All
Hardware	Supermicro	A1sai-2550f	-	All	All	All
Operating System	Supermicro	A1sai-2550f Firmware	3.83	All	All	All
Operating System	Supermicro	A1sai-2550f Firmware	3.83	All	All	All
Hardware	Supermicro	A1sai-2750f	-	All	All	All
Hardware	Supermicro	A1sai-2750f	-	All	All	All
Operating System	Supermicro	A1sai-2750f Firmware	3.83	All	All	All
Operating System	Supermicro	A1sai-2750f Firmware	3.83	All	All	All
Hardware	Supermicro	A1sam-2550f	-	All	All	All
Hardware	Supermicro	A1sam-2550f	-	All	All	All
Operating System	Supermicro	A1sam-2550f Firmware	3.83	All	All	All
Operating System	Supermicro	A1sam-2550f Firmware	3.83	All	All	All
Hardware	Supermicro	A1sam-2750f	-	All	All	All

Hardware	Supermicro	A1sam-2750f	-	All	All	All
Operating System	Supermicro	A1sam-2750f Firmware	3.83	All	All	All
Operating System	Supermicro	A1sam-2750f Firmware	3.83	All	All	All
Hardware	Supermicro	A1sri-2358f	-	All	All	All
Hardware	Supermicro	A1sri-2358f	-	All	All	All
Operating System	Supermicro	A1sri-2358f Firmware	3.83	All	All	All
Operating System	Supermicro	A1sri-2358f Firmware	3.83	All	All	All
Hardware	Supermicro	A1sri-2558f	-	All	All	All
Hardware	Supermicro	A1sri-2558f	-	All	All	All
Operating System	Supermicro	A1sri-2558f Firmware	3.83	All	All	All
Operating System	Supermicro	A1sri-2558f Firmware	3.83	All	All	All
Hardware	Supermicro	A1sri-2758f	-	All	All	All
Hardware	Supermicro	A1sri-2758f	-	All	All	All
Operating System	Supermicro	A1sri-2758f Firmware	3.83	All	All	All
Operating System	Supermicro	A1sri-2758f Firmware	3.83	All	All	All
Hardware	Supermicro	A1srm-2558f	-	All	All	All
Hardware	Supermicro	A1srm-2558f	-	All	All	All
Operating System	Supermicro	A1srm-2558f Firmware	3.83	All	All	All
Operating System	Supermicro	A1srm-2558f Firmware	3.83	All	All	All
Hardware	Supermicro	A1srm-2758f	-	All	All	All
Hardware	Supermicro	A1srm-2758f	-	All	All	All
Operating System	Supermicro	A1srm-2758f Firmware	3.83	All	All	All
Operating System	Supermicro	A1srm-2758f Firmware	3.83	All	All	All
Hardware	Supermicro	A1srm-In5f-2358	-	All	All	All
Hardware	Supermicro	A1srm-In5f-2358	-	All	All	All
Operating System	Supermicro	A1srm-In5f-2358 Firmware	3.83	All	All	All
Operating System	Supermicro	A1srm-In5f-2358 Firmware	3.83	All	All	All
Hardware	Supermicro	A1srm-In7f-2358	-	All	All	All
Hardware	Supermicro	A1srm-In7f-2358	-	All	All	All
Operating System	Supermicro	A1srm-In7f-2358 Firmware	3.83	All	All	All
Operating System	Supermicro	A1srm-In7f-2358 Firmware	3.83	All	All	All
Hardware	Supermicro	A1srm-In7f-2758	-	All	All	All
Hardware	Supermicro	A1srm-In7f-2758	-	All	All	All
Operating System	Supermicro	A1srm-In7f-2758 Firmware	3.83	All	All	All
Operating System	Supermicro	A1srm-In7f-2758 Firmware	3.83	All	All	All

Hardware	Supermicro	B10drc	-	All	All	All
Hardware	Supermicro	B10drc	-	All	All	All
Hardware	Supermicro	B10drc-n	-	All	All	All
Hardware	Supermicro	B10drc-n	-	All	All	All
Operating System	Supermicro	B10drc-n Firmware	3.68	All	All	All
Operating System	Supermicro	B10drc-n Firmware	3.68	All	All	All
Operating System	Supermicro	B10drc Firmware	3.68	All	All	All
Operating System	Supermicro	B10drc Firmware	3.68	All	All	All
Hardware	Supermicro	B10drg-ibf	-	All	All	All
Hardware	Supermicro	B10drg-ibf	-	All	All	All
Hardware	Supermicro	B10drg-ibf2	-	All	All	All
Hardware	Supermicro	B10drg-ibf2	-	All	All	All
Operating System	Supermicro	B10drg-ibf2 Firmware	3.68	All	All	All
Operating System	Supermicro	B10drg-ibf2 Firmware	3.68	All	All	All
Operating System	Supermicro	B10drg-ibf Firmware	3.68	All	All	All
Operating System	Supermicro	B10drg-ibf Firmware	3.68	All	All	All
Hardware	Supermicro	B10drg-tp	-	All	All	All
Hardware	Supermicro	B10drg-tp	-	All	All	All
Operating System	Supermicro	B10drg-tp Firmware	3.68	All	All	All
Operating System	Supermicro	B10drg-tp Firmware	3.68	All	All	All
Hardware	Supermicro	B10dri	-	All	All	All
Hardware	Supermicro	B10dri	-	All	All	All
Hardware	Supermicro	B10dri-n	-	All	All	All
Hardware	Supermicro	B10dri-n	-	All	All	All
Operating System	Supermicro	B10dri-n Firmware	3.68	All	All	All
Operating System	Supermicro	B10dri-n Firmware	3.68	All	All	All
Operating System	Supermicro	B10dri Firmware	3.68	All	All	All
Operating System	Supermicro	B10dri Firmware	3.68	All	All	All
Hardware	Supermicro	B10drt	-	All	All	All
Hardware	Supermicro	B10drt	-	All	All	All
Hardware	Supermicro	B10drt-ibf	-	All	All	All
Hardware	Supermicro	B10drt-ibf	-	All	All	All
Hardware	Supermicro	B10drt-ibf2	-	All	All	All
Hardware	Supermicro	B10drt-ibf2	-	All	All	All
Operating System	Supermicro	B10drt-ibf2 Firmware	3.68	All	All	All

Operating System	Supermicro	B10drt-ibf2 Firmware	3.68	All	All	All
Operating System	Supermicro	B10drt-ibf Firmware	3.68	All	All	All
Operating System	Supermicro	B10drt-ibf Firmware	3.68	All	All	All
Hardware	Supermicro	B10drt-tp	-	All	All	All
Hardware	Supermicro	B10drt-tp	-	All	All	All
Operating System	Supermicro	B10drt-tp Firmware	3.68	All	All	All
Operating System	Supermicro	B10drt-tp Firmware	3.68	All	All	All
Operating System	Supermicro	B10drt Firmware	3.68	All	All	All
Operating System	Supermicro	B10drt Firmware	3.68	All	All	All
Hardware	Supermicro	B11dpe	-	All	All	All
Hardware	Supermicro	B11dpe	-	All	All	All
Operating System	Supermicro	B11dpe Firmware	3.68	All	All	All
Operating System	Supermicro	B11dpe Firmware	3.68	All	All	All
Hardware	Supermicro	B11dpt	-	All	All	All
Hardware	Supermicro	B11dpt	-	All	All	All
Operating System	Supermicro	B11dpt Firmware	3.68	All	All	All
Operating System	Supermicro	B11dpt Firmware	3.68	All	All	All
Hardware	Supermicro	B11qpi	-	All	All	All
Hardware	Supermicro	B11qpi	-	All	All	All
Operating System	Supermicro	B11qpi Firmware	3.68	All	All	All
Operating System	Supermicro	B11qpi Firmware	3.68	All	All	All
Hardware	Supermicro	B11spe-cpu-25g	-	All	All	All
Hardware	Supermicro	B11spe-cpu-25g	-	All	All	All
Operating System	Supermicro	B11spe-cpu-25g Firmware	3.68	All	All	All
Operating System	Supermicro	B11spe-cpu-25g Firmware	3.68	All	All	All
Hardware	Supermicro	B11spe-cpu-tf	-	All	All	All
Hardware	Supermicro	B11spe-cpu-tf	-	All	All	All
Operating System	Supermicro	B11spe-cpu-tf Firmware	3.68	All	All	All
Operating System	Supermicro	B11spe-cpu-tf Firmware	3.68	All	All	All
Hardware	Supermicro	B1sd1-16c-tf	-	All	All	All
Hardware	Supermicro	B1sd1-16c-tf	-	All	All	All
Operating System	Supermicro	B1sd1-16c-tf Firmware	3.68	All	All	All
Operating System	Supermicro	B1sd1-16c-tf Firmware	3.68	All	All	All
Hardware	Supermicro	B1sd1-tf	-	All	All	All
Hardware	Supermicro	B1sd1-tf	-	All	All	All
Operating System	Supermicro	B1sd1-tf Firmware	3.68	All	All	All

Operating System	Supermicro	B1sd1-tf Firmware	3.68	All	All	All
Hardware	Supermicro	B1sd2-16c-tf	-	All	All	All
Hardware	Supermicro	B1sd2-16c-tf	-	All	All	All
Operating System	Supermicro	B1sd2-16c-tf Firmware	3.68	All	All	All
Operating System	Supermicro	B1sd2-16c-tf Firmware	3.68	All	All	All
Hardware	Supermicro	B1sd2-tf	-	All	All	All
Hardware	Supermicro	B1sd2-tf	-	All	All	All
Operating System	Supermicro	B1sd2-tf Firmware	3.68	All	All	All
Operating System	Supermicro	B1sd2-tf Firmware	3.68	All	All	All
Hardware	Supermicro	B2ss1-cf	-	All	All	All
Hardware	Supermicro	B2ss1-cf	-	All	All	All
Operating System	Supermicro	B2ss1-cf Firmware	3.68	All	All	All
Operating System	Supermicro	B2ss1-cf Firmware	3.68	All	All	All
Hardware	Supermicro	B2ss1-cpu	-	All	All	All
Hardware	Supermicro	B2ss1-cpu	-	All	All	All
Operating System	Supermicro	B2ss1-cpu Firmware	3.68	All	All	All
Operating System	Supermicro	B2ss1-cpu Firmware	3.68	All	All	All
Hardware	Supermicro	B2ss1-f	-	All	All	All
Hardware	Supermicro	B2ss1-f	-	All	All	All
Operating System	Supermicro	B2ss1-f Firmware	3.68	All	All	All
Operating System	Supermicro	B2ss1-f Firmware	3.68	All	All	All
Hardware	Supermicro	B2ss1-h-mtf	-	All	All	All
Hardware	Supermicro	B2ss1-h-mtf	-	All	All	All
Operating System	Supermicro	B2ss1-h-mtf Firmware	3.68	All	All	All
Operating System	Supermicro	B2ss1-h-mtf Firmware	3.68	All	All	All
Hardware	Supermicro	B2ss1-mtf	-	All	All	All
Hardware	Supermicro	B2ss1-mtf	-	All	All	All
Operating System	Supermicro	B2ss1-mtf Firmware	3.68	All	All	All
Operating System	Supermicro	B2ss1-mtf Firmware	3.68	All	All	All
Hardware	Supermicro	B2ss2-f	-	All	All	All
Hardware	Supermicro	B2ss2-f	-	All	All	All
Operating System	Supermicro	B2ss2-f Firmware	3.68	All	All	All
Operating System	Supermicro	B2ss2-f Firmware	3.68	All	All	All
Hardware	Supermicro	B2ss2-h-mtf	-	All	All	All
Hardware	Supermicro	B2ss2-h-mtf	-	All	All	All

Operating System	Supermicro	B2ss2-h-mtf Firmware	3.68	All	All	All
Operating System	Supermicro	B2ss2-h-mtf Firmware	3.68	All	All	All
Hardware	Supermicro	B2ss2-mtf	-	All	All	All
Hardware	Supermicro	B2ss2-mtf	-	All	All	All
Operating System	Supermicro	B2ss2-mtf Firmware	3.68	All	All	All
Operating System	Supermicro	B2ss2-mtf Firmware	3.68	All	All	All
Hardware	Supermicro	X10dbt-t	-	All	All	All
Hardware	Supermicro	X10dbt-t	-	All	All	All
Operating System	Supermicro	X10dbt-t Firmware	3.83	All	All	All
Operating System	Supermicro	X10dbt-t Firmware	3.83	All	All	All
Hardware	Supermicro	X10ddw-i	-	All	All	All
Hardware	Supermicro	X10ddw-i	-	All	All	All
Hardware	Supermicro	X10ddw-in	-	All	All	All
Hardware	Supermicro	X10ddw-in	-	All	All	All
Operating System	Supermicro	X10ddw-in Firmware	3.83	All	All	All
Operating System	Supermicro	X10ddw-in Firmware	3.83	All	All	All
Operating System	Supermicro	X10ddw-i Firmware	3.83	All	All	All
Operating System	Supermicro	X10ddw-i Firmware	3.83	All	All	All
Hardware	Supermicro	X10dgo-t	-	All	All	All
Hardware	Supermicro	X10dgo-t	-	All	All	All
Operating System	Supermicro	X10dgo-t Firmware	3.83	All	All	All
Operating System	Supermicro	X10dgo-t Firmware	3.83	All	All	All
Hardware	Supermicro	X10dgq	-	All	All	All
Hardware	Supermicro	X10dgq	-	All	All	All
Operating System	Supermicro	X10dgq Firmware	3.83	All	All	All
Operating System	Supermicro	X10dgq Firmware	3.83	All	All	All
Hardware	Supermicro	X10drc-ln4	-	All	All	All
Operating System	Supermicro	X10drc-ln4 Firmware	3.83	All	All	All
Hardware	Supermicro	X10drc-ln4	-	All	All	All
Hardware	Supermicro	X10drc-ln4	-	All	All	All
Operating System	Supermicro	X10drc-ln4 Firmware	3.83	All	All	All
Operating System	Supermicro	X10drc-ln4 Firmware	3.83	All	All	All
Hardware	Supermicro	X10drc-t4	-	All	All	All
Operating System	Supermicro	X10drc-t4 Firmware	3.83	All	All	All
Hardware	Supermicro	X10drc-t4	-	All	All	All
Hardware	Supermicro	X10drc-t4	-	All	All	All

Hardware	Supermicro	X100rc-t4	-	All	All	All
Operating System	Supermicro	X10drc-t4 Firmware	3.83	All	All	All
Operating System	Supermicro	X10drc-t4 Firmware	3.83	All	All	All
Hardware	Supermicro	X10drd-i	-	All	All	All
Hardware	Supermicro	X10drd-i	-	All	All	All
Hardware	Supermicro	X10drd-int	-	All	All	All
Hardware	Supermicro	X10drd-int	-	All	All	All
Hardware	Supermicro	X10drd-intp	-	All	All	All
Hardware	Supermicro	X10drd-intp	-	All	All	All
Operating System	Supermicro	X10drd-intp Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-intp Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-int Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-int Firmware	3.83	All	All	All
Hardware	Supermicro	X10drd-it	-	All	All	All
Hardware	Supermicro	X10drd-it	-	All	All	All
Hardware	Supermicro	X10drd-itp	-	All	All	All
Hardware	Supermicro	X10drd-itp	-	All	All	All
Operating System	Supermicro	X10drd-itp Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-itp Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-it Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-it Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-i Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-i Firmware	3.83	All	All	All
Hardware	Supermicro	X10drd-l	-	All	All	All
Hardware	Supermicro	X10drd-l	-	All	All	All
Hardware	Supermicro	X10drd-lt	-	All	All	All
Hardware	Supermicro	X10drd-lt	-	All	All	All
Hardware	Supermicro	X10drd-ltp	-	All	All	All
Hardware	Supermicro	X10drd-ltp	-	All	All	All
Operating System	Supermicro	X10drd-ltp Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-ltp Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-lt Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-lt Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-l Firmware	3.83	All	All	All
Operating System	Supermicro	X10drd-l Firmware	3.83	All	All	All
Hardware	Supermicro	X10drff	-	All	All	All

Hardware	Supermicro	X10drff	-	All	All	All
Hardware	Supermicro	X10drff-c	-	All	All	All
Hardware	Supermicro	X10drff-c	-	All	All	All
Hardware	Supermicro	X10drff-cg	-	All	All	All
Hardware	Supermicro	X10drff-cg	-	All	All	All
Operating System	Supermicro	X10drff-cg Firmware	3.83	All	All	All
Operating System	Supermicro	X10drff-cg Firmware	3.83	All	All	All
Hardware	Supermicro	X10drff-ctg	-	All	All	All
Hardware	Supermicro	X10drff-ctg	-	All	All	All
Operating System	Supermicro	X10drff-ctg Firmware	3.83	All	All	All
Operating System	Supermicro	X10drff-ctg Firmware	3.83	All	All	All
Operating System	Supermicro	X10drff-c Firmware	3.83	All	All	All
Operating System	Supermicro	X10drff-c Firmware	3.83	All	All	All
Hardware	Supermicro	X10drff-ig	-	All	All	All
Hardware	Supermicro	X10drff-ig	-	All	All	All
Operating System	Supermicro	X10drff-ig Firmware	3.83	All	All	All
Operating System	Supermicro	X10drff-ig Firmware	3.83	All	All	All
Hardware	Supermicro	X10drff-itg	-	All	All	All
Hardware	Supermicro	X10drff-itg	-	All	All	All
Operating System	Supermicro	X10drff-itg Firmware	3.83	All	All	All
Operating System	Supermicro	X10drff-itg Firmware	3.83	All	All	All
Operating System	Supermicro	X10drff Firmware	3.83	All	All	All
Operating System	Supermicro	X10drff Firmware	3.83	All	All	All
Hardware	Supermicro	X10drfr	-	All	All	All
Hardware	Supermicro	X10drfr	-	All	All	All
Hardware	Supermicro	X10drfr-n	-	All	All	All
Hardware	Supermicro	X10drfr-n	-	All	All	All
Hardware	Supermicro	X10drfr-nt	-	All	All	All
Hardware	Supermicro	X10drfr-nt	-	All	All	All
Operating System	Supermicro	X10drfr-nt Firmware	3.83	All	All	All
Operating System	Supermicro	X10drfr-nt Firmware	3.83	All	All	All
Operating System	Supermicro	X10drfr-n Firmware	3.83	All	All	All
Operating System	Supermicro	X10drfr-n Firmware	3.83	All	All	All
Hardware	Supermicro	X10drfr-t	-	All	All	All
Hardware	Supermicro	X10drfr-t	-	All	All	All

Operating System	Supermicro	X10drfr-t Firmware	3.83	All	All	All
Operating System	Supermicro	X10drfr-t Firmware	3.83	All	All	All
Operating System	Supermicro	X10drfr Firmware	3.83	All	All	All
Operating System	Supermicro	X10drfr Firmware	3.83	All	All	All
Hardware	Supermicro	X10drg-h	-	All	All	All
Hardware	Supermicro	X10drg-h	-	All	All	All
Hardware	Supermicro	X10drg-ht	-	All	All	All
Hardware	Supermicro	X10drg-ht	-	All	All	All
Operating System	Supermicro	X10drg-ht Firmware	3.83	All	All	All
Operating System	Supermicro	X10drg-ht Firmware	3.83	All	All	All
Operating System	Supermicro	X10drg-h Firmware	3.83	All	All	All
Operating System	Supermicro	X10drg-h Firmware	3.83	All	All	All
Hardware	Supermicro	X10drg-o -cpu	-	All	All	All
Operating System	Supermicro	X10drg-o -cpu Firmware	3.83	All	All	All
Hardware	Supermicro	X10drg-ot -cpu	-	All	All	All
Operating System	Supermicro	X10drg-ot -cpu Firmware	3.83	All	All	All
Hardware	Supermicro	X10drg-ot -cpu	-	All	All	All
Hardware	Supermicro	X10drg-ot -cpu	-	All	All	All
Operating System	Supermicro	X10drg-ot -cpu Firmware	3.83	All	All	All
Operating System	Supermicro	X10drg-ot -cpu Firmware	3.83	All	All	All
Hardware	Supermicro	X10drg-o -cpu	-	All	All	All
Hardware	Supermicro	X10drg-o -cpu	-	All	All	All
Operating System	Supermicro	X10drg-o -cpu Firmware	3.83	All	All	All
Operating System	Supermicro	X10drg-o -cpu Firmware	3.83	All	All	All
Hardware	Supermicro	X10drg-q	-	All	All	All
Hardware	Supermicro	X10drg-q	-	All	All	All
Operating System	Supermicro	X10drg-q Firmware	3.83	All	All	All
Operating System	Supermicro	X10drg-q Firmware	3.83	All	All	All
Hardware	Supermicro	X10drh-c	-	All	All	All
Hardware	Supermicro	X10drh-c	-	All	All	All
Hardware	Supermicro	X10drh-cln4	-	All	All	All
Hardware	Supermicro	X10drh-cln4	-	All	All	All
Operating System	Supermicro	X10drh-cln4 Firmware	3.83	All	All	All
Operating System	Supermicro	X10drh-cln4 Firmware	3.83	All	All	All
Hardware	Supermicro	X10drh-ct	-	All	All	All
Hardware	Supermicro	X10drh-ct	-	All	All	All

Hardware	Supermicro	X10DRH-CT	-	All	All	All
Operating System	Supermicro	X10drh-ct Firmware	3.83	All	All	All
Operating System	Supermicro	X10drh-ct Firmware	3.83	All	All	All
Operating System	Supermicro	X10drh-c Firmware	3.83	All	All	All
Operating System	Supermicro	X10drh-c Firmware	3.83	All	All	All
Hardware	Supermicro	X10drh-i	-	All	All	All
Hardware	Supermicro	X10drh-i	-	All	All	All
Hardware	Supermicro	X10drh-iln4	-	All	All	All
Hardware	Supermicro	X10drh-iln4	-	All	All	All
Operating System	Supermicro	X10drh-iln4 Firmware	3.83	All	All	All
Operating System	Supermicro	X10drh-iln4 Firmware	3.83	All	All	All
Hardware	Supermicro	X10drh-it	-	All	All	All
Hardware	Supermicro	X10drh-it	-	All	All	All
Operating System	Supermicro	X10drh-it Firmware	3.83	All	All	All
Operating System	Supermicro	X10drh-it Firmware	3.83	All	All	All
Operating System	Supermicro	X10drh-i Firmware	3.83	All	All	All
Operating System	Supermicro	X10drh-i Firmware	3.83	All	All	All
Hardware	Supermicro	X10dri	-	All	All	All
Hardware	Supermicro	X10dri	-	All	All	All
Hardware	Supermicro	X10dri-ln4	-	All	All	All
Operating System	Supermicro	X10dri-ln4 Firmware	3.83	All	All	All
Hardware	Supermicro	X10dri-ln4	-	All	All	All
Hardware	Supermicro	X10dri-ln4	-	All	All	All
Operating System	Supermicro	X10dri-ln4 Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri-ln4 Firmware	3.83	All	All	All
Hardware	Supermicro	X10dri-t	-	All	All	All
Hardware	Supermicro	X10dri-t	-	All	All	All
Hardware	Supermicro	X10dri-t4	-	All	All	All
Operating System	Supermicro	X10dri-t4 Firmware	3.83	All	All	All
Hardware	Supermicro	X10dri-t4	-	All	All	All
Hardware	Supermicro	X10dri-t4	-	All	All	All
Operating System	Supermicro	X10dri-t4 Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri-t4 Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri-t Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri-t Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri Firmware	3.83	All	All	All

Operating System	Supermicro	X10dri Firmware	3.83	All	All	All
Hardware	Supermicro	X10dri-c	-	All	All	All
Hardware	Supermicro	X10dri-c	-	All	All	All
Hardware	Supermicro	X10dri-ct	-	All	All	All
Hardware	Supermicro	X10dri-ct	-	All	All	All
Operating System	Supermicro	X10dri-ct Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri-ct Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri-c Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri-c Firmware	3.83	All	All	All
Hardware	Supermicro	X10dri-i	-	All	All	All
Hardware	Supermicro	X10dri-i	-	All	All	All
Hardware	Supermicro	X10dri-it	-	All	All	All
Hardware	Supermicro	X10dri-it	-	All	All	All
Operating System	Supermicro	X10dri-it Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri-it Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri-i Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri-i Firmware	3.83	All	All	All
Hardware	Supermicro	X10dri-ln4	-	All	All	All
Hardware	Supermicro	X10dri-ln4	-	All	All	All
Operating System	Supermicro	X10dri-ln4 Firmware	3.83	All	All	All
Operating System	Supermicro	X10dri-ln4 Firmware	3.83	All	All	All
Hardware	Supermicro	X10drs	-	All	All	All
Hardware	Supermicro	X10drs	-	All	All	All
Operating System	Supermicro	X10drs Firmware	3.83	All	All	All
Operating System	Supermicro	X10drs Firmware	3.83	All	All	All
Hardware	Supermicro	X10drt-b	-	All	All	All
Operating System	Supermicro	X10drt-b Firmware	3.83	All	All	All
Hardware	Supermicro	X10drt-b	-	All	All	All
Hardware	Supermicro	X10drt-b	-	All	All	All
Operating System	Supermicro	X10drt-b Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-b Firmware	3.83	All	All	All
Hardware	Supermicro	X10drt-h	-	All	All	All
Hardware	Supermicro	X10drt-h	-	All	All	All
Hardware	Supermicro	X10drt-hibf	-	All	All	All
Hardware	Supermicro	X10drt-hibf	-	All	All	All

Operating System	Supermicro	X10drt-hibf Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-hibf Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-h Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-h Firmware	3.83	All	All	All
Hardware	Supermicro	X10drt-l	-	All	All	All
Hardware	Supermicro	X10drt-l	-	All	All	All
Hardware	Supermicro	X10drt-libf	-	All	All	All
Hardware	Supermicro	X10drt-libf	-	All	All	All
Operating System	Supermicro	X10drt-libf Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-libf Firmware	3.83	All	All	All
Hardware	Supermicro	X10drt-libq	-	All	All	All
Hardware	Supermicro	X10drt-libq	-	All	All	All
Operating System	Supermicro	X10drt-libq Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-libq Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-l Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-l Firmware	3.83	All	All	All
Hardware	Supermicro	X10drt-p	-	All	All	All
Hardware	Supermicro	X10drt-p	-	All	All	All
Hardware	Supermicro	X10drt-pibf	-	All	All	All
Hardware	Supermicro	X10drt-pibf	-	All	All	All
Operating System	Supermicro	X10drt-pibf Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-pibf Firmware	3.83	All	All	All
Hardware	Supermicro	X10drt-pibq	-	All	All	All
Hardware	Supermicro	X10drt-pibq	-	All	All	All
Operating System	Supermicro	X10drt-pibq Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-pibq Firmware	3.83	All	All	All
Hardware	Supermicro	X10drt-ps	-	All	All	All
Hardware	Supermicro	X10drt-ps	-	All	All	All
Operating System	Supermicro	X10drt-ps Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-ps Firmware	3.83	All	All	All
Hardware	Supermicro	X10drt-pt	-	All	All	All
Hardware	Supermicro	X10drt-pt	-	All	All	All
Operating System	Supermicro	X10drt-pt Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-pt Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-p Firmware	3.83	All	All	All
Operating System	Supermicro	X10drt-p Firmware	3.83	All	All	All

Operating System	Supermicro	X10drp-i Firmware	3.83	All	All	All
Hardware	Supermicro	X10dru-i	-	All	All	All
Operating System	Supermicro	X10dru-i Firmware	3.83	All	All	All
Hardware	Supermicro	X10dru-i	-	All	All	All
Hardware	Supermicro	X10dru-i	-	All	All	All
Operating System	Supermicro	X10dru-i Firmware	3.83	All	All	All
Operating System	Supermicro	X10dru-i Firmware	3.83	All	All	All
Hardware	Supermicro	X10dru-x	-	All	All	All
Hardware	Supermicro	X10dru-x	-	All	All	All
Hardware	Supermicro	X10dru-xll	-	All	All	All
Hardware	Supermicro	X10dru-xll	-	All	All	All
Operating System	Supermicro	X10dru-xll Firmware	3.83	All	All	All
Operating System	Supermicro	X10dru-xll Firmware	3.83	All	All	All
Operating System	Supermicro	X10dru-x Firmware	3.83	All	All	All
Operating System	Supermicro	X10dru-x Firmware	3.83	All	All	All
Hardware	Supermicro	X10drw-e	-	All	All	All
Hardware	Supermicro	X10drw-e	-	All	All	All
Hardware	Supermicro	X10drw-et	-	All	All	All
Hardware	Supermicro	X10drw-et	-	All	All	All
Operating System	Supermicro	X10drw-et Firmware	3.83	All	All	All
Operating System	Supermicro	X10drw-et Firmware	3.83	All	All	All
Operating System	Supermicro	X10drw-e Firmware	3.83	All	All	All
Operating System	Supermicro	X10drw-e Firmware	3.83	All	All	All
Hardware	Supermicro	X10drw-i	-	All	All	All
Hardware	Supermicro	X10drw-i	-	All	All	All
Hardware	Supermicro	X10drw-it	-	All	All	All
Hardware	Supermicro	X10drw-it	-	All	All	All
Operating System	Supermicro	X10drw-it Firmware	3.83	All	All	All
Operating System	Supermicro	X10drw-it Firmware	3.83	All	All	All
Operating System	Supermicro	X10drw-i Firmware	3.83	All	All	All
Operating System	Supermicro	X10drw-i Firmware	3.83	All	All	All
Hardware	Supermicro	X10drw-n	-	All	All	All
Hardware	Supermicro	X10drw-n	-	All	All	All
Hardware	Supermicro	X10drw-nt	-	All	All	All
Hardware	Supermicro	X10drw-nt	-	All	All	All
Operating System	Supermicro	X10drw-nt Firmware	3.83	All	All	All

Operating System	Supermicro	X10drw-nt Firmware	3.83	All	All	All
Operating System	Supermicro	X10drw-n Firmware	3.83	All	All	All
Operating System	Supermicro	X10drw-n Firmware	3.83	All	All	All
Hardware	Supermicro	X10drx	-	All	All	All
Hardware	Supermicro	X10drx	-	All	All	All
Operating System	Supermicro	X10drx Firmware	3.83	All	All	All
Operating System	Supermicro	X10drx Firmware	3.83	All	All	All
Hardware	Supermicro	X10dsc	-	All	All	All
Operating System	Supermicro	X10dsc Firmware	3.83	All	All	All
Hardware	Supermicro	X10dsc	-	All	All	All
Hardware	Supermicro	X10dsc	-	All	All	All
Operating System	Supermicro	X10dsc Firmware	3.83	All	All	All
Operating System	Supermicro	X10dsc Firmware	3.83	All	All	All
Hardware	Supermicro	X10dsn-ts	-	All	All	All
Hardware	Supermicro	X10dsn-ts	-	All	All	All
Operating System	Supermicro	X10dsn-ts Firmware	3.83	All	All	All
Operating System	Supermicro	X10dsn-ts Firmware	3.83	All	All	All
Hardware	Supermicro	X10obi-cpu	-	All	All	All
Hardware	Supermicro	X10obi-cpu	-	All	All	All
Operating System	Supermicro	X10obi-cpu Firmware	3.83	All	All	All
Operating System	Supermicro	X10obi-cpu Firmware	3.83	All	All	All
Hardware	Supermicro	X10qbi	-	All	All	All
Hardware	Supermicro	X10qbi	-	All	All	All
Operating System	Supermicro	X10qbi Firmware	3.81	All	All	All
Operating System	Supermicro	X10qbi Firmware	3.81	All	All	All
Hardware	Supermicro	X10qbl	-	All	All	All
Hardware	Supermicro	X10qbl	-	All	All	All
Hardware	Supermicro	X10qbl-4	-	All	All	All
Hardware	Supermicro	X10qbl-4	-	All	All	All
Hardware	Supermicro	X10qbl-4ct	-	All	All	All
Hardware	Supermicro	X10qbl-4ct	-	All	All	All
Operating System	Supermicro	X10qbl-4ct Firmware	3.80	All	All	All
Operating System	Supermicro	X10qbl-4ct Firmware	3.80	All	All	All
Operating System	Supermicro	X10qbl-4 Firmware	3.80	All	All	All
Operating System	Supermicro	X10qbl-4 Firmware	3.80	All	All	All

Hardware	Supermicro	X10qbl-ct	-	All	All	All
Hardware	Supermicro	X10qbl-ct	-	All	All	All
Operating System	Supermicro	X10qbl-ct Firmware	3.80	All	All	All
Operating System	Supermicro	X10qbl-ct Firmware	3.80	All	All	All
Operating System	Supermicro	X10qbl Firmware	3.80	All	All	All
Operating System	Supermicro	X10qbl Firmware	3.80	All	All	All
Hardware	Supermicro	X10qrh	-	All	All	All
Operating System	Supermicro	X10qrh Firmware	3.80	All	All	All
Hardware	Supermicro	X10qrh	-	All	All	All
Hardware	Supermicro	X10qrh	-	All	All	All
Operating System	Supermicro	X10qrh Firmware	3.80	All	All	All
Operating System	Supermicro	X10qrh Firmware	3.80	All	All	All
Hardware	Supermicro	X10sae	-	All	All	All
Hardware	Supermicro	X10sae	-	All	All	All
Operating System	Supermicro	X10sae Firmware	3.83	All	All	All
Operating System	Supermicro	X10sae Firmware	3.83	All	All	All
Hardware	Supermicro	X10sat	-	All	All	All
Hardware	Supermicro	X10sat	-	All	All	All
Operating System	Supermicro	X10sat Firmware	3.83	All	All	All
Operating System	Supermicro	X10sat Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdd-16c-f	-	All	All	All
Hardware	Supermicro	X10sdd-16c-f	-	All	All	All
Operating System	Supermicro	X10sdd-16c-f Firmware	3.68	All	All	All
Operating System	Supermicro	X10sdd-16c-f Firmware	3.68	All	All	All
Hardware	Supermicro	X10sdd-f	-	All	All	All
Hardware	Supermicro	X10sdd-f	-	All	All	All
Operating System	Supermicro	X10sdd-f Firmware	3.68	All	All	All
Operating System	Supermicro	X10sdd-f Firmware	3.68	All	All	All
Hardware	Supermicro	X10sde-df	-	All	All	All
Hardware	Supermicro	X10sde-df	-	All	All	All
Operating System	Supermicro	X10sde-df Firmware	3.68	All	All	All
Operating System	Supermicro	X10sde-df Firmware	3.68	All	All	All
Hardware	Supermicro	X10sdv-12c -tln4f	-	All	All	All
Operating System	Supermicro	X10sdv-12c -tln4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-12c-tln4f	-	All	All	All
Hardware	Supermicro	X10sdv-12c-tln4f	-	All	All	All

Operating System	Supermicro	X10sdv-2c-tln2f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-2c-tp4f	-	All	All	All
Hardware	Supermicro	X10sdv-2c-tp4f	-	All	All	All
Operating System	Supermicro	X10sdv-2c-tp4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-2c-tp4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-2c-tp8f	-	All	All	All
Hardware	Supermicro	X10sdv-2c-tp8f	-	All	All	All
Operating System	Supermicro	X10sdv-2c-tp8f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-2c-tp8f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-4c -tln4f	-	All	All	All
Operating System	Supermicro	X10sdv-4c -tln4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-4c -tp4f	-	All	All	All
Operating System	Supermicro	X10sdv-4c -tp4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-4c-7tp4f	-	All	All	All
Hardware	Supermicro	X10sdv-4c-7tp4f	-	All	All	All
Operating System	Supermicro	X10sdv-4c-7tp4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-4c-7tp4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-4c-tln2f	-	All	All	All
Hardware	Supermicro	X10sdv-4c-tln2f	-	All	All	All
Operating System	Supermicro	X10sdv-4c-tln2f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-4c-tln2f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-4c-tln4f	-	All	All	All
Hardware	Supermicro	X10sdv-4c-tln4f	-	All	All	All
Operating System	Supermicro	X10sdv-4c-tln4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-4c-tln4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-4c -tln4f	-	All	All	All
Hardware	Supermicro	X10sdv-4c -tln4f	-	All	All	All
Operating System	Supermicro	X10sdv-4c -tln4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-4c -tln4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-4c -tp4f	-	All	All	All
Hardware	Supermicro	X10sdv-4c -tp4f	-	All	All	All
Operating System	Supermicro	X10sdv-4c -tp4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-4c -tp4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-6c -tln4f	-	All	All	All
Operating System	Supermicro	X10sdv-6c -tln4f Firmware	3.83	All	All	All

Hardware	Supermicro	X10sdv-6c-tln4f	-	All	All	All
Hardware	Supermicro	X10sdv-6c-tln4f	-	All	All	All
Operating System	Supermicro	X10sdv-6c-tln4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-6c-tln4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-6c -tln4f	-	All	All	All
Hardware	Supermicro	X10sdv-6c -tln4f	-	All	All	All
Operating System	Supermicro	X10sdv-6c -tln4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-6c -tln4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-7tp4f	-	All	All	All
Hardware	Supermicro	X10sdv-7tp4f	-	All	All	All
Operating System	Supermicro	X10sdv-7tp4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-7tp4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-7tp8f	-	All	All	All
Hardware	Supermicro	X10sdv-7tp8f	-	All	All	All
Operating System	Supermicro	X10sdv-7tp8f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-7tp8f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-8c -ln2f	-	All	All	All
Operating System	Supermicro	X10sdv-8c -ln2f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-8c-tln4f	-	All	All	All
Hardware	Supermicro	X10sdv-8c-tln4f	-	All	All	All
Hardware	Supermicro	X10sdv-8c-tln4f	-	All	All	All
Operating System	Supermicro	X10sdv-8c-tln4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-8c-tln4f	-	All	All	All
Hardware	Supermicro	X10sdv-8c-tln4f	-	All	All	All
Operating System	Supermicro	X10sdv-8c-tln4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-8c-tln4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-8c-tln4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-8c-tln4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-8c -ln2f	-	All	All	All
Hardware	Supermicro	X10sdv-8c -ln2f	-	All	All	All
Operating System	Supermicro	X10sdv-8c -ln2f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-8c -ln2f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-f	-	All	All	All
Hardware	Supermicro	X10sdv-f	-	All	All	All
Operating System	Supermicro	X10sdv-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-f Firmware	3.83	All	All	All

Hardware	Supermicro	X10sdv-tln4f	-	All	All	All
Hardware	Supermicro	X10sdv-tln4f	-	All	All	All
Operating System	Supermicro	X10sdv-tln4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-tln4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sdv-tp8f	-	All	All	All
Hardware	Supermicro	X10sdv-tp8f	-	All	All	All
Operating System	Supermicro	X10sdv-tp8f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sdv-tp8f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sl7-f	-	All	All	All
Hardware	Supermicro	X10sl7-f	-	All	All	All
Operating System	Supermicro	X10sl7-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sl7-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sla-f	-	All	All	All
Hardware	Supermicro	X10sla-f	-	All	All	All
Operating System	Supermicro	X10sla-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sla-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sld-f	-	All	All	All
Hardware	Supermicro	X10sld-f	-	All	All	All
Operating System	Supermicro	X10sld-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sld-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sld-hf	-	All	All	All
Hardware	Supermicro	X10sld-hf	-	All	All	All
Operating System	Supermicro	X10sld-hf Firmware	3.83	All	All	All
Operating System	Supermicro	X10sld-hf Firmware	3.83	All	All	All
Hardware	Supermicro	X10sle-df	-	All	All	All
Hardware	Supermicro	X10sle-df	-	All	All	All
Operating System	Supermicro	X10sle-df Firmware	3.83	All	All	All
Operating System	Supermicro	X10sle-df Firmware	3.83	All	All	All
Hardware	Supermicro	X10sle-f	-	All	All	All
Hardware	Supermicro	X10sle-f	-	All	All	All
Operating System	Supermicro	X10sle-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sle-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sle-hf	-	All	All	All
Hardware	Supermicro	X10sle-hf	-	All	All	All
Operating System	Supermicro	X10sle-hf Firmware	3.83	All	All	All

Operating System	Supermicro	X10sle-hf Firmware	3.83	All	All	All
Hardware	Supermicro	X10slh-f	-	All	All	All
Hardware	Supermicro	X10slh-f	-	All	All	All
Operating System	Supermicro	X10slh-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10slh-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sll -f	-	All	All	All
Operating System	Supermicro	X10sll -f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sll-f	-	All	All	All
Hardware	Supermicro	X10sll-f	-	All	All	All
Operating System	Supermicro	X10sll-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sll-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sll-s	-	All	All	All
Hardware	Supermicro	X10sll-s	-	All	All	All
Hardware	Supermicro	X10sll-sf	-	All	All	All
Hardware	Supermicro	X10sll-sf	-	All	All	All
Operating System	Supermicro	X10sll-sf Firmware	3.83	All	All	All
Operating System	Supermicro	X10sll-sf Firmware	3.83	All	All	All
Operating System	Supermicro	X10sll-s Firmware	3.83	All	All	All
Operating System	Supermicro	X10sll-s Firmware	3.83	All	All	All
Hardware	Supermicro	X10sll -f	-	All	All	All
Hardware	Supermicro	X10sll -f	-	All	All	All
Operating System	Supermicro	X10sll -f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sll -f Firmware	3.83	All	All	All
Hardware	Supermicro	X10slm -f	-	All	All	All
Operating System	Supermicro	X10slm -f Firmware	3.83	All	All	All
Hardware	Supermicro	X10slm -In4f	-	All	All	All
Operating System	Supermicro	X10slm -In4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10slm-f	-	All	All	All
Hardware	Supermicro	X10slm-f	-	All	All	All
Operating System	Supermicro	X10slm-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10slm-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10slm -f	-	All	All	All
Hardware	Supermicro	X10slm -f	-	All	All	All
Operating System	Supermicro	X10slm -f Firmware	3.83	All	All	All
Operating System	Supermicro	X10slm -f Firmware	3.83	All	All	All

Hardware	Supermicro	X10slm -ln4f	-	All	All	All
Hardware	Supermicro	X10slm -ln4f	-	All	All	All
Operating System	Supermicro	X10slm -ln4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10slm -ln4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10slx-f	-	All	All	All
Hardware	Supermicro	X10slx-f	-	All	All	All
Operating System	Supermicro	X10slx-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10slx-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sra	-	All	All	All
Hardware	Supermicro	X10sra	-	All	All	All
Hardware	Supermicro	X10sra-f	-	All	All	All
Hardware	Supermicro	X10sra-f	-	All	All	All
Operating System	Supermicro	X10sra-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sra-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sra Firmware	3.83	All	All	All
Operating System	Supermicro	X10sra Firmware	3.83	All	All	All
Hardware	Supermicro	X10srd-f	-	All	All	All
Hardware	Supermicro	X10srd-f	-	All	All	All
Operating System	Supermicro	X10srd-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10srd-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10srg-f	-	All	All	All
Hardware	Supermicro	X10srg-f	-	All	All	All
Operating System	Supermicro	X10srg-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10srg-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10srh-cf	-	All	All	All
Hardware	Supermicro	X10srh-cf	-	All	All	All
Operating System	Supermicro	X10srh-cf Firmware	3.83	All	All	All
Operating System	Supermicro	X10srh-cf Firmware	3.83	All	All	All
Hardware	Supermicro	X10srh-cln4f	-	All	All	All
Hardware	Supermicro	X10srh-cln4f	-	All	All	All
Operating System	Supermicro	X10srh-cln4f Firmware	3.83	All	All	All
Operating System	Supermicro	X10srh-cln4f Firmware	3.83	All	All	All
Hardware	Supermicro	X10sri-f	-	All	All	All
Hardware	Supermicro	X10sri-f	-	All	All	All
Operating System	Supermicro	X10sri-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10sri-f Firmware	3.83	All	All	All

Hardware	Supermicro	X10srl-f	-	All	All	All
Hardware	Supermicro	X10srl-f	-	All	All	All
Operating System	Supermicro	X10srl-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10srl-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10srm-f	-	All	All	All
Hardware	Supermicro	X10srm-f	-	All	All	All
Operating System	Supermicro	X10srm-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10srm-f Firmware	3.83	All	All	All
Hardware	Supermicro	X10srm-tf	-	All	All	All
Hardware	Supermicro	X10srm-tf	-	All	All	All
Operating System	Supermicro	X10srm-tf Firmware	3.83	All	All	All
Operating System	Supermicro	X10srm-tf Firmware	3.83	All	All	All
Hardware	Supermicro	X10srw-f	-	All	All	All
Hardware	Supermicro	X10srw-f	-	All	All	All
Operating System	Supermicro	X10srw-f Firmware	3.83	All	All	All
Operating System	Supermicro	X10srw-f Firmware	3.83	All	All	All
Hardware	Supermicro	X11dac	-	All	All	All
Hardware	Supermicro	X11dac	-	All	All	All
Operating System	Supermicro	X11dac Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dac Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dai-n	-	All	All	All
Hardware	Supermicro	X11dai-n	-	All	All	All
Operating System	Supermicro	X11dai-n Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dai-n Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11ddw-l	-	All	All	All
Hardware	Supermicro	X11ddw-l	-	All	All	All
Operating System	Supermicro	X11ddw-l Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11ddw-l Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11ddw-nt	-	All	All	All
Hardware	Supermicro	X11ddw-nt	-	All	All	All
Operating System	Supermicro	X11ddw-nt Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11ddw-nt Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dgo-t	-	All	All	All
Hardware	Supermicro	X11dgo-t	-	All	All	All
Operating System	Supermicro	X11dgo-t Firmware	1.71.5	All	All	All

Operating System	Supermicro	X11dgo-t Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dgg	-	All	All	All
Hardware	Supermicro	X11dgg	-	All	All	All
Operating System	Supermicro	X11dgg Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dgg Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpff-sn	-	All	All	All
Hardware	Supermicro	X11dpff-sn	-	All	All	All
Operating System	Supermicro	X11dpff-sn Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpff-sn Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpfr-s	-	All	All	All
Hardware	Supermicro	X11dpfr-s	-	All	All	All
Hardware	Supermicro	X11dpfr-sn	-	All	All	All
Hardware	Supermicro	X11dpfr-sn	-	All	All	All
Operating System	Supermicro	X11dpfr-sn Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpfr-sn Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpfr-s Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpfr-s Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpg-ot-cpu	-	All	All	All
Hardware	Supermicro	X11dpg-ot-cpu	-	All	All	All
Operating System	Supermicro	X11dpg-ot-cpu Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpg-ot-cpu Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpg-qt	-	All	All	All
Hardware	Supermicro	X11dpg-qt	-	All	All	All
Operating System	Supermicro	X11dpg-qt Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpg-qt Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpg-sn	-	All	All	All
Hardware	Supermicro	X11dpg-sn	-	All	All	All
Operating System	Supermicro	X11dpg-sn Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpg-sn Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dph-i	-	All	All	All
Hardware	Supermicro	X11dph-i	-	All	All	All
Operating System	Supermicro	X11dph-i Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dph-i Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dph-t	-	All	All	All
Hardware	Supermicro	X11dph-t	-	All	All	All
Hardware	Supermicro	X11dph-t	-	All	All	All

Hardware	Supermicro	X11dph-tq	-	All	All	All
Hardware	Supermicro	X11dph-tq	-	All	All	All
Operating System	Supermicro	X11dph-tq Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dph-tq Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dph-t Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dph-t Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpi-n	-	All	All	All
Hardware	Supermicro	X11dpi-n	-	All	All	All
Hardware	Supermicro	X11dpi-nt	-	All	All	All
Hardware	Supermicro	X11dpi-nt	-	All	All	All
Operating System	Supermicro	X11dpi-nt Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpi-nt Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpi-n Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpi-n Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpl-i	-	All	All	All
Hardware	Supermicro	X11dpl-i	-	All	All	All
Operating System	Supermicro	X11dpl-i Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpl-i Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dps-re	-	All	All	All
Hardware	Supermicro	X11dps-re	-	All	All	All
Operating System	Supermicro	X11dps-re Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dps-re Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpt-b	-	All	All	All
Hardware	Supermicro	X11dpt-b	-	All	All	All
Hardware	Supermicro	X11dpt-bh	-	All	All	All
Hardware	Supermicro	X11dpt-bh	-	All	All	All
Operating System	Supermicro	X11dpt-bh Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpt-bh Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpt-b Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpt-b Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpt-l	-	All	All	All
Hardware	Supermicro	X11dpt-l	-	All	All	All
Operating System	Supermicro	X11dpt-l Firmware	3.74	All	All	All
Operating System	Supermicro	X11dpt-l Firmware	3.74	All	All	All
Hardware	Supermicro	X11dpt-ps	-	All	All	All
Hardware	Supermicro	X11dpt-ps	-	All	All	All

Operating System	Supermicro	X11dpt-ps Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpt-ps Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpu	-	All	All	All
Hardware	Supermicro	X11dpu	-	All	All	All
Hardware	Supermicro	X11dpu-v	-	All	All	All
Hardware	Supermicro	X11dpu-v	-	All	All	All
Operating System	Supermicro	X11dpu-v Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpu-v Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpu-x	-	All	All	All
Hardware	Supermicro	X11dpu-x	-	All	All	All
Hardware	Supermicro	X11dpu-xll	-	All	All	All
Hardware	Supermicro	X11dpu-xll	-	All	All	All
Operating System	Supermicro	X11dpu-xll Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpu-xll Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpu-x Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpu-x Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpu-z	-	All	All	All
Operating System	Supermicro	X11dpu-z Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpu-ze	-	All	All	All
Operating System	Supermicro	X11dpu-ze Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpu-ze	-	All	All	All
Hardware	Supermicro	X11dpu-ze	-	All	All	All
Operating System	Supermicro	X11dpu-ze Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpu-ze Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpu-z	-	All	All	All
Hardware	Supermicro	X11dpu-z	-	All	All	All
Operating System	Supermicro	X11dpu-z Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpu-z Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpu Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpu Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dpx-t	-	All	All	All
Hardware	Supermicro	X11dpx-t	-	All	All	All
Operating System	Supermicro	X11dpx-t Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dpx-t Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dsc	-	All	All	All

Operating System	Supermicro	X11dsc Firmware	1.74	All	All	All
Hardware	Supermicro	X11dsc	-	All	All	All
Hardware	Supermicro	X11dsc	-	All	All	All
Operating System	Supermicro	X11dsc Firmware	1.74	All	All	All
Operating System	Supermicro	X11dsc Firmware	1.74	All	All	All
Hardware	Supermicro	X11dsf-e	-	All	All	All
Hardware	Supermicro	X11dsf-e	-	All	All	All
Operating System	Supermicro	X11dsf-e Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dsf-e Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11dsn-ts	-	All	All	All
Hardware	Supermicro	X11dsn-ts	-	All	All	All
Hardware	Supermicro	X11dsn-tsq	-	All	All	All
Hardware	Supermicro	X11dsn-tsq	-	All	All	All
Operating System	Supermicro	X11dsn-tsq Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dsn-tsq Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dsn-ts Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11dsn-ts Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11opi-cpu	-	All	All	All
Hardware	Supermicro	X11opi-cpu	-	All	All	All
Operating System	Supermicro	X11opi-cpu Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11opi-cpu Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11qph	-	All	All	All
Operating System	Supermicro	X11qph Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11qph	-	All	All	All
Hardware	Supermicro	X11qph	-	All	All	All
Operating System	Supermicro	X11qph Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11qph Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11sca	-	All	All	All
Hardware	Supermicro	X11sca	-	All	All	All
Hardware	Supermicro	X11sca-f	-	All	All	All
Hardware	Supermicro	X11sca-f	-	All	All	All
Operating System	Supermicro	X11sca-f Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11sca-f Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11sca-w	-	All	All	All
Hardware	Supermicro	X11sca-w	-	All	All	All
Operating System	Supermicro	X11sca-w Firmware	1.71.5	All	All	All

Operating System	Supermicro	X11sca-w Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11sca-w Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11sca Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11sca Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11scd-f	-	All	All	All
Hardware	Supermicro	X11scd-f	-	All	All	All
Operating System	Supermicro	X11scd-f Firmware	3.68	All	All	All
Operating System	Supermicro	X11scd-f Firmware	3.68	All	All	All
Hardware	Supermicro	X11sch-f	-	All	All	All
Hardware	Supermicro	X11sch-f	-	All	All	All
Operating System	Supermicro	X11sch-f Firmware	1.23.2	All	All	All
Operating System	Supermicro	X11sch-f Firmware	1.23.2	All	All	All
Hardware	Supermicro	X11sch-In4f	-	All	All	All
Hardware	Supermicro	X11sch-In4f	-	All	All	All
Operating System	Supermicro	X11sch-In4f Firmware	1.23.2	All	All	All
Operating System	Supermicro	X11sch-In4f Firmware	1.23.2	All	All	All
Hardware	Supermicro	X11scl-f	-	All	All	All
Hardware	Supermicro	X11scl-f	-	All	All	All
Operating System	Supermicro	X11scl-f Firmware	1.23.2	All	All	All
Operating System	Supermicro	X11scl-f Firmware	1.23.2	All	All	All
Hardware	Supermicro	X11scl-if	-	All	All	All
Hardware	Supermicro	X11scl-if	-	All	All	All
Operating System	Supermicro	X11scl-if Firmware	1.23.2	All	All	All
Operating System	Supermicro	X11scl-if Firmware	1.23.2	All	All	All
Hardware	Supermicro	X11scl-In4f	-	All	All	All
Hardware	Supermicro	X11scl-In4f	-	All	All	All
Operating System	Supermicro	X11scl-In4f Firmware	1.23.2	All	All	All
Operating System	Supermicro	X11scl-In4f Firmware	1.23.2	All	All	All
Hardware	Supermicro	X11scm-f	-	All	All	All
Hardware	Supermicro	X11scm-f	-	All	All	All
Operating System	Supermicro	X11scm-f Firmware	1.23.2	All	All	All
Operating System	Supermicro	X11scm-f Firmware	1.23.2	All	All	All
Hardware	Supermicro	X11scm-In8f	-	All	All	All
Hardware	Supermicro	X11scm-In8f	-	All	All	All
Operating System	Supermicro	X11scm-In8f Firmware	1.23.2	All	All	All
Operating System	Supermicro	X11scm-In8f Firmware	1.23.2	All	All	All

Hardware	Supermicro	X11scw-f	-	All	All	All
Hardware	Supermicro	X11scw-f	-	All	All	All
Operating System	Supermicro	X11scw-f Firmware	3.75.00	All	All	All
Operating System	Supermicro	X11scw-f Firmware	3.75.00	All	All	All
Hardware	Supermicro	X11sdd-18c-f	-	All	All	All
Hardware	Supermicro	X11sdd-18c-f	-	All	All	All
Operating System	Supermicro	X11sdd-18c-f Firmware	3.68	All	All	All
Operating System	Supermicro	X11sdd-18c-f Firmware	3.68	All	All	All
Hardware	Supermicro	X11sdd-8c-f	-	All	All	All
Hardware	Supermicro	X11sdd-8c-f	-	All	All	All
Operating System	Supermicro	X11sdd-8c-f Firmware	3.68	All	All	All
Operating System	Supermicro	X11sdd-8c-f Firmware	3.68	All	All	All
Hardware	Supermicro	X11sds-12c	-	All	All	All
Hardware	Supermicro	X11sds-12c	-	All	All	All
Operating System	Supermicro	X11sds-12c Firmware	3.74.2	All	All	All
Operating System	Supermicro	X11sds-12c Firmware	3.74.2	All	All	All
Hardware	Supermicro	X11sds-16c	-	All	All	All
Hardware	Supermicro	X11sds-16c	-	All	All	All
Operating System	Supermicro	X11sds-16c Firmware	3.74.2	All	All	All
Operating System	Supermicro	X11sds-16c Firmware	3.74.2	All	All	All
Hardware	Supermicro	X11sds-8c	-	All	All	All
Hardware	Supermicro	X11sds-8c	-	All	All	All
Operating System	Supermicro	X11sds-8c Firmware	3.74.2	All	All	All
Operating System	Supermicro	X11sds-8c Firmware	3.74.2	All	All	All
Hardware	Supermicro	X11spa-t	-	All	All	All
Hardware	Supermicro	X11spa-t	-	All	All	All
Hardware	Supermicro	X11spa-tf	-	All	All	All
Hardware	Supermicro	X11spa-tf	-	All	All	All
Operating System	Supermicro	X11spa-tf Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11spa-tf Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11spa-t Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11spa-t Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11spg-tf	-	All	All	All
Hardware	Supermicro	X11spg-tf	-	All	All	All
Operating System	Supermicro	X11spg-tf Firmware	1.71.6	All	All	All

Operating System	Supermicro	X11spg-tf Firmware	1.71.6	All	All	All
Hardware	Supermicro	X11sph-nctf	-	All	All	All
Hardware	Supermicro	X11sph-nctf	-	All	All	All
Operating System	Supermicro	X11sph-nctf Firmware	1.71.6	All	All	All
Operating System	Supermicro	X11sph-nctf Firmware	1.71.6	All	All	All
Hardware	Supermicro	X11sph-nctpf	-	All	All	All
Hardware	Supermicro	X11sph-nctpf	-	All	All	All
Operating System	Supermicro	X11sph-nctpf Firmware	1.71.6	All	All	All
Operating System	Supermicro	X11sph-nctpf Firmware	1.71.6	All	All	All
Hardware	Supermicro	X11spi-tf	-	All	All	All
Hardware	Supermicro	X11spi-tf	-	All	All	All
Operating System	Supermicro	X11spi-tf Firmware	1.71.6	All	All	All
Operating System	Supermicro	X11spi-tf Firmware	1.71.6	All	All	All
Hardware	Supermicro	X11spl-f	-	All	All	All
Hardware	Supermicro	X11spl-f	-	All	All	All
Operating System	Supermicro	X11spl-f Firmware	1.71.6	All	All	All
Operating System	Supermicro	X11spl-f Firmware	1.71.6	All	All	All
Hardware	Supermicro	X11spm-f	-	All	All	All
Hardware	Supermicro	X11spm-f	-	All	All	All
Operating System	Supermicro	X11spm-f Firmware	1.71.6	All	All	All
Operating System	Supermicro	X11spm-f Firmware	1.71.6	All	All	All
Hardware	Supermicro	X11spm-tf	-	All	All	All
Hardware	Supermicro	X11spm-tf	-	All	All	All
Operating System	Supermicro	X11spm-tf Firmware	1.71.6	All	All	All
Operating System	Supermicro	X11spm-tf Firmware	1.71.6	All	All	All
Hardware	Supermicro	X11spm-tpf	-	All	All	All
Hardware	Supermicro	X11spm-tpf	-	All	All	All
Operating System	Supermicro	X11spm-tpf Firmware	1.71.6	All	All	All
Operating System	Supermicro	X11spm-tpf Firmware	1.71.6	All	All	All
Hardware	Supermicro	X11spw-ctf	-	All	All	All
Hardware	Supermicro	X11spw-ctf	-	All	All	All
Operating System	Supermicro	X11spw-ctf Firmware	1.71.6	All	All	All
Operating System	Supermicro	X11spw-ctf Firmware	1.71.6	All	All	All
Hardware	Supermicro	X11spw-tf	-	All	All	All
Hardware	Supermicro	X11spw-tf	-	All	All	All
Operating System	Supermicro	X11spw-tf Firmware	1.71.6	All	All	All

Operating System	Supermicro	X11spw-tf Firmware	1.71.0	All	All	All
Operating System	Supermicro	X11spw-tf Firmware	1.71.6	All	All	All
Hardware	Supermicro	X11sri-if	-	All	All	All
Hardware	Supermicro	X11sri-if	-	All	All	All
Operating System	Supermicro	X11sri-if Firmware	3.75.00	All	All	All
Operating System	Supermicro	X11sri-if Firmware	3.75.00	All	All	All
Hardware	Supermicro	X11srl-f	-	All	All	All
Hardware	Supermicro	X11srl-f	-	All	All	All
Operating System	Supermicro	X11srl-f Firmware	3.74.2	All	All	All
Operating System	Supermicro	X11srl-f Firmware	3.74.2	All	All	All
Hardware	Supermicro	X11srm-f	-	All	All	All
Hardware	Supermicro	X11srm-f	-	All	All	All
Operating System	Supermicro	X11srm-f Firmware	1.31.1	All	All	All
Operating System	Supermicro	X11srm-f Firmware	1.31.1	All	All	All
Hardware	Supermicro	X11srm-vf	-	All	All	All
Hardware	Supermicro	X11srm-vf	-	All	All	All
Operating System	Supermicro	X11srm-vf Firmware	1.31.1	All	All	All
Operating System	Supermicro	X11srm-vf Firmware	1.31.1	All	All	All
Hardware	Supermicro	X11ssd-f	-	All	All	All
Hardware	Supermicro	X11ssd-f	-	All	All	All
Operating System	Supermicro	X11ssd-f Firmware	3.68	All	All	All
Operating System	Supermicro	X11ssd-f Firmware	3.68	All	All	All
Hardware	Supermicro	X11sse-f	-	All	All	All
Hardware	Supermicro	X11sse-f	-	All	All	All
Operating System	Supermicro	X11sse-f Firmware	3.68	All	All	All
Operating System	Supermicro	X11sse-f Firmware	3.68	All	All	All
Hardware	Supermicro	X11ssh-ctf	-	All	All	All
Hardware	Supermicro	X11ssh-ctf	-	All	All	All
Operating System	Supermicro	X11ssh-ctf Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssh-ctf Firmware	1.56	All	All	All
Hardware	Supermicro	X11ssh-f	-	All	All	All
Hardware	Supermicro	X11ssh-f	-	All	All	All
Operating System	Supermicro	X11ssh-f Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssh-f Firmware	1.56	All	All	All
Hardware	Supermicro	X11ssh-gf-1585	-	All	All	All
Hardware	Supermicro	X11ssh-gf-1585	-	All	All	All

Hardware	Supermicro	X11ssh-gf-1585l	-	All	All	All
Hardware	Supermicro	X11ssh-gf-1585l	-	All	All	All
Operating System	Supermicro	X11ssh-gf-1585l Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssh-gf-1585l Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssh-gf-1585 Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssh-gf-1585 Firmware	1.56	All	All	All
Hardware	Supermicro	X11ssh-gtf-1585	-	All	All	All
Hardware	Supermicro	X11ssh-gtf-1585	-	All	All	All
Hardware	Supermicro	X11ssh-gtf-1585l	-	All	All	All
Hardware	Supermicro	X11ssh-gtf-1585l	-	All	All	All
Operating System	Supermicro	X11ssh-gtf-1585l Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssh-gtf-1585l Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssh-gtf-1585 Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssh-gtf-1585 Firmware	1.56	All	All	All
Hardware	Supermicro	X11ssh-ln4f	-	All	All	All
Hardware	Supermicro	X11ssh-ln4f	-	All	All	All
Operating System	Supermicro	X11ssh-ln4f Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssh-ln4f Firmware	1.56	All	All	All
Hardware	Supermicro	X11ssh-tf	-	All	All	All
Hardware	Supermicro	X11ssh-tf	-	All	All	All
Operating System	Supermicro	X11ssh-tf Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssh-tf Firmware	1.56	All	All	All
Hardware	Supermicro	X11ssi-ln4f	-	All	All	All
Hardware	Supermicro	X11ssi-ln4f	-	All	All	All
Operating System	Supermicro	X11ssi-ln4f Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11ssi-ln4f Firmware	1.71.5	All	All	All
Hardware	Supermicro	X11ssl	-	All	All	All
Hardware	Supermicro	X11ssl	-	All	All	All
Hardware	Supermicro	X11ssl-cf	-	All	All	All
Hardware	Supermicro	X11ssl-cf	-	All	All	All
Operating System	Supermicro	X11ssl-cf Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssl-cf Firmware	1.56	All	All	All
Hardware	Supermicro	X11ssl-f	-	All	All	All
Hardware	Supermicro	X11ssl-f	-	All	All	All
Operating System	Supermicro	X11ssl-f Firmware	1.56	All	All	All

Operating System	Supermicro	X11ssl-f Firmware	1.56	All	All	All
Hardware	Supermicro	X11ssl-nf	-	All	All	All
Hardware	Supermicro	X11ssl-nf	-	All	All	All
Operating System	Supermicro	X11ssl-nf Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssl-nf Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssl Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssl Firmware	1.56	All	All	All
Hardware	Supermicro	X11ssm	-	All	All	All
Hardware	Supermicro	X11ssm	-	All	All	All
Hardware	Supermicro	X11ssm-f	-	All	All	All
Hardware	Supermicro	X11ssm-f	-	All	All	All
Operating System	Supermicro	X11ssm-f Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssm-f Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssm Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssm Firmware	1.56	All	All	All
Hardware	Supermicro	X11ssw-4tf	-	All	All	All
Hardware	Supermicro	X11ssw-4tf	-	All	All	All
Operating System	Supermicro	X11ssw-4tf Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssw-4tf Firmware	1.56	All	All	All
Hardware	Supermicro	X11ssw-f	-	All	All	All
Hardware	Supermicro	X11ssw-f	-	All	All	All
Operating System	Supermicro	X11ssw-f Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11ssw-f Firmware	3.85.00	All	All	All
Operating System	Supermicro	X11ssw-f Firmware	1.71.5	All	All	All
Operating System	Supermicro	X11ssw-f Firmware	3.85.00	All	All	All
Hardware	Supermicro	X11ssw-tf	-	All	All	All
Hardware	Supermicro	X11ssw-tf	-	All	All	All
Operating System	Supermicro	X11ssw-tf Firmware	1.56	All	All	All
Operating System	Supermicro	X11ssw-tf Firmware	1.56	All	All	All

References

Reference	Source	Link	Tags
GitHub - eclipsium/USBAnywhere	MISC	github.com	Third Party Advisory
BMC/IPMI Security Vulnerability Supermicro	MISC	www.supermicro.com	Vendor Advisory
Virtual Media Vulnerability in BMC Opens Servers to Remote Attack - Eclipsium	MISC	eclipsium.com	Mitigation, Third Party
CVE Program record	CVE.ORG	www.cve.org	canonical

No vendor comments have been submitted for this CVE.

There are currently no legacy QID mappings associated with this CVE.

© [CVE.report](https://cve.report) 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](https://www.mitre.org) and the authoritative source of CVE content is [MITRE's CVE web site](https://www.mitre.org/cve). This site includes MITRE data granted under the following [license](https://www.mitre.org/cve).

CVE.report and Source URL Uptime Status status.cve.report