



# CVE-2019-19417

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

## Summary

<b>CVE</b>	CVE-2019-19417
<b>State</b>	PUBLIC
<b>Assigner</b>	psirt@huawei.com
<b>Source Priority</b>	CVE Program / NVD first with legacy fallback
<b>Published</b>	2020-07-08 17:15:00 UTC
<b>Updated</b>	2021-07-21 11:39:00 UTC
<b>Description</b>	The SIP module of some Huawei products have a denial of service (DoS) vulnerability. A remote attacker could exploit this

## Risk And Classification

**Problem Types:** CWE-119 | CWE-20

## NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware	<a href="#">Huawei</a>	<a href="#">Ar120-s</a>	-	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Ar120-s</a>	-	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ar120-s Firmware</a>	v200r006c10	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ar120-s Firmware</a>	v200r007c00	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ar120-s Firmware</a>	v200r008c20	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ar120-s Firmware</a>	v200r008c30	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ar120-s Firmware</a>	v200r006c10	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ar120-s Firmware</a>	v200r007c00	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ar120-s Firmware</a>	v200r008c20	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ar120-s Firmware</a>	v200r008c30	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Ar1200</a>	-	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Ar1200</a>	-	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Ar1200-s</a>	-	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Ar1200-s</a>	-	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ar1200-s Firmware</a>	v200r006c10	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ar1200-s Firmware</a>	v200r007c00	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ar1200-s Firmware</a>	v200r008c20	All	All	All

Operating System	Huawei	Ar1200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar1200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar1200 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar150	-	All	All	All
Hardware	Huawei	Ar150	-	All	All	All
Hardware	Huawei	Ar150-s	-	All	All	All
Hardware	Huawei	Ar150-s	-	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r006c10spc300	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar150-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c02	All	All	All

Operating System	Huawei	Ar150 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar150 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar160	-	All	All	All
Hardware	Huawei	Ar160	-	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c12	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r006c12	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar160 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar200	-	All	All	All
Hardware	Huawei	Ar200	-	All	All	All
Hardware	Huawei	Ar200-s	-	All	All	All
Hardware	Huawei	Ar200-s	-	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200-s Firmware	v200r008c20	All	All	All

Operating System	Huawei	Ar200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar200 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar2200	-	All	All	All
Hardware	Huawei	Ar2200	-	All	All	All
Hardware	Huawei	Ar2200-s	-	All	All	All
Hardware	Huawei	Ar2200-s	-	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200-s Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c16pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r006c16pwe	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r007c01	All	All	All

Operating System	Huawei	Ar2200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar2200 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar3200	-	All	All	All
Hardware	Huawei	Ar3200	-	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c11	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r006c11	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c00	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c10	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar3200 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ar3600	-	All	All	All
Hardware	Huawei	Ar3600	-	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r007c01	All	All	All
Operating System	Huawei	Ar3600 Firmware	v200r008c20	All	All	All
Hardware	Huawei	Ar510	-	All	All	All
Hardware	Huawei	Ar510	-	All	All	All

Operating System	Huawei	Ar510 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c12	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c15	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c16	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c17	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc180t	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c12	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c13	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c15	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c16	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r006c17	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc180t	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc600	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spc900	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r007c00spcb00	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Ar510 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Dp300	-	All	All	All
Hardware	Huawei	Dp300	-	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Dp300 Firmware	v500r002c00	All	All	All
Hardware	Huawei	Espace U1910	-	All	All	All
Hardware	Huawei	Espace U1910	-	All	All	All
Operating System	Huawei	Espace U1910 Firmware	v100r001c20spc300	All	All	All
Operating System	Huawei	Espace U1910 Firmware	v100r001c20spc400	All	All	All
Operating System	Huawei	Espace U1910 Firmware	v100r001c20spc500	All	All	All
Operating System	Huawei	Espace U1910 Firmware	v100r001c20spc600	All	All	All
Operating System	Huawei	Espace U1910 Firmware	v100r001c20sph703	All	All	All
Operating System	Huawei	Espace U1910 Firmware	v200r002c00	All	All	All





Operating System	Huawei	Espace U1960 Firmware	v200r003c20	All	All	All
Operating System	Huawei	Espace U1960 Firmware	v200r003c30	All	All	All
Hardware	Huawei	Espace U1980	-	All	All	All
Hardware	Huawei	Espace U1980	-	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c01spc500t	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20spc300	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20spc400	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20spc500t	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20spc502	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20spc600	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20sph309	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20sph703	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v200r003c20	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v200r003c30	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c01spc500t	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20spc300	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20spc400	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20spc500t	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20spc502	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20spc600	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20sph309	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v100r001c20sph703	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v200r003c20	All	All	All
Operating System	Huawei	Espace U1980 Firmware	v200r003c30	All	All	All
Hardware	Huawei	Espace U1981	-	All	All	All
Hardware	Huawei	Espace U1981	-	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20spc300	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20spc400	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20spc500	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20spc600	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20spc700	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20sph702	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20sph703	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20	All	All	All

Operating System	Huawei	Espace U1981 Firmware	v100r001c30	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v200r003c20	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v200r003c30	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20spc300	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20spc400	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20spc500	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20spc600	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20spc700	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20sph702	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c20sph703	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v100r001c30	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v200r003c20	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v200r003c30	All	All	All
Hardware	Huawei	Ips Module	-	All	All	All
Hardware	Huawei	Ips Module	-	All	All	All
Operating System	Huawei	Ips Module Firmware	v100r001c10	All	All	All
Operating System	Huawei	Ips Module Firmware	v100r001c20	All	All	All
Operating System	Huawei	Ips Module Firmware	v100r001c30	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c00	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c30	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c50	All	All	All
Operating System	Huawei	Ips Module Firmware	v100r001c10	All	All	All
Operating System	Huawei	Ips Module Firmware	v100r001c20	All	All	All
Operating System	Huawei	Ips Module Firmware	v100r001c30	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c00	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c30	All	All	All
Operating System	Huawei	Ips Module Firmware	v500r001c50	All	All	All
Hardware	Huawei	Netengine16ex	-	All	All	All
Hardware	Huawei	Netengine16ex	-	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r006c10	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c20	All	All	All

Operating System	Huawei	Netengine16ex Firmware	v200r008c30	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r006c10	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r007c00	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c20	All	All	All
Operating System	Huawei	Netengine16ex Firmware	v200r008c30	All	All	All
Hardware	Huawei	Ngfw Module	-	All	All	All
Hardware	Huawei	Ngfw Module	-	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c10	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c20	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c30	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r001c00	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r002c00	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r002c10	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c10	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c20	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v100r001c30	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r001c00	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r002c00	All	All	All
Operating System	Huawei	Ngfw Module Firmware	v500r002c10	All	All	All
Hardware	Huawei	Nip6300	-	All	All	All
Hardware	Huawei	Nip6300	-	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c50	All	All	All
Hardware	Huawei	Nip6600	-	All	All	All
Hardware	Huawei	Nip6600	-	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20	All	All	All

Operating System	Huawei	Nip6600 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c50	All	All	All
Hardware	Huawei	Nip6800	-	All	All	All
Hardware	Huawei	Nip6800	-	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c50	All	All	All
Hardware	Huawei	Rse6500	-	All	All	All
Hardware	Huawei	Rse6500	-	All	All	All
Operating System	Huawei	Rse6500 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Rse6500 Firmware	v500r002c00	All	All	All
Hardware	Huawei	Secospace Usg6300	-	All	All	All
Hardware	Huawei	Secospace Usg6300	-	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c20	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c30	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c20	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v100r001c30	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Secospace Usg6300 Firmware	v500r001c50	All	All	All
Hardware	Huawei	Secospace Usg6500	-	All	All	All
Hardware	Huawei	Secospace Usg6500	-	All	All	All
Operating System	Huawei	Secospace Usg6500 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Secospace Usg6500 Firmware	v100r001c20	All	All	All



Operating System	Huawei	Semg9811 Firmware	v300r001c01spca00	All	All	All
Operating System	Huawei	Semg9811 Firmware	v300r001c01spc500	All	All	All
Operating System	Huawei	Semg9811 Firmware	v300r001c01spc500t	All	All	All
Operating System	Huawei	Semg9811 Firmware	v300r001c01spc700	All	All	All
Operating System	Huawei	Semg9811 Firmware	v300r001c01spca00	All	All	All
Hardware	Huawei	Smc2.0	-	All	All	All
Hardware	Huawei	Smc2.0	-	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r003c00spc200t	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r003c00spc300t	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r003c00spc301t	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r003c10	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc100	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc101b001t	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc102	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc103	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc200	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc201t	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v600r006c00	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r003c00spc200t	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r003c00spc300t	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r003c00spc301t	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r003c10	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc100	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc101b001t	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc102	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc103	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc200	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v100r005c00spc201t	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Smc2.0 Firmware	v600r006c00	All	All	All
Hardware	Huawei	Softco	-	All	All	All
Hardware	Huawei	Softco	-	All	All	All
Operating System	Huawei	Softco Firmware	v200r001c01spc300	All	All	All
Operating System	Huawei	Softco Firmware	v200r001c01spc400	All	All	All

Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r001c01spc500	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r001c01spc600	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r001c01sph703	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r003c00spc100	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r003c00spc200	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r003c00spc500	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r003c20	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r001c01spc300	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r001c01spc400	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r001c01spc500	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r001c01spc600	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r001c01sph703	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r003c00spc100	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r003c00spc200	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r003c00spc500	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Softco Firmware</a>	v200r003c20	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Srg1300</a>	-	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Srg1300</a>	-	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg1300 Firmware</a>	v200r006c10	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg1300 Firmware</a>	v200r007c00	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg1300 Firmware</a>	v200r007c02	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg1300 Firmware</a>	v200r008c20	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg1300 Firmware</a>	v200r008c30	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg1300 Firmware</a>	v200r006c10	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg1300 Firmware</a>	v200r007c00	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg1300 Firmware</a>	v200r007c02	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg1300 Firmware</a>	v200r008c20	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg1300 Firmware</a>	v200r008c30	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Srg2300</a>	-	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Srg2300</a>	-	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg2300 Firmware</a>	v200r006c10	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg2300 Firmware</a>	v200r007c00	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg2300 Firmware</a>	v200r007c02	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg2300 Firmware</a>	v200r008c20	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Srg2300 Firmware</a>	v200r008c30	All	All	All
Operatina Svstem	<a href="#">Huawei</a>	<a href="#">Sra2300 Firmware</a>	v200r006c10	All	All	All

Operating System	Huawei	Srg2300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r007c02	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg2300 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Srg3300	-	All	All	All
Hardware	Huawei	Srg3300	-	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c30	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r006c10	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r007c00	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c20	All	All	All
Operating System	Huawei	Srg3300 Firmware	v200r008c30	All	All	All
Hardware	Huawei	Svn5600	-	All	All	All
Hardware	Huawei	Svn5600	-	All	All	All
Operating System	Huawei	Svn5600 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5600 Firmware	v200r003c10	All	All	All
Operating System	Huawei	Svn5600 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5600 Firmware	v200r003c10	All	All	All
Hardware	Huawei	Svn5800	-	All	All	All
Hardware	Huawei	Svn5800	-	All	All	All
Hardware	Huawei	Svn5800-c	-	All	All	All
Hardware	Huawei	Svn5800-c	-	All	All	All
Operating System	Huawei	Svn5800-c Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5800-c Firmware	v200r003c10	All	All	All
Operating System	Huawei	Svn5800-c Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5800-c Firmware	v200r003c10	All	All	All
Operating System	Huawei	Svn5800 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5800 Firmware	v200r003c10	All	All	All
Operating System	Huawei	Svn5800 Firmware	v200r003c00	All	All	All
Operating System	Huawei	Svn5800 Firmware	v200r003c10	All	All	All
Hardware	Huawei	Te30	-	All	All	All
Hardware	Huawei	Te30	-	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c02spc100	All	All	All

Operating System	Huawei	Te30 Firmware	v100r001c02spc200	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc200	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te30 Firmware	v600r006c00	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c02spc100	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c02spc200	All	All	All
Operating System	Huawei	Te30 Firmware	v100r001c10	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc200	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Te30 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te30 Firmware	v600r006c00	All	All	All
Hardware	Huawei	Te40	-	All	All	All
Hardware	Huawei	Te40	-	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te40 Firmware	v600r006c00	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Te40 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te40 Firmware	v600r006c00	All	All	All
Hardware	Huawei	Te50	-	All	All	All
Hardware	Huawei	Te50	-	All	All	All
Operating System	Huawei	Te50 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te50 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te50 Firmware	v600r006c00	All	All	All
Operating System	Huawei	Te50 Firmware	v500r002c00spc600	All	All	All



Operating System	Huawei	Te60 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc800	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spca00	All	All	All
Operating System	Huawei	Te60 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Te60 Firmware	v600r006c00	All	All	All
Operating System	Huawei	Te60 Firmware	v600r006c00spc200	All	All	All
Hardware	Huawei	Tp3206	-	All	All	All
Hardware	Huawei	Tp3206	-	All	All	All
Operating System	Huawei	Tp3206 Firmware	v100r002c00	All	All	All
Operating System	Huawei	Tp3206 Firmware	v100r002c00	All	All	All
Hardware	Huawei	Usg9500	-	All	All	All
Hardware	Huawei	Usg9500	-	All	All	All
Operating System	Huawei	Usg9500 Firmware	v300r001c01	All	All	All
Operating System	Huawei	Usg9500 Firmware	v300r001c20	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Usg9500 Firmware	v300r001c01	All	All	All
Operating System	Huawei	Usg9500 Firmware	v300r001c20	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Usg9500 Firmware	v500r001c50	All	All	All
Hardware	Huawei	Usg9520	-	All	All	All
Hardware	Huawei	Usg9520	-	All	All	All
Operating System	Huawei	Usg9520 Firmware	v300r001c01spc800pwe	All	All	All
Operating System	Huawei	Usg9520 Firmware	v300r001c01spc800pwe	All	All	All
Hardware	Huawei	Usg9560	-	All	All	All
Hardware	Huawei	Usg9560	-	All	All	All
Operating System	Huawei	Usg9560 Firmware	v300r001c20spc300	All	All	All
Operating System	Huawei	Usg9560 Firmware	v300r001c20spc300	All	All	All
Hardware	Huawei	Viewpoint 8660	-	All	All	All



Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03b012sp16	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03b015sp03	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03lgwl01spc100	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03lgwl01spc100b012	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc100	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc200	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc300	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc400	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc500	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c02spc100	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03b012sp15	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03b012sp16	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03b015sp03	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03lgwl01spc100	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03lgwl01spc100b012	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc100	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc200	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc300	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc400	All	All	All
Operating System	Huawei	Viewpoint 9030 Firmware	v100r011c03spc500	All	All	All
Hardware	Huawei	Vp9660	-	All	All	All
Hardware	Huawei	Vp9660	-	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c02spc100	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c02spc200	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c02spc300	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c02spc300t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c02spc400	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc100	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc100b015t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc101	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc101tb015	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc102t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc103t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc104t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc200	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc200b022t	All	All	All





Operating System	Huawei	Vp9660 Firmware	v500r002c10	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c10spc100	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c10spc100t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c10t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c02spc100	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c02spc200	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c02spc300	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c02spc300t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c02spc400	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc100	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc100b015t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc101	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc101tb015	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc102t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc103t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc104t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc200	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc200b022t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc201b023t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc202b025t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc203t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc206t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc207t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc208t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc209t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc300	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc400	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc400b001	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc400t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc401t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc402t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc403t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc404t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc405t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc600	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc700	All	All	All

Operating System	Huawei	Vp9660 Firmware	v200r001c30spc700t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc701t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc702t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc703t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc800	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc800t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spc900	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spca00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spca00t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spca01	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spca01t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spca02t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcb00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcc00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcd00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcd00t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcd01t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcd02t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcd03t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcd04t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcd05t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spce00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spce01t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcf00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcg00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spch00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spci00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v200r001c30spcj00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc001t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc200	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc200t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc201t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc203t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc204t	All	All	All

Operating System	Huawei	Vp9660 Firmware	v500r002c00spc205t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc206t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc300	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc400	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc500	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc600	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc700	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc800	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc900	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc900t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spc901t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spca00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spcb00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spcb01t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spcc00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00spcd00	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c00t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c10	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c10spc100	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c10spc100t	All	All	All
Operating System	Huawei	Vp9660 Firmware	v500r002c10t	All	All	All

## References

Reference	Source	Link	Tags
Security Advisory - Three DoS Vulnerabilities in the SIP Module of Some Huawei Products	CONFIRM	<a href="http://www.huawei.com">www.huawei.com</a>	Vendor Adviso
CVE Program record	CVE.ORG	<a href="http://www.cve.org">www.cve.org</a>	canonical
NVD vulnerability detail	NVD	<a href="http://nvd.nist.gov">nvd.nist.gov</a>	canonical, ana

No vendor comments have been submitted for this CVE.

## Legacy QID Mappings

43871 Huawei Router Three Denial of Service (DoS) Vulnerabilities In The SIP Module (huawei-sa-20200115-01-sip-en)

consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](#) and the authoritative source of CVE content is [MITRE's CVE web site](#). This site includes MITRE data granted under the following [license](#).

**CVE.report and Source URL Uptime Status [status.cve.report](#)**