



CVE-2019-5255

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

Summary

| | |
|------------------------|--|
| CVE | CVE-2019-5255 |
| State | PUBLIC |
| Assigner | psirt@huawei.com |
| Source Priority | CVE Program / NVD first with legacy fallback |
| Published | 2019-12-13 23:15:00 UTC |
| Updated | 2020-08-24 17:37:00 UTC |
| Description | Certain Huawei products (AP2000;IPS Module;NGFW Module;NIP6300;NIP6600;NIP6800;S5700;SVN5600;SVN5800;SVN |

Risk And Classification

Problem Types: CWE-125

NVD Known Affected Configurations (CPE 2.3)

| Type | Vendor | Product | Version | Update | Edition | Language |
|------------------|------------------------|---------------------------------|-------------|--------|---------|----------|
| Hardware | Huawei | Ap2000 | - | All | All | All |
| Hardware | Huawei | Ap2000 | - | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r005c30 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r006c20 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r007c10 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r007c20 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r008c00 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r008c10 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r009c00 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r005c30 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r006c10 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r006c20 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r007c10 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r007c20 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r008c00 | All | All | All |
| Operating System | Huawei | Ap2000 Firmware | v200r008c10 | All | All | All |

| | | | | | | |
|------------------|--------|-----------------------|-----------------------|-----|-----|-----|
| Operating System | Huawei | Ap2000 Firmware | v200r009c00 | All | All | All |
| Hardware | Huawei | Espace U1981 | - | All | All | All |
| Hardware | Huawei | Espace U1981 | - | All | All | All |
| Operating System | Huawei | Espace U1981 Firmware | v200r003c50spc700 | All | All | All |
| Operating System | Huawei | Espace U1981 Firmware | v200r003c50spc700 | All | All | All |
| Hardware | Huawei | Ips | - | All | All | All |
| Hardware | Huawei | Ips | - | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c00spc300 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c00spc500 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c00sph303 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c00sph508 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc100 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc100pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc200 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc200b062 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc200pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc300b078 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc300pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30spc100 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30spc100pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30spc200 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30spc200pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30spc300 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c50 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c50pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c80 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r005c00 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c00spc300 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c00spc500 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c00sph303 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c00sph508 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc100 | All | All | All |

| | | | | | | |
|------------------|--------|---------------|-----------------------|-----|-----|-----|
| Operating System | Huawei | Ips Firmware | v500r001c20spc100pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc200 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc200b062 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc200pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc300b078 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c20spc300pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30spc100 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30spc100pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30spc200 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30spc200pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c30spc300 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c50 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c50pwe | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r001c80 | All | All | All |
| Operating System | Huawei | Ips Firmware | v500r005c00 | All | All | All |
| Hardware | Huawei | Ngfw | - | All | All | All |
| Hardware | Huawei | Ngfw | - | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c00spc300 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c00spc500 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c00spc500pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c00sph303 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c00sph508 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc100 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc100pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc200 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc200b062 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc200pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc300b078 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc300pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c00 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c00spc100 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c00spc100pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c00spc200 | All | All | All |

| | | | | | | |
|------------------|--------|------------------|-----------------------|-----|-----|-----|
| Operating System | Huawei | Ngfw Firmware | v500r002c00spc200pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c00spc300 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c10 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c10pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c30 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c30pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r005c00 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c00spc300 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c00spc500 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c00spc500pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c00sph303 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c00sph508 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc100 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc100pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc200 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc200b062 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc200pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc300b078 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r001c20spc300pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c00 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c00spc100 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c00spc100pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c00spc200 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c00spc200pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c00spc300 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c10 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c10pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c30 | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r002c30pwe | All | All | All |
| Operating System | Huawei | Ngfw Firmware | v500r005c00 | All | All | All |
| Hardware | Huawei | Nip6300 | - | All | All | All |
| Hardware | Huawei | Nip6300 | - | All | All | All |
| Operating System | Huawei | Nip6300 Firmware | v500r001c00spc300 | All | All | All |
| Operating System | Huawei | Nip6300 Firmware | v500r001c00spc500 | All | All | All |
| Operating System | Huawei | Nip6300 Firmware | v500r001c00sph303 | All | All | All |

| | | | | | | |
|------------------|--------|------------------|-----------------------|-----|-----|-----|
| Operating System | Huawei | Nip6300 Firmware | v500r001c30spc200pwe | All | All | All |
| Operating System | Huawei | Nip6300 Firmware | v500r001c30spc300 | All | All | All |
| Operating System | Huawei | Nip6300 Firmware | v500r001c50 | All | All | All |
| Operating System | Huawei | Nip6300 Firmware | v500r001c50pwe | All | All | All |
| Operating System | Huawei | Nip6300 Firmware | v500r001c80 | All | All | All |
| Operating System | Huawei | Nip6300 Firmware | v500r005c00 | All | All | All |
| Hardware | Huawei | Nip6600 | - | All | All | All |
| Hardware | Huawei | Nip6600 | - | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c00spc300 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c00spc500 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c00sph303 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c00sph508 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc100 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc100pwe | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc200 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc200b062 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc200pwe | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc300b078 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30spc100 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30spc100pwe | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30spc200 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30spc200pwe | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30spc300 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c50 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c50pwe | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c80 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r005c00 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c00spc300 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c00spc500 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c00sph303 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c00sph508 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc100 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc100pwe | All | All | All |

| | | | | | | |
|------------------|--------|---------------------------------|-----------------------|-----|-----|-----|
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc100pwe | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc200 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc200b062 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc200pwe | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c20spc300b078 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30spc100 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30spc100pwe | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30spc200 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30spc200pwe | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c30spc300 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c50 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c50pwe | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r001c80 | All | All | All |
| Operating System | Huawei | Nip6600 Firmware | v500r005c00 | All | All | All |
| Hardware | Huawei | Nip6800 | - | All | All | All |
| Hardware | Huawei | Nip6800 | - | All | All | All |
| Operating System | Huawei | Nip6800 Firmware | v500r001c50 | All | All | All |
| Operating System | Huawei | Nip6800 Firmware | v500r001c50pwe | All | All | All |
| Operating System | Huawei | Nip6800 Firmware | v500r001c80 | All | All | All |
| Operating System | Huawei | Nip6800 Firmware | v500r005c00 | All | All | All |
| Operating System | Huawei | Nip6800 Firmware | v500r001c50 | All | All | All |
| Operating System | Huawei | Nip6800 Firmware | v500r001c50pwe | All | All | All |
| Operating System | Huawei | Nip6800 Firmware | v500r001c80 | All | All | All |
| Operating System | Huawei | Nip6800 Firmware | v500r005c00 | All | All | All |
| Hardware | Huawei | S5700 | - | All | All | All |
| Hardware | Huawei | S5700 | - | All | All | All |
| Operating System | Huawei | S5700 Firmware | v200r005c03 | All | All | All |
| Operating System | Huawei | S5700 Firmware | v200r005c03 | All | All | All |
| Hardware | Huawei | Secospace Antiddos8000 | - | All | All | All |
| Hardware | Huawei | Secospace Antiddos8000 | - | All | All | All |
| Operating System | Huawei | Secospace Antiddos8000 Firmware | v500r001c00 | All | All | All |
| Operating System | Huawei | Secospace Antiddos8000 Firmware | v500r001c00spc200 | All | All | All |
| Operating System | Huawei | Secospace Antiddos8000 Firmware | v500r001c00spc300 | All | All | All |
| Operating System | Huawei | Secospace Antiddos8000 Firmware | v500r001c00spc500 | All | All | All |
| Operating System | Huawei | Secospace Antiddos8000 Firmware | v500r001c00spc600 | All | All | All |

| | | | | | | |
|------------------|------------------------|--|---------------------------------------|-----|-----|-----|
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c20spc101 | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c20spc200 | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c20spc200b062 | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c20spc200pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c20spc300b078 | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c20spc300pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c30 | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c30spc100 | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c30spc100pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c30spc200 | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c30spc200pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c30spc300 | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c50 | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c50pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c80 | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r001c80pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6300 Firmware | v500r005c00 | All | All | All |
| Hardware | Huawei | Secospace Usg6500 | - | All | All | All |
| Hardware | Huawei | Secospace Usg6500 | - | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v100r001c20spc100 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c00spc300 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c00spc500 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c00spc500pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c00sph303 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c00sph508 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c20 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c20spc100 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c20spc100pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c20spc101 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c20spc200 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c20spc200b062 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c20spc200pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c20spc300b078 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c20spc300pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c30 | All | All | All |
| Operating System | Huawei | Secospace Usg6500 Firmware | v500r001c30spc100 | All | All | All |

| | | | | | | |
|------------------|------------------------|--|---------------------------------------|-----|-----|-----|
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c20spc300 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c20spc300b078 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c20spc300pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c30 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c30spc100 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c30spc100pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c30spc200 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c30spc200pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c30spc300 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c30spc500 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c30spc600 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c30spc600pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c30spc601 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c50 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c50pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c50spc009 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c50spc100 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c50spc100pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c50spc200 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c50spc200pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c50spc300 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c60 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c60spc100 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c60spc100pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c60spc200 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c60spc200pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c60spc300 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c60spc500 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c80 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r001c80pwe | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r005c00 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r005c00spc100 | All | All | All |
| Operating System | Huawei | Secospace Usg6600 Firmware | v500r005c00spc102 | All | All | All |
| Hardware | Huawei | Semg9811 | - | All | All | All |
| Hardware | Huawei | Semg9811 | - | All | All | All |

| | | | | | | |
|------------------|--------|--------------------|-------------------|-----|-----|-----|
| Operating System | Huawei | Semg9811 Firmware | v500r002c20 | All | All | All |
| Operating System | Huawei | Semg9811 Firmware | v500r002c30 | All | All | All |
| Operating System | Huawei | Semg9811 Firmware | v500r005c00 | All | All | All |
| Operating System | Huawei | Semg9811 Firmware | v500r002c20 | All | All | All |
| Operating System | Huawei | Semg9811 Firmware | v500r002c30 | All | All | All |
| Operating System | Huawei | Semg9811 Firmware | v500r005c00 | All | All | All |
| Hardware | Huawei | Svn5600 | - | All | All | All |
| Hardware | Huawei | Svn5600 | - | All | All | All |
| Operating System | Huawei | Svn5600 Firmware | v200r003c00spc100 | All | All | All |
| Operating System | Huawei | Svn5600 Firmware | v200r003c00spc100 | All | All | All |
| Hardware | Huawei | Svn5800 | - | All | All | All |
| Hardware | Huawei | Svn5800 | - | All | All | All |
| Hardware | Huawei | Svn5800-c | - | All | All | All |
| Hardware | Huawei | Svn5800-c | - | All | All | All |
| Operating System | Huawei | Svn5800-c Firmware | v200r003c00spc100 | All | All | All |
| Operating System | Huawei | Svn5800-c Firmware | v200r003c00spc100 | All | All | All |
| Operating System | Huawei | Svn5800 Firmware | v200r003c00spc100 | All | All | All |
| Operating System | Huawei | Svn5800 Firmware | v200r003c00spc100 | All | All | All |
| Hardware | Huawei | Usg6000v | - | All | All | All |
| Hardware | Huawei | Usg6000v | - | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c10 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c10spc100 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c10spc200 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c20 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c20spc100 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c20spc200 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c20spc300 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c20spc500 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c20spc600 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r003c00 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r003c00spc100 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r005c00 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r005c00spc100 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c10 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c10spc100 | All | All | All |
| Operatina Svstem | Huawei | Usa6000v Firmware | v500r001c10spc200 | All | All | All |

| Operating System | Vendor | Usg6000v Firmware | Version | ... | ... | ... |
|------------------|--------|-------------------|-------------------|-----|-----|-----|
| Operating System | Huawei | Usg6000v Firmware | v500r001c20 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c20spc100 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c20spc200 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c20spc300 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c20spc500 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r001c20spc600 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r003c00 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r003c00spc100 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r005c00 | All | All | All |
| Operating System | Huawei | Usg6000v Firmware | v500r005c00spc100 | All | All | All |

References

| Reference | Source | Link | Tags |
|--|---------|--|---------------------|
| Security Advisory - Multiple Vulnerabilities in Some Huawei Products | MISC | www.huawei.com | Vendor Advisory |
| CVE Program record | CVE.ORG | www.cve.org | canonical |
| NVD vulnerability detail | NVD | nvd.nist.gov | canonical, analysis |

No vendor comments have been submitted for this CVE.

Legacy QID Mappings

43893 Huawei Router and Switch Multiple Vulnerabilities (huawei-sa-20191211-01-ssp-en)

© CVE.report 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](https://www.mitre.org/) and the authoritative source of CVE content is [MITRE's CVE web site](https://www.mitre.org/cve/). This site includes MITRE data granted under the following [license](https://www.mitre.org/licenses/).

CVE.report and Source URL Uptime Status status.cve.report