



# CVE-2019-5256

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

## Summary

<b>CVE</b>	CVE-2019-5256
<b>State</b>	PUBLIC
<b>Assigner</b>	psirt@huawei.com
<b>Source Priority</b>	CVE Program / NVD first with legacy fallback
<b>Published</b>	2019-12-13 23:15:00 UTC
<b>Updated</b>	2020-08-24 17:37:00 UTC
<b>Description</b>	Certain Huawei products (AP2000;IPS Module;NGFW Module;NIP6300;NIP6600;NIP6800;S5700;SVN5600;SVN5800;SVN

## Risk And Classification

**Problem Types:** CWE-476

## NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware	<a href="#">Huawei</a>	<a href="#">Ap2000</a>	-	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Ap2000</a>	-	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r005c30	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r006c10	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r006c20	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r007c10	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r007c20	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r008c00	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r008c10	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r009c00	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r005c30	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r006c10	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r006c20	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r007c10	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r007c20	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r008c00	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Ap2000 Firmware</a>	v200r008c10	All	All	All

Operating System	Huawei	Ap2000 Firmware	v200r009c00	All	All	All
Hardware	Huawei	Espace U1981	-	All	All	All
Hardware	Huawei	Espace U1981	-	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v200r003c50spc700	All	All	All
Operating System	Huawei	Espace U1981 Firmware	v200r003c50spc700	All	All	All
Hardware	Huawei	Ips	-	All	All	All
Hardware	Huawei	Ips	-	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c00spc300	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c00spc500	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c00sph303	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c00sph508	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc100	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc100pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc200	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc200b062	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc200pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc300b078	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc300pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30spc100	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30spc100pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30spc200	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30spc200pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30spc300	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c50	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c50pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c80	All	All	All
Operating System	Huawei	Ips Firmware	v500r005c00	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c00spc300	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c00spc500	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c00sph303	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c00sph508	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc100	All	All	All

Operating System	Huawei	Ips Firmware	v500r001c20spc100pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc200	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc200b062	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc200pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc300b078	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c20spc300pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30spc100	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30spc100pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30spc200	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30spc200pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c30spc300	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c50	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c50pwe	All	All	All
Operating System	Huawei	Ips Firmware	v500r001c80	All	All	All
Operating System	Huawei	Ips Firmware	v500r005c00	All	All	All
Hardware	Huawei	Ngfw	-	All	All	All
Hardware	Huawei	Ngfw	-	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c00spc300	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c00spc500	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c00spc500pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c00sph303	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c00sph508	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc100	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc100pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc200	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc200b062	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc200pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc300b078	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc300pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c00	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c00spc100	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c00spc100pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c00spc200	All	All	All

Operating System	Huawei	Ngfw Firmware	v500r002c00spc200pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c00spc300	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c10	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c10pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c30	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c30pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r005c00	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c00spc300	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c00spc500	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c00spc500pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c00sph303	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c00sph508	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc100	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc100pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc200	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc200b062	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc200pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc300b078	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r001c20spc300pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c00	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c00spc100	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c00spc100pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c00spc200	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c00spc200pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c00spc300	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c10	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c10pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c30	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r002c30pwe	All	All	All
Operating System	Huawei	Ngfw Firmware	v500r005c00	All	All	All
Hardware	Huawei	Nip6300	-	All	All	All
Hardware	Huawei	Nip6300	-	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c00spc300	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c00spc500	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c00sph303	All	All	All



Operating System	Huawei	Nip6300 Firmware	v500r001c30spc200pwe	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c30spc300	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c50pwe	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r001c80	All	All	All
Operating System	Huawei	Nip6300 Firmware	v500r005c00	All	All	All
Hardware	Huawei	Nip6600	-	All	All	All
Hardware	Huawei	Nip6600	-	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00spc300	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00spc500	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00sph303	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00sph508	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc100	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc100pwe	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc200	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc200b062	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc200pwe	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc300b078	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30spc100	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30spc100pwe	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30spc200	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30spc200pwe	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30spc300	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c50pwe	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c80	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r005c00	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00spc300	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00spc500	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00sph303	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c00sph508	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc100	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc100pwe	All	All	All

Operating System	Huawei	Nip6600 Firmware	v500r001c20spc100pwe	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc200	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc200b062	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc200pwe	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c20spc300b078	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30spc100	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30spc100pwe	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30spc200	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30spc200pwe	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c30spc300	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c50pwe	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r001c80	All	All	All
Operating System	Huawei	Nip6600 Firmware	v500r005c00	All	All	All
Hardware	Huawei	Nip6800	-	All	All	All
Hardware	Huawei	Nip6800	-	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c50pwe	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c80	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r005c00	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c50	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c50pwe	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r001c80	All	All	All
Operating System	Huawei	Nip6800 Firmware	v500r005c00	All	All	All
Hardware	Huawei	S5700	-	All	All	All
Hardware	Huawei	S5700	-	All	All	All
Operating System	Huawei	S5700 Firmware	v200r005c03	All	All	All
Operating System	Huawei	S5700 Firmware	v200r005c03	All	All	All
Hardware	Huawei	Secospace Antiddos8000	-	All	All	All
Hardware	Huawei	Secospace Antiddos8000	-	All	All	All
Operating System	Huawei	Secospace Antiddos8000 Firmware	v500r001c00	All	All	All
Operating System	Huawei	Secospace Antiddos8000 Firmware	v500r001c00spc200	All	All	All
Operating System	Huawei	Secospace Antiddos8000 Firmware	v500r001c00spc300	All	All	All
Operating System	Huawei	Secospace Antiddos8000 Firmware	v500r001c00spc500	All	All	All
Operating System	Huawei	Secospace Antiddos8000 Firmware	v500r001c00spc600	All	All	All





Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c20spc101</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c20spc200</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c20spc200b062</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c20spc200pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c20spc300b078</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c20spc300pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c30</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c30spc100</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c30spc100pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c30spc200</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c30spc200pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c30spc300</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c50</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c50pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c80</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r001c80pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6300 Firmware</a>	<a href="#">v500r005c00</a>	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500</a>	-	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500</a>	-	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v100r001c20spc100</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c00spc300</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c00spc500</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c00spc500pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c00sph303</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c00sph508</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c20</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c20spc100</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c20spc100pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c20spc101</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c20spc200</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c20spc200b062</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c20spc200pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c20spc300b078</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c20spc300pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c30</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6500 Firmware</a>	<a href="#">v500r001c30spc100</a>	All	All	All







Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c20spc300</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c20spc300b078</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c20spc300pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c30</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c30spc100</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c30spc100pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c30spc200</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c30spc200pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c30spc300</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c30spc500</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c30spc600</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c30spc600pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c30spc601</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c50</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c50pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c50spc009</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c50spc100</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c50spc100pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c50spc200</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c50spc200pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c50spc300</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c60</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c60spc100</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c60spc100pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c60spc200</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c60spc200pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c60spc300</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c60spc500</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c80</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r001c80pwe</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r005c00</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r005c00spc100</a>	All	All	All
Operating System	<a href="#">Huawei</a>	<a href="#">Secospace Usg6600 Firmware</a>	<a href="#">v500r005c00spc102</a>	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Semg9811</a>	-	All	All	All
Hardware	<a href="#">Huawei</a>	<a href="#">Semg9811</a>	-	All	All	All

Operating System	Huawei	Semg9811 Firmware	v500r002c20	All	All	All
Operating System	Huawei	Semg9811 Firmware	v500r002c30	All	All	All
Operating System	Huawei	Semg9811 Firmware	v500r005c00	All	All	All
Operating System	Huawei	Semg9811 Firmware	v500r002c20	All	All	All
Operating System	Huawei	Semg9811 Firmware	v500r002c30	All	All	All
Operating System	Huawei	Semg9811 Firmware	v500r005c00	All	All	All
Hardware	Huawei	Svn5600	-	All	All	All
Hardware	Huawei	Svn5600	-	All	All	All
Operating System	Huawei	Svn5600 Firmware	v200r003c00spc100	All	All	All
Operating System	Huawei	Svn5600 Firmware	v200r003c00spc100	All	All	All
Hardware	Huawei	Svn5800	-	All	All	All
Hardware	Huawei	Svn5800	-	All	All	All
Hardware	Huawei	Svn5800-c	-	All	All	All
Hardware	Huawei	Svn5800-c	-	All	All	All
Operating System	Huawei	Svn5800-c Firmware	v200r003c00spc100	All	All	All
Operating System	Huawei	Svn5800-c Firmware	v200r003c00spc100	All	All	All
Operating System	Huawei	Svn5800 Firmware	v200r003c00spc100	All	All	All
Operating System	Huawei	Svn5800 Firmware	v200r003c00spc100	All	All	All
Hardware	Huawei	Usg6000v	-	All	All	All
Hardware	Huawei	Usg6000v	-	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c10	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c10spc100	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c10spc200	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20spc100	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20spc200	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20spc300	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20spc500	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20spc600	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r003c00	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r003c00spc100	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r005c00	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r005c00spc100	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c10	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c10spc100	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c10spc200	All	All	All

Operating System	Vendor	Usg6000v Firmware	Version	...	...	...
Operating System	Huawei	Usg6000v Firmware	v500r001c20	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20spc100	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20spc200	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20spc300	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20spc500	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r001c20spc600	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r003c00	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r003c00spc100	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r005c00	All	All	All
Operating System	Huawei	Usg6000v Firmware	v500r005c00spc100	All	All	All

## References

Reference	Source	Link	Tags
Security Advisory - Multiple Vulnerabilities in Some Huawei Products	MISC	<a href="http://www.huawei.com">www.huawei.com</a>	Vendor Advisory
CVE Program record	CVE.ORG	<a href="http://www.cve.org">www.cve.org</a>	canonical
NVD vulnerability detail	NVD	<a href="http://nvd.nist.gov">nvd.nist.gov</a>	canonical, analysis

No vendor comments have been submitted for this CVE.

## Legacy QID Mappings

43893 Huawei Router and Switch Multiple Vulnerabilities (huawei-sa-20191211-01-ssp-en)

© CVE.report 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](https://www.mitre.org/) and the authoritative source of CVE content is [MITRE's CVE web site](https://www.mitre.org/cve/). This site includes MITRE data granted under the following [license](https://www.mitre.org/licenses/).

**CVE.report and Source URL Uptime Status** [status.cve.report](https://status.cve.report)