



# CVE-2021-33103

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

## Summary

<b>CVE</b>	CVE-2021-33103
<b>State</b>	PUBLIC
<b>Assigner</b>	secure@intel.com
<b>Source Priority</b>	CVE Program / NVD first with legacy fallback
<b>Published</b>	2022-05-12 17:15:00 UTC
<b>Updated</b>	2022-10-26 22:42:00 UTC
<b>Description</b>	Unintended intermediary in the BIOS authenticated code module for some Intel(R) Processors may allow a privileged user t

## Risk And Classification

**Problem Types:** NVD-CWE-noinfo

## NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware	<a href="#">Intel</a>	<a href="#">Core I3-1000g1</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-1000g1 Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core I3-1000g4</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-1000g4 Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core I3-1005g1</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-1005g1 Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core I3-10100</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core I3-10100e</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10100e Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core I3-10100f</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10100f Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core I3-10100t</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core I3-10100te</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10100te Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10100t Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core I3-10100y</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10100y Firmware</a>	-	All	All	All

Operating System	Intel	Core I3-10100 Firmware	-	All	All	All
Hardware	Intel	Core I3-10105	-	All	All	All
Hardware	Intel	Core I3-10105f	-	All	All	All
Operating System	Intel	Core I3-10105f Firmware	-	All	All	All
Hardware	Intel	Core I3-10105t	-	All	All	All
Operating System	Intel	Core I3-10105t Firmware	-	All	All	All
Operating System	Intel	Core I3-10105 Firmware	-	All	All	All
Hardware	Intel	Core I3-10110u	-	All	All	All
Operating System	Intel	Core I3-10110u Firmware	-	All	All	All
Hardware	Intel	Core I3-10110y	-	All	All	All
Operating System	Intel	Core I3-10110y Firmware	-	All	All	All
Hardware	Intel	Core I3-10300	-	All	All	All
Hardware	Intel	Core I3-10300t	-	All	All	All
Operating System	Intel	Core I3-10300t Firmware	-	All	All	All
Operating System	Intel	Core I3-10300 Firmware	-	All	All	All
Hardware	Intel	Core I3-10305	-	All	All	All
Hardware	Intel	Core I3-10305t	-	All	All	All
Operating System	Intel	Core I3-10305t Firmware	-	All	All	All
Operating System	Intel	Core I3-10305 Firmware	-	All	All	All
Hardware	Intel	Core I3-10320	-	All	All	All
Operating System	Intel	Core I3-10320 Firmware	-	All	All	All
Hardware	Intel	Core I3-10325	-	All	All	All
Operating System	Intel	Core I3-10325 Firmware	-	All	All	All
Hardware	Intel	Core I3-11100he	-	All	All	All
Operating System	Intel	Core I3-11100he Firmware	-	All	All	All
Hardware	Intel	Core I3-1110g4	-	All	All	All
Operating System	Intel	Core I3-1110g4 Firmware	-	All	All	All
Hardware	Intel	Core I3-1115g4	-	All	All	All
Hardware	Intel	Core I3-1115g4e	-	All	All	All
Operating System	Intel	Core I3-1115g4e Firmware	-	All	All	All
Operating System	Intel	Core I3-1115g4 Firmware	-	All	All	All
Hardware	Intel	Core I3-1115gre	-	All	All	All
Operating System	Intel	Core I3-1115gre Firmware	-	All	All	All
Hardware	Intel	Core I3-1120g4	-	All	All	All
Operating System	Intel	Core I3-1120g4 Firmware	-	All	All	All

Hardware	Intel	Core I3-1125g4	-	All	All	All
Operating System	Intel	Core I3-1125g4 Firmware	-	All	All	All
Hardware	Intel	Core I3-9100	-	All	All	All
Hardware	Intel	Core I3-9100e	-	All	All	All
Operating System	Intel	Core I3-9100e Firmware	-	All	All	All
Hardware	Intel	Core I3-9100f	-	All	All	All
Operating System	Intel	Core I3-9100f Firmware	-	All	All	All
Hardware	Intel	Core I3-9100hl	-	All	All	All
Operating System	Intel	Core I3-9100hl Firmware	-	All	All	All
Hardware	Intel	Core I3-9100t	-	All	All	All
Hardware	Intel	Core I3-9100te	-	All	All	All
Operating System	Intel	Core I3-9100te Firmware	-	All	All	All
Operating System	Intel	Core I3-9100t Firmware	-	All	All	All
Operating System	Intel	Core I3-9100 Firmware	-	All	All	All
Hardware	Intel	Core I3-9300	-	All	All	All
Hardware	Intel	Core I3-9300t	-	All	All	All
Operating System	Intel	Core I3-9300t Firmware	-	All	All	All
Operating System	Intel	Core I3-9300 Firmware	-	All	All	All
Hardware	Intel	Core I3-9320	-	All	All	All
Operating System	Intel	Core I3-9320 Firmware	-	All	All	All
Hardware	Intel	Core I3-9350k	-	All	All	All
Hardware	Intel	Core I3-9350kf	-	All	All	All
Operating System	Intel	Core I3-9350kf Firmware	-	All	All	All
Operating System	Intel	Core I3-9350k Firmware	-	All	All	All
Hardware	Intel	Core I5-10200h	-	All	All	All
Operating System	Intel	Core I5-10200h Firmware	-	All	All	All
Hardware	Intel	Core I5-10210u	-	All	All	All
Operating System	Intel	Core I5-10210u Firmware	-	All	All	All
Hardware	Intel	Core I5-10210y	-	All	All	All
Operating System	Intel	Core I5-10210y Firmware	-	All	All	All
Hardware	Intel	Core I5-10300h	-	All	All	All
Operating System	Intel	Core I5-10300h Firmware	-	All	All	All
Hardware	Intel	Core I5-1030g4	-	All	All	All
Operating System	Intel	Core I5-1030g4 Firmware	-	All	All	All
Hardware	Intel	Core I5-1030g7	-	All	All	All

Operating System	Intel	Core I5-1030g/ Firmware	-	All	All	All
Hardware	Intel	Core I5-10310u	-	All	All	All
Operating System	Intel	Core I5-10310u Firmware	-	All	All	All
Hardware	Intel	Core I5-10310y	-	All	All	All
Operating System	Intel	Core I5-10310y Firmware	-	All	All	All
Hardware	Intel	Core I5-1035g1	-	All	All	All
Operating System	Intel	Core I5-1035g1 Firmware	-	All	All	All
Hardware	Intel	Core I5-1035g4	-	All	All	All
Operating System	Intel	Core I5-1035g4 Firmware	-	All	All	All
Hardware	Intel	Core I5-1035g7	-	All	All	All
Operating System	Intel	Core I5-1035g7 Firmware	-	All	All	All
Hardware	Intel	Core I5-1038ng7	-	All	All	All
Operating System	Intel	Core I5-1038ng7 Firmware	-	All	All	All
Hardware	Intel	Core I5-10400	-	All	All	All
Hardware	Intel	Core I5-10400f	-	All	All	All
Operating System	Intel	Core I5-10400f Firmware	-	All	All	All
Hardware	Intel	Core I5-10400h	-	All	All	All
Operating System	Intel	Core I5-10400h Firmware	-	All	All	All
Hardware	Intel	Core I5-10400t	-	All	All	All
Operating System	Intel	Core I5-10400t Firmware	-	All	All	All
Operating System	Intel	Core I5-10400 Firmware	-	All	All	All
Hardware	Intel	Core I5-10500	-	All	All	All
Hardware	Intel	Core I5-10500e	-	All	All	All
Operating System	Intel	Core I5-10500e Firmware	-	All	All	All
Hardware	Intel	Core I5-10500h	-	All	All	All
Operating System	Intel	Core I5-10500h Firmware	-	All	All	All
Hardware	Intel	Core I5-10500t	-	All	All	All
Hardware	Intel	Core I5-10500te	-	All	All	All
Operating System	Intel	Core I5-10500te Firmware	-	All	All	All
Operating System	Intel	Core I5-10500t Firmware	-	All	All	All
Operating System	Intel	Core I5-10500 Firmware	-	All	All	All
Hardware	Intel	Core I5-10505	-	All	All	All
Operating System	Intel	Core I5-10505 Firmware	-	All	All	All
Hardware	Intel	Core I5-10600	-	All	All	All
Hardware	Intel	Core I5-10600k	-	All	All	All
Hardware	Intel	Core I5-10600kf	-	All	All	All

Operating System	Intel	Core I5-10600kf Firmware	-	All	All	All
Operating System	Intel	Core I5-10600k Firmware	-	All	All	All
Hardware	Intel	Core I5-10600t	-	All	All	All
Operating System	Intel	Core I5-10600t Firmware	-	All	All	All
Operating System	Intel	Core I5-10600 Firmware	-	All	All	All
Hardware	Intel	Core I5-11260h	-	All	All	All
Operating System	Intel	Core I5-11260h Firmware	-	All	All	All
Hardware	Intel	Core I5-11300h	-	All	All	All
Operating System	Intel	Core I5-11300h Firmware	-	All	All	All
Hardware	Intel	Core I5-1130g7	-	All	All	All
Operating System	Intel	Core I5-1130g7 Firmware	-	All	All	All
Hardware	Intel	Core I5-11320h	-	All	All	All
Operating System	Intel	Core I5-11320h Firmware	-	All	All	All
Hardware	Intel	Core I5-1135g7	-	All	All	All
Operating System	Intel	Core I5-1135g7 Firmware	-	All	All	All
Hardware	Intel	Core I5-11400	-	All	All	All
Hardware	Intel	Core I5-11400f	-	All	All	All
Operating System	Intel	Core I5-11400f Firmware	-	All	All	All
Hardware	Intel	Core I5-11400h	-	All	All	All
Operating System	Intel	Core I5-11400h Firmware	-	All	All	All
Hardware	Intel	Core I5-11400t	-	All	All	All
Operating System	Intel	Core I5-11400t Firmware	-	All	All	All
Operating System	Intel	Core I5-11400 Firmware	-	All	All	All
Hardware	Intel	Core I5-1140g7	-	All	All	All
Operating System	Intel	Core I5-1140g7 Firmware	-	All	All	All
Hardware	Intel	Core I5-1145g7	-	All	All	All
Hardware	Intel	Core I5-1145g7e	-	All	All	All
Operating System	Intel	Core I5-1145g7e Firmware	-	All	All	All
Operating System	Intel	Core I5-1145g7 Firmware	-	All	All	All
Hardware	Intel	Core I5-1145gre	-	All	All	All
Operating System	Intel	Core I5-1145gre Firmware	-	All	All	All
Hardware	Intel	Core I5-11500	-	All	All	All
Hardware	Intel	Core I5-11500h	-	All	All	All
Hardware	Intel	Core I5-11500he	-	All	All	All
Operating System	Intel	Core I5-11500he Firmware	-	All	All	All

Operating System	Intel	Core I5-11500h Firmware	-	All	All	All
Hardware	Intel	Core I5-11500t	-	All	All	All
Operating System	Intel	Core I5-11500t Firmware	-	All	All	All
Operating System	Intel	Core I5-11500 Firmware	-	All	All	All
Hardware	Intel	Core I5-1155g7	-	All	All	All
Operating System	Intel	Core I5-1155g7 Firmware	-	All	All	All
Hardware	Intel	Core I5-11600	-	All	All	All
Hardware	Intel	Core I5-11600k	-	All	All	All
Hardware	Intel	Core I5-11600kf	-	All	All	All
Operating System	Intel	Core I5-11600kf Firmware	-	All	All	All
Operating System	Intel	Core I5-11600k Firmware	-	All	All	All
Hardware	Intel	Core I5-11600t	-	All	All	All
Operating System	Intel	Core I5-11600t Firmware	-	All	All	All
Operating System	Intel	Core I5-11600 Firmware	-	All	All	All
Hardware	Intel	Core I5-9300h	-	All	All	All
Hardware	Intel	Core I5-9300hf	-	All	All	All
Operating System	Intel	Core I5-9300hf Firmware	-	All	All	All
Operating System	Intel	Core I5-9300h Firmware	-	All	All	All
Hardware	Intel	Core I5-9400	-	All	All	All
Hardware	Intel	Core I5-9400f	-	All	All	All
Operating System	Intel	Core I5-9400f Firmware	-	All	All	All
Hardware	Intel	Core I5-9400h	-	All	All	All
Operating System	Intel	Core I5-9400h Firmware	-	All	All	All
Hardware	Intel	Core I5-9400t	-	All	All	All
Operating System	Intel	Core I5-9400t Firmware	-	All	All	All
Operating System	Intel	Core I5-9400 Firmware	-	All	All	All
Hardware	Intel	Core I5-9500	-	All	All	All
Hardware	Intel	Core I5-9500e	-	All	All	All
Operating System	Intel	Core I5-9500e Firmware	-	All	All	All
Hardware	Intel	Core I5-9500f	-	All	All	All
Operating System	Intel	Core I5-9500f Firmware	-	All	All	All
Hardware	Intel	Core I5-9500t	-	All	All	All
Hardware	Intel	Core I5-9500te	-	All	All	All
Operating System	Intel	Core I5-9500te Firmware	-	All	All	All
Operating System	Intel	Core I5-9500t Firmware	-	All	All	All
Operating System	Intel	Core I5-9500 Firmware	-	All	All	All

Operating System	<a href="#">intel</a>	<a href="#">Core i5-9500 Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i5-9600</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i5-9600k</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i5-9600kf</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-9600kf Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-9600k Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i5-9600t</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-9600t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-9600 Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-10510u</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10510u Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-10510y</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10510y Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-1060g7</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1060g7 Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-10610u</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10610u Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-1065g7</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1065g7 Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-1068ng7</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1068ng7 Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-10700</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-10700e</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700e Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-10700f</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700f Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-10700k</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-10700kf</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700kf Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700k Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-10700t</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-10700te</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700te Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700 Firmware</a>	-	All	All	All
Hardware	<a href="#">Intel</a>	<a href="#">Core i7-10710u</a>	-	All	All	All

Operating System	Intel	Core I7-10710u Firmware	-	All	All	All
Hardware	Intel	Core I7-10750h	-	All	All	All
Operating System	Intel	Core I7-10750h Firmware	-	All	All	All
Hardware	Intel	Core I7-10810u	-	All	All	All
Operating System	Intel	Core I7-10810u Firmware	-	All	All	All
Hardware	Intel	Core I7-10850h	-	All	All	All
Operating System	Intel	Core I7-10850h Firmware	-	All	All	All
Hardware	Intel	Core I7-10870h	-	All	All	All
Operating System	Intel	Core I7-10870h Firmware	-	All	All	All
Hardware	Intel	Core I7-10875h	-	All	All	All
Operating System	Intel	Core I7-10875h Firmware	-	All	All	All
Hardware	Intel	Core I7-11370h	-	All	All	All
Operating System	Intel	Core I7-11370h Firmware	-	All	All	All
Hardware	Intel	Core I7-11375h	-	All	All	All
Operating System	Intel	Core I7-11375h Firmware	-	All	All	All
Hardware	Intel	Core I7-11390h	-	All	All	All
Operating System	Intel	Core I7-11390h Firmware	-	All	All	All
Hardware	Intel	Core I7-11600h	-	All	All	All
Operating System	Intel	Core I7-11600h Firmware	-	All	All	All
Hardware	Intel	Core I7-1160g7	-	All	All	All
Operating System	Intel	Core I7-1160g7 Firmware	-	All	All	All
Hardware	Intel	Core I7-1165g7	-	All	All	All
Operating System	Intel	Core I7-1165g7 Firmware	-	All	All	All
Hardware	Intel	Core I7-11700	-	All	All	All
Hardware	Intel	Core I7-11700f	-	All	All	All
Operating System	Intel	Core I7-11700f Firmware	-	All	All	All
Hardware	Intel	Core I7-11700k	-	All	All	All
Hardware	Intel	Core I7-11700kf	-	All	All	All
Operating System	Intel	Core I7-11700kf Firmware	-	All	All	All
Operating System	Intel	Core I7-11700k Firmware	-	All	All	All
Hardware	Intel	Core I7-11700t	-	All	All	All
Operating System	Intel	Core I7-11700t Firmware	-	All	All	All
Operating System	Intel	Core I7-11700 Firmware	-	All	All	All
Hardware	Intel	Core I7-11800h	-	All	All	All
Operating System	Intel	Core I7-11800h Firmware	-	All	All	All

Hardware	Intel	Core I7-1180g7	-	All	All	All
Operating System	Intel	Core I7-1180g7 Firmware	-	All	All	All
Hardware	Intel	Core I7-11850h	-	All	All	All
Hardware	Intel	Core I7-11850he	-	All	All	All
Operating System	Intel	Core I7-11850he Firmware	-	All	All	All
Operating System	Intel	Core I7-11850h Firmware	-	All	All	All
Hardware	Intel	Core I7-1185g7	-	All	All	All
Hardware	Intel	Core I7-1185g7e	-	All	All	All
Operating System	Intel	Core I7-1185g7e Firmware	-	All	All	All
Operating System	Intel	Core I7-1185g7 Firmware	-	All	All	All
Hardware	Intel	Core I7-1185gre	-	All	All	All
Operating System	Intel	Core I7-1185gre Firmware	-	All	All	All
Hardware	Intel	Core I7-1195g7	-	All	All	All
Operating System	Intel	Core I7-1195g7 Firmware	-	All	All	All
Hardware	Intel	Core I7-9700	-	All	All	All
Hardware	Intel	Core I7-9700e	-	All	All	All
Operating System	Intel	Core I7-9700e Firmware	-	All	All	All
Hardware	Intel	Core I7-9700f	-	All	All	All
Operating System	Intel	Core I7-9700f Firmware	-	All	All	All
Hardware	Intel	Core I7-9700k	-	All	All	All
Hardware	Intel	Core I7-9700kf	-	All	All	All
Operating System	Intel	Core I7-9700kf Firmware	-	All	All	All
Operating System	Intel	Core I7-9700k Firmware	-	All	All	All
Hardware	Intel	Core I7-9700t	-	All	All	All
Hardware	Intel	Core I7-9700te	-	All	All	All
Operating System	Intel	Core I7-9700te Firmware	-	All	All	All
Operating System	Intel	Core I7-9700t Firmware	-	All	All	All
Operating System	Intel	Core I7-9700 Firmware	-	All	All	All
Hardware	Intel	Core I7-9750h	-	All	All	All
Hardware	Intel	Core I7-9750hf	-	All	All	All
Operating System	Intel	Core I7-9750hf Firmware	-	All	All	All
Operating System	Intel	Core I7-9750h Firmware	-	All	All	All
Hardware	Intel	Core I7-9850h	-	All	All	All
Hardware	Intel	Core I7-9850he	-	All	All	All
Operating System	Intel	Core I7-9850he Firmware	-	All	All	All
Hardware	Intel	Core I7-9850h	-	All	All	All

Hardware	Intel	Core i7-9650H	-	All	All	All
Operating System	Intel	Core i7-9850H Firmware	-	All	All	All
Operating System	Intel	Core i7-9850H Firmware	-	All	All	All
Hardware	Intel	Core i9-10850k	-	All	All	All
Operating System	Intel	Core i9-10850k Firmware	-	All	All	All
Hardware	Intel	Core i9-10885h	-	All	All	All
Operating System	Intel	Core i9-10885h Firmware	-	All	All	All
Hardware	Intel	Core i9-10900	-	All	All	All
Hardware	Intel	Core i9-10900e	-	All	All	All
Operating System	Intel	Core i9-10900e Firmware	-	All	All	All
Hardware	Intel	Core i9-10900f	-	All	All	All
Operating System	Intel	Core i9-10900f Firmware	-	All	All	All
Hardware	Intel	Core i9-10900k	-	All	All	All
Hardware	Intel	Core i9-10900kf	-	All	All	All
Operating System	Intel	Core i9-10900kf Firmware	-	All	All	All
Operating System	Intel	Core i9-10900k Firmware	-	All	All	All
Hardware	Intel	Core i9-10900t	-	All	All	All
Hardware	Intel	Core i9-10900te	-	All	All	All
Operating System	Intel	Core i9-10900te Firmware	-	All	All	All
Operating System	Intel	Core i9-10900t Firmware	-	All	All	All
Operating System	Intel	Core i9-10900 Firmware	-	All	All	All
Hardware	Intel	Core i9-10980hk	-	All	All	All
Operating System	Intel	Core i9-10980hk Firmware	-	All	All	All
Hardware	Intel	Core i9-11900	-	All	All	All
Hardware	Intel	Core i9-11900f	-	All	All	All
Operating System	Intel	Core i9-11900f Firmware	-	All	All	All
Hardware	Intel	Core i9-11900h	-	All	All	All
Operating System	Intel	Core i9-11900h Firmware	-	All	All	All
Hardware	Intel	Core i9-11900k	-	All	All	All
Hardware	Intel	Core i9-11900kf	-	All	All	All
Operating System	Intel	Core i9-11900kf Firmware	-	All	All	All
Operating System	Intel	Core i9-11900k Firmware	-	All	All	All
Hardware	Intel	Core i9-11900t	-	All	All	All
Operating System	Intel	Core i9-11900t Firmware	-	All	All	All
Operating System	Intel	Core i9-11900 Firmware	-	All	All	All
Hardware	Intel	Core i9-11950h	-	All	All	All

Operating System	Intel	Core I9-11950h Firmware	-	All	All	All
Hardware	Intel	Core I9-11980hk	-	All	All	All
Operating System	Intel	Core I9-11980hk Firmware	-	All	All	All
Hardware	Intel	Core I9-9880h	-	All	All	All
Operating System	Intel	Core I9-9880h Firmware	-	All	All	All
Hardware	Intel	Core I9-9900	-	All	All	All
Hardware	Intel	Core I9-9900k	-	All	All	All
Hardware	Intel	Core I9-9900kf	-	All	All	All
Operating System	Intel	Core I9-9900kf Firmware	-	All	All	All
Hardware	Intel	Core I9-9900ks	-	All	All	All
Operating System	Intel	Core I9-9900ks Firmware	-	All	All	All
Operating System	Intel	Core I9-9900k Firmware	-	All	All	All
Hardware	Intel	Core I9-9900t	-	All	All	All
Operating System	Intel	Core I9-9900t Firmware	-	All	All	All
Operating System	Intel	Core I9-9900 Firmware	-	All	All	All
Hardware	Intel	Core I9-9980hk	-	All	All	All
Operating System	Intel	Core I9-9980hk Firmware	-	All	All	All
Hardware	Intel	Xeon E-2314	-	All	All	All
Operating System	Intel	Xeon E-2314 Firmware	-	All	All	All
Hardware	Intel	Xeon E-2324g	-	All	All	All
Operating System	Intel	Xeon E-2324g Firmware	-	All	All	All
Hardware	Intel	Xeon E-2334	-	All	All	All
Operating System	Intel	Xeon E-2334 Firmware	-	All	All	All
Hardware	Intel	Xeon E-2336	-	All	All	All
Operating System	Intel	Xeon E-2336 Firmware	-	All	All	All
Hardware	Intel	Xeon E-2356g	-	All	All	All
Operating System	Intel	Xeon E-2356g Firmware	-	All	All	All
Hardware	Intel	Xeon E-2374g	-	All	All	All
Operating System	Intel	Xeon E-2374g Firmware	-	All	All	All
Hardware	Intel	Xeon E-2378	-	All	All	All
Hardware	Intel	Xeon E-2378g	-	All	All	All
Operating System	Intel	Xeon E-2378g Firmware	-	All	All	All
Operating System	Intel	Xeon E-2378 Firmware	-	All	All	All
Hardware	Intel	Xeon E-2386g	-	All	All	All
Operating System	Intel	Xeon E-2386g Firmware	-	All	All	All

Hardware	Intel	Xeon E-2388g	-	All	All	All
Operating System	Intel	Xeon E-2388g Firmware	-	All	All	All
Hardware	Intel	Xeon W-1350	-	All	All	All
Hardware	Intel	Xeon W-1350p	-	All	All	All
Operating System	Intel	Xeon W-1350p Firmware	-	All	All	All
Operating System	Intel	Xeon W-1350 Firmware	-	All	All	All
Hardware	Intel	Xeon W-1370	-	All	All	All
Hardware	Intel	Xeon W-1370p	-	All	All	All
Operating System	Intel	Xeon W-1370p Firmware	-	All	All	All
Operating System	Intel	Xeon W-1370 Firmware	-	All	All	All
Hardware	Intel	Xeon W-1390	-	All	All	All
Hardware	Intel	Xeon W-1390p	-	All	All	All
Operating System	Intel	Xeon W-1390p Firmware	-	All	All	All
Hardware	Intel	Xeon W-1390t	-	All	All	All
Operating System	Intel	Xeon W-1390t Firmware	-	All	All	All
Operating System	Intel	Xeon W-1390 Firmware	-	All	All	All

## References

Reference	Source	Link	Tags
INTEL-SA-00601	MISC	<a href="http://www.intel.com">www.intel.com</a>	
Intel SA-00601 BIOS Firmware Vulnerabilities in NetApp Products   NetApp Product Security	CONFIRM	<a href="https://security.netapp.com">security.netapp.com</a>	
CVE Program record	CVE.ORG	<a href="http://www.cve.org">www.cve.org</a>	canonical
NVD vulnerability detail	NVD	<a href="https://nvd.nist.gov">nvd.nist.gov</a>	canonical,

No vendor comments have been submitted for this CVE.

There are currently no legacy QID mappings associated with this CVE.

© CVE.report 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](https://www.mitre.org) and the authoritative source of CVE content is [MITRE's CVE web site](https://www.mitre.org). This site includes MITRE data granted under the following [license](https://www.mitre.org).

**CVE.report and Source URL Uptime Status** [status.cve.report](https://status.cve.report)