



# CVE-2022-26047

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

## Summary

<b>CVE</b>	CVE-2022-26047
<b>State</b>	PUBLIC
<b>Assigner</b>	secure@intel.com
<b>Source Priority</b>	CVE Program / NVD first with legacy fallback
<b>Published</b>	2022-11-11 16:15:00 UTC
<b>Updated</b>	2023-09-27 20:53:00 UTC
<b>Description</b>	Improper input validation for some Intel(R) PROSet/Wireless WiFi, Intel vPro(R) CSME WiFi and Killer(TM) WiFi products n

## Risk And Classification

### Problem Types: CWE-20

## NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Application	<a href="#">Intel</a>	<a href="#">Converged Security And Manageability Engine</a>	All	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-1000g1 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-1000g4 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-1000ng4 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-1005g1 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10100e Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10100f Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10100te Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10100t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10100y Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10100 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10105f Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10105t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10105 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10110u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10110y Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I3-10300t Firmware</a>	-	All	All	All

Operating System	Intel	Core I3-10300 Firmware	-	All	All	All
Operating System	Intel	Core I3-10305t Firmware	-	All	All	All
Operating System	Intel	Core I3-10305 Firmware	-	All	All	All
Operating System	Intel	Core I3-10320 Firmware	-	All	All	All
Operating System	Intel	Core I3-10325 Firmware	-	All	All	All
Operating System	Intel	Core I3-11100b Firmware	-	All	All	All
Operating System	Intel	Core I3-11100he Firmware	-	All	All	All
Operating System	Intel	Core I3-1110g4 Firmware	-	All	All	All
Operating System	Intel	Core I3-1115g4e Firmware	-	All	All	All
Operating System	Intel	Core I3-1115g4 Firmware	-	All	All	All
Operating System	Intel	Core I3-1115gre Firmware	-	All	All	All
Operating System	Intel	Core I3-1120g4 Firmware	-	All	All	All
Operating System	Intel	Core I3-1125g4 Firmware	-	All	All	All
Operating System	Intel	Core I3-12100f Firmware	-	All	All	All
Operating System	Intel	Core I3-12100t Firmware	-	All	All	All
Operating System	Intel	Core I3-12100 Firmware	-	All	All	All
Operating System	Intel	Core I3-1210u Firmware	-	All	All	All
Operating System	Intel	Core I3-1215u Firmware	-	All	All	All
Operating System	Intel	Core I3-1220p Firmware	-	All	All	All
Operating System	Intel	Core I3-12300t Firmware	-	All	All	All
Operating System	Intel	Core I3-12300 Firmware	-	All	All	All
Operating System	Intel	Core I3-8000t Firmware	-	All	All	All
Operating System	Intel	Core I3-8000 Firmware	-	All	All	All
Operating System	Intel	Core I3-8020 Firmware	-	All	All	All
Operating System	Intel	Core I3-8100b Firmware	-	All	All	All
Operating System	Intel	Core I3-8100h Firmware	-	All	All	All
Operating System	Intel	Core I3-8100t Firmware	-	All	All	All
Operating System	Intel	Core I3-8100 Firmware	-	All	All	All
Operating System	Intel	Core I3-8109u Firmware	-	All	All	All
Operating System	Intel	Core I3-8120 Firmware	-	All	All	All
Operating System	Intel	Core I3-8121u Firmware	-	All	All	All
Operating System	Intel	Core I3-8130u Firmware	-	All	All	All
Operating System	Intel	Core I3-8140u Firmware	-	All	All	All
Operating System	Intel	Core I3-8145ue Firmware	-	All	All	All
Operating System	Intel	Core I3-8145u Firmware	-	All	All	All

Operating System	Intel	Core I3-8300t Firmware	-	All	All	All
Operating System	Intel	Core I3-8300 Firmware	-	All	All	All
Operating System	Intel	Core I3-8350k Firmware	-	All	All	All
Operating System	Intel	Core I3-9100e Firmware	-	All	All	All
Operating System	Intel	Core I3-9100f Firmware	-	All	All	All
Operating System	Intel	Core I3-9100hl Firmware	-	All	All	All
Operating System	Intel	Core I3-9100te Firmware	-	All	All	All
Operating System	Intel	Core I3-9100t Firmware	-	All	All	All
Operating System	Intel	Core I3-9100 Firmware	-	All	All	All
Operating System	Intel	Core I3-9130u Firmware	-	All	All	All
Operating System	Intel	Core I3-9300t Firmware	-	All	All	All
Operating System	Intel	Core I3-9300 Firmware	-	All	All	All
Operating System	Intel	Core I3-9320 Firmware	-	All	All	All
Operating System	Intel	Core I3-9350kf Firmware	-	All	All	All
Operating System	Intel	Core I3-9350k Firmware	-	All	All	All
Operating System	Intel	Core I5-10110y Firmware	-	All	All	All
Operating System	Intel	Core I5-10200h Firmware	-	All	All	All
Operating System	Intel	Core I5-10210u Firmware	-	All	All	All
Operating System	Intel	Core I5-10210y Firmware	-	All	All	All
Operating System	Intel	Core I5-10300h Firmware	-	All	All	All
Operating System	Intel	Core I5-1030g4 Firmware	-	All	All	All
Operating System	Intel	Core I5-1030g7 Firmware	-	All	All	All
Operating System	Intel	Core I5-1030ng7 Firmware	-	All	All	All
Operating System	Intel	Core I5-10310u Firmware	-	All	All	All
Operating System	Intel	Core I5-10310y Firmware	-	All	All	All
Operating System	Intel	Core I5-1035g1 Firmware	-	All	All	All
Operating System	Intel	Core I5-1035g4 Firmware	-	All	All	All
Operating System	Intel	Core I5-1035g7 Firmware	-	All	All	All
Operating System	Intel	Core I5-1038ng7 Firmware	-	All	All	All
Operating System	Intel	Core I5-10400f Firmware	-	All	All	All
Operating System	Intel	Core I5-10400h Firmware	-	All	All	All
Operating System	Intel	Core I5-10400t Firmware	-	All	All	All
Operating System	Intel	Core I5-10400 Firmware	-	All	All	All
Operating System	Intel	Core I5-10500e Firmware	-	All	All	All
Operating System	Intel	Core I5-10500h Firmware	-	All	All	All

Operating System	<a href="#">Intel</a>	<a href="#">Core i5-10500te Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-10500t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-10500 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-10505 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-10600kf Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-10600k Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-10600t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-10600 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-10610u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11260h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11300h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-1130g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11320h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-1135g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11400f Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11400h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11400t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11400 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-1140g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-1145g7e Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-1145g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-1145gre Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11500b Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11500he Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11500h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11500t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11500 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-1155g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11600kf Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11600k Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11600t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-11600 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-1230u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-1235u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-12400f Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i5-12400t Firmware</a>	-	All	All	All

Operating System	Intel	Core I5-12400 Firmware	-	All	All	All
Operating System	Intel	Core I5-1240p Firmware	-	All	All	All
Operating System	Intel	Core I5-1240u Firmware	-	All	All	All
Operating System	Intel	Core I5-12450hx Firmware	-	All	All	All
Operating System	Intel	Core I5-12450h Firmware	-	All	All	All
Operating System	Intel	Core I5-1245u Firmware	-	All	All	All
Operating System	Intel	Core I5-12500h Firmware	-	All	All	All
Operating System	Intel	Core I5-12500t Firmware	-	All	All	All
Operating System	Intel	Core I5-12500 Firmware	-	All	All	All
Operating System	Intel	Core I5-1250p Firmware	-	All	All	All
Operating System	Intel	Core I5-12600hx Firmware	-	All	All	All
Operating System	Intel	Core I5-12600h Firmware	-	All	All	All
Operating System	Intel	Core I5-12600kf Firmware	-	All	All	All
Operating System	Intel	Core I5-12600k Firmware	-	All	All	All
Operating System	Intel	Core I5-12600t Firmware	-	All	All	All
Operating System	Intel	Core I5-12600 Firmware	-	All	All	All
Operating System	Intel	Core I5-8200y Firmware	-	All	All	All
Operating System	Intel	Core I5-8210y Firmware	-	All	All	All
Operating System	Intel	Core I5-8250u Firmware	-	All	All	All
Operating System	Intel	Core I5-8257u Firmware	-	All	All	All
Operating System	Intel	Core I5-8259u Firmware	-	All	All	All
Operating System	Intel	Core I5-8260u Firmware	-	All	All	All
Operating System	Intel	Core I5-8265u Firmware	-	All	All	All
Operating System	Intel	Core I5-8269u Firmware	-	All	All	All
Operating System	Intel	Core I5-8279u Firmware	-	All	All	All
Operating System	Intel	Core I5-8300h Firmware	-	All	All	All
Operating System	Intel	Core I5-8305g Firmware	-	All	All	All
Operating System	Intel	Core I5-8310y Firmware	-	All	All	All
Operating System	Intel	Core I5-8350u Firmware	-	All	All	All
Operating System	Intel	Core I5-8365ue Firmware	-	All	All	All
Operating System	Intel	Core I5-8365u Firmware	-	All	All	All
Operating System	Intel	Core I5-8400b Firmware	-	All	All	All
Operating System	Intel	Core I5-8400h Firmware	-	All	All	All
Operating System	Intel	Core I5-8400t Firmware	-	All	All	All
Operating System	Intel	Core I5-8400 Firmware	-	All	All	All

Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8420t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8420 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8500b Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8500t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8500 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8550u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8550 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8600k Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8600t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8600 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8650k Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8650 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-8700b Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9300hf Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9300h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9400f Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9400h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9400t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9400 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9500e Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9500f Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9500te Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9500t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9500 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9600kf Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9600k Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9600t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I5-9600 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-10510u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-10510y Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-1060g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-1060ng7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-10610u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-1065g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-1068ng7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-10700e Firmware</a>	-	All	All	All

Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700E Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700f Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700kf Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700k Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700te Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10700 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10710u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10750h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10810u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10850h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10870h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-10875h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11370h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11375h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11390h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11600h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1160g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1165g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11700b Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11700f Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11700kf Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11700k Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11700t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11700 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11800h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1180g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11850he Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-11850h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1185g7e Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1185g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1185gre Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1195g7 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1250u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1255u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core i7-1260p Firmware</a>	-	All	All	All

Operating System	<a href="#">Intel</a>	<a href="#">Core I7-1260u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-12650hx Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-12650h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-1265u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-12700f Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-12700h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-12700kf Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-12700k Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-12700t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-12700 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-1270p Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-12800hx Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-12800h Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-1280p Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-12850hx Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8086k Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8500y Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8510y Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8550u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8557u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8559u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8560u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8565u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8569u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8650u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8665ue Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8665u Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8670t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8670 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8700b Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8700k Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8700t Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8700 Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8705g Firmware</a>	-	All	All	All
Operating System	<a href="#">Intel</a>	<a href="#">Core I7-8706g Firmware</a>	-	All	All	All

Operating System	Intel	Core I7-8706g Firmware	-	All	All	All
Operating System	Intel	Core I7-8709g Firmware	-	All	All	All
Operating System	Intel	Core I7-8750hf Firmware	-	All	All	All
Operating System	Intel	Core I7-8750h Firmware	-	All	All	All
Operating System	Intel	Core I7-8809g Firmware	-	All	All	All
Operating System	Intel	Core I7-8850h Firmware	-	All	All	All
Operating System	Intel	Core I7-9700e Firmware	-	All	All	All
Operating System	Intel	Core I7-9700f Firmware	-	All	All	All
Operating System	Intel	Core I7-9700kf Firmware	-	All	All	All
Operating System	Intel	Core I7-9700k Firmware	-	All	All	All
Operating System	Intel	Core I7-9700te Firmware	-	All	All	All
Operating System	Intel	Core I7-9700t Firmware	-	All	All	All
Operating System	Intel	Core I7-9700 Firmware	-	All	All	All
Operating System	Intel	Core I7-9750hf Firmware	-	All	All	All
Operating System	Intel	Core I7-9750h Firmware	-	All	All	All
Operating System	Intel	Core I7-9800x Firmware	-	All	All	All
Operating System	Intel	Core I7-9850he Firmware	-	All	All	All
Operating System	Intel	Core I7-9850hl Firmware	-	All	All	All
Operating System	Intel	Core I7-9850h Firmware	-	All	All	All
Operating System	Intel	Core I9-10850h Firmware	-	All	All	All
Operating System	Intel	Core I9-10850k Firmware	-	All	All	All
Operating System	Intel	Core I9-10885h Firmware	-	All	All	All
Operating System	Intel	Core I9-10900e Firmware	-	All	All	All
Operating System	Intel	Core I9-10900f Firmware	-	All	All	All
Operating System	Intel	Core I9-10900kf Firmware	-	All	All	All
Operating System	Intel	Core I9-10900k Firmware	-	All	All	All
Operating System	Intel	Core I9-10900te Firmware	-	All	All	All
Operating System	Intel	Core I9-10900t Firmware	-	All	All	All
Operating System	Intel	Core I9-10900x Firmware	-	All	All	All
Operating System	Intel	Core I9-10900 Firmware	-	All	All	All
Operating System	Intel	Core I9-10910 Firmware	-	All	All	All
Operating System	Intel	Core I9-10920x Firmware	-	All	All	All
Operating System	Intel	Core I9-10940x Firmware	-	All	All	All
Operating System	Intel	Core I9-10980hk Firmware	-	All	All	All
Operating System	Intel	Core I9-10980xe Firmware	-	All	All	All
Operating System	Intel	Core I9-11900f Firmware	-	All	All	All

Operating System	Intel	Core i9-11900i Firmware	-	All	All	All
Operating System	Intel	Core i9-11900h Firmware	-	All	All	All
Operating System	Intel	Core i9-11900kb Firmware	-	All	All	All
Operating System	Intel	Core i9-11900kf Firmware	-	All	All	All
Operating System	Intel	Core i9-11900k Firmware	-	All	All	All
Operating System	Intel	Core i9-11900t Firmware	-	All	All	All
Operating System	Intel	Core i9-11900 Firmware	-	All	All	All
Operating System	Intel	Core i9-11950h Firmware	-	All	All	All
Operating System	Intel	Core i9-11980hk Firmware	-	All	All	All
Operating System	Intel	Core i9-12900f Firmware	-	All	All	All
Operating System	Intel	Core i9-12900hk Firmware	-	All	All	All
Operating System	Intel	Core i9-12900hx Firmware	-	All	All	All
Operating System	Intel	Core i9-12900h Firmware	-	All	All	All
Operating System	Intel	Core i9-12900kf Firmware	-	All	All	All
Operating System	Intel	Core i9-12900k Firmware	-	All	All	All
Operating System	Intel	Core i9-12900t Firmware	-	All	All	All
Operating System	Intel	Core i9-12900 Firmware	-	All	All	All
Operating System	Intel	Core i9-12950hx Firmware	-	All	All	All
Operating System	Intel	Core i9-8950hk Firmware	-	All	All	All
Operating System	Intel	Core i9-9800x Firmware	-	All	All	All
Operating System	Intel	Core i9-9820x Firmware	-	All	All	All
Operating System	Intel	Core i9-9880h Firmware	-	All	All	All
Operating System	Intel	Core i9-9900kf Firmware	-	All	All	All
Operating System	Intel	Core i9-9900ks Firmware	-	All	All	All
Operating System	Intel	Core i9-9900k Firmware	-	All	All	All
Operating System	Intel	Core i9-9900t Firmware	-	All	All	All
Operating System	Intel	Core i9-9900x Firmware	-	All	All	All
Operating System	Intel	Core i9-9900 Firmware	-	All	All	All
Operating System	Intel	Core i9-9920x Firmware	-	All	All	All
Operating System	Intel	Core i9-9940x Firmware	-	All	All	All
Operating System	Intel	Core i9-9960x Firmware	-	All	All	All
Operating System	Intel	Core i9-9980hk Firmware	-	All	All	All
Operating System	Intel	Core i9-9980xe Firmware	-	All	All	All
Operating System	Intel	Core i9-9980xe Firmware	-	All	All	All
Hardware	Intel	Killer Wi-fi 6e Ax1675	-	All	All	All
Operating System	Intel	Killer Wi-fi 6e Ax1675 Firmware	-	All	All	All

Hardware	Intel	Killer Wi-fi 6e Ax1690	-	All	All	All
Operating System	Intel	Killer Wi-fi 6e Ax1690 Firmware	-	All	All	All
Hardware	Intel	Killer Wi-fi 6 Ax1650	-	All	All	All
Operating System	Intel	Killer Wi-fi 6 Ax1650 Firmware	-	All	All	All
Application	Intel	Killer Wifi Software	All	All	All	All
Application	Intel	Proset/wireless Wifi	All	All	All	All
Application	Intel	Uefi Wifi Driver	All	All	All	All
Hardware	Intel	Wi-fi 6e Ax210	-	All	All	All
Hardware	Intel	Wi-fi 6e Ax211	-	All	All	All
Hardware	Intel	Wi-fi 6 Ax200	-	All	All	All
Operating System	Intel	Wi-fi 6 Ax200 Firmware	-	All	All	All
Hardware	Intel	Wi-fi 6 Ax201	-	All	All	All
Operating System	Intel	Wi-fi 6 Ax201 Firmware	-	All	All	All
Hardware	Intel	Wi-fi 6 Ax210	-	All	All	All
Operating System	Intel	Wi-fi 6 Ax210 Firmware	-	All	All	All
Hardware	Intel	Wi-fi 6 Ax211	-	All	All	All
Operating System	Intel	Wi-fi 6 Ax211 Firmware	-	All	All	All
Hardware	Intel	Wi-fi 6 Ax411	-	All	All	All
Operating System	Intel	Wi-fi 6 Ax411 Firmware	-	All	All	All

## References

Reference	Source	Link	Tags
INTEL-SA-00699	MISC	<a href="http://www.intel.com">www.intel.com</a>	
CVE Program record	CVE.ORG	<a href="http://www.cve.org">www.cve.org</a>	canonical
NVD vulnerability detail	NVD	<a href="http://nvd.nist.gov">nvd.nist.gov</a>	canonical, analysis

No vendor comments have been submitted for this CVE.

There are currently no legacy QID mappings associated with this CVE.

© CVE.report 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](https://www.mitre.org/) and the authoritative source of CVE content is [MITRE's CVE web site](https://www.mitre.org/cve/). This site includes MITRE data granted under the following [license](https://www.mitre.org/cve/).

