



CVE-2023-2846

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

Summary

CVE	CVE-2023-2846
State	PUBLIC
Assigner	Mitsubishielectric.Psirt@yd.MitsubishiElectric.co.jp
Source Priority	CVE Program / NVD first with legacy fallback
Published	2023-06-30 05:15:00 UTC
Updated	2023-07-10 18:51:00 UTC
Description	Authentication Bypass by Capture-replay vulnerability in Mitsubishi Electric Corporation MELSEC iQ-F Series main module:

Risk And Classification

Problem Types: CWE-294

NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware	Mitsubishielectric	Fx3g-14mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mr/ds	-	All	All	All

Operating System	Mitsubishielectric	Fx3g-24mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mr/es-a	-	All	All	All

Operating System	Mitsubishielectric	Fx3g-60mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-24mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-24mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-24mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-24mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-40mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-40mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-40mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-40mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-60mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-60mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-60mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-60mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3gc-32mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx3gc-32mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3gc-32mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3gc-32mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-24mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-24mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-24mt/dss Firmware	-	All	All	All

Operating System	Mitsubishielectric	Fx3ge-24mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-24mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-24mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-14mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-14mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-14mt/dss Firmware	-	All	All	All

Operating System	Mitsubishielectric	Fx3s-14mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-14mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-14mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mr/es-2ad	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mr/es-2ad Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/es-2ad	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/es-2ad Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/ess	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/ess-2ad	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/ess-2ad Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/es Firmware	-	All	All	All

Hardware	Mitsubishielectric	Fx3sa-10mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-10mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-10mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-10mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-14mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-14mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-14mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-14mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-20mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-20mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-20mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-20mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-30mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-30mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-30mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-30mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mt/ds Firmware	-	All	All	All

Operating System	mitsubishielectric	Fx3u-16mt/os Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mr/ua1	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mr/ua1 Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32ms/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32ms/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mt/dss Firmware	-	All	All	All

Operating System	Mitsubishielectric	Fx3u-48mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mr/ua1	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mr/ua1 Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64ms/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64ms/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mt/dss	-	All	All	All

Operating System	Mitsubishielectric	Fx3u-80mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mr/d-t	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mr/d-t Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mr/ds-t	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mr/ds-t Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mt/d-p4	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mt/d-p4 Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mt/dss	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mt/dss-p4	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mt/dss-p4 Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-32mt-lt	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-32mt-lt-2	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-32mt-lt-2 Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-32mt-lt Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-32mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-32mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-32mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-32mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-64mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-64mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-64mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-64mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-96mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-96mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-96mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-96mt/d Firmware	-	All	All	All

References

Reference	Source	Link	Tags
JVNVU#94519952: 三菱電機製MELSEC-Fシリーズ基本ユニットにおける認証回避の脆弱性	MISC	jvn.jp	
Mitsubishi Electric MELSEC-F Series CISA	MISC	www.cisa.gov	
www.mitsubishielectric.com/en/psirt/vulnerability/pdf/2023-005_en.pdf	MISC	www.mitsubishielectric.com	
CVE Program record	CVE.ORG	www.cve.org	car
NVD vulnerability detail	NVD	nvd.nist.gov	car

No vendor comments have been submitted for this CVE.

There are currently no legacy QID mappings associated with this CVE.

© CVE.report 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](https://www.mitre.org) and the authoritative source of CVE content is [MITRE's CVE web site](https://www.mitre.org). This site includes MITRE data granted under the following [license](https://www.mitre.org).

CVE.report and Source URL Uptime Status status.cve.report