



CVE-2023-34853

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

Summary

CVE	CVE-2023-34853
State	PUBLIC
Assigner	cve@mitre.org
Source Priority	CVE Program / NVD first with legacy fallback
Published	2023-08-22 19:16:00 UTC
Updated	2023-08-29 14:22:00 UTC
Description	Buffer Overflow vulnerability in Supermicro motherboard X12DPG-QR 1.4b allows local attackers to hijack control flow via n

Risk And Classification

Problem Types: CWE-787

NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware	Supermicro	H11dsi	-	All	All	All
Hardware	Supermicro	H11dsi-nt	-	All	All	All
Operating System	Supermicro	H11dsi-nt Firmware	-	All	All	All
Operating System	Supermicro	H11dsi Firmware	-	All	All	All
Hardware	Supermicro	H11dst-b	-	All	All	All
Operating System	Supermicro	H11dst-b Firmware	-	All	All	All
Hardware	Supermicro	H11dsu-in	-	All	All	All
Operating System	Supermicro	H11dsu-in Firmware	-	All	All	All
Hardware	Supermicro	H12dgo-6	-	All	All	All
Operating System	Supermicro	H12dgo-6 Firmware	-	All	All	All
Hardware	Supermicro	H12dgg-nt6	-	All	All	All
Operating System	Supermicro	H12dgg-nt6 Firmware	-	All	All	All
Hardware	Supermicro	H12dsg-o-cpu	-	All	All	All
Operating System	Supermicro	H12dsg-o-cpu Firmware	-	All	All	All
Hardware	Supermicro	H12dsg-q-cpu6	-	All	All	All
Operating System	Supermicro	H12dsg-q-cpu6 Firmware	-	All	All	All
Hardware	Supermicro	H12dsi-n6	-	All	All	All

Operating System	Supermicro	H12dsi-n6 Firmware	-	All	All	All
Hardware	Supermicro	H12dsi-nt6	-	All	All	All
Operating System	Supermicro	H12dsi-nt6 Firmware	-	All	All	All
Hardware	Supermicro	H12dst-b	-	All	All	All
Operating System	Supermicro	H12dst-b Firmware	-	All	All	All
Hardware	Supermicro	H12dsu-in	-	All	All	All
Hardware	Supermicro	H12dsu-inr	-	All	All	All
Operating System	Supermicro	H12dsu-inr Firmware	-	All	All	All
Operating System	Supermicro	H12dsu-in Firmware	-	All	All	All
Hardware	Supermicro	H12ssff-an6	-	All	All	All
Operating System	Supermicro	H12ssff-an6 Firmware	-	All	All	All
Hardware	Supermicro	H12ssfr-an6	-	All	All	All
Operating System	Supermicro	H12ssfr-an6 Firmware	-	All	All	All
Hardware	Supermicro	H12ssg-an6	-	All	All	All
Operating System	Supermicro	H12ssg-an6 Firmware	-	All	All	All
Hardware	Supermicro	H12ssg-anp6	-	All	All	All
Operating System	Supermicro	H12ssg-anp6 Firmware	-	All	All	All
Hardware	Supermicro	H12ssl-c	-	All	All	All
Hardware	Supermicro	H12ssl-ct	-	All	All	All
Operating System	Supermicro	H12ssl-ct Firmware	-	All	All	All
Operating System	Supermicro	H12ssl-c Firmware	-	All	All	All
Hardware	Supermicro	H12ssl-i	-	All	All	All
Operating System	Supermicro	H12ssl-i Firmware	-	All	All	All
Hardware	Supermicro	H12ssl-nt	-	All	All	All
Operating System	Supermicro	H12ssl-nt Firmware	-	All	All	All
Hardware	Supermicro	H12sst-ps	-	All	All	All
Operating System	Supermicro	H12sst-ps Firmware	-	All	All	All
Hardware	Supermicro	H12ssw-an6	-	All	All	All
Operating System	Supermicro	H12ssw-an6 Firmware	-	All	All	All
Hardware	Supermicro	H12ssw-in	-	All	All	All
Hardware	Supermicro	H12ssw-inl	-	All	All	All
Operating System	Supermicro	H12ssw-inl Firmware	-	All	All	All
Hardware	Supermicro	H12ssw-inr	-	All	All	All
Operating System	Supermicro	H12ssw-inr Firmware	-	All	All	All
Operating System	Supermicro	H12ssw-in Firmware	-	All	All	All

Hardware	Supermicro	H12ssw-nt	-	All	All	All
Hardware	Supermicro	H12ssw-ntl	-	All	All	All
Operating System	Supermicro	H12ssw-ntl Firmware	-	All	All	All
Hardware	Supermicro	H12ssw-ntr	-	All	All	All
Operating System	Supermicro	H12ssw-ntr Firmware	-	All	All	All
Operating System	Supermicro	H12ssw-nt Firmware	-	All	All	All
Hardware	Supermicro	H13dsg-o-cpu	-	All	All	All
Hardware	Supermicro	H13dsg-o-cpu-d	-	All	All	All
Operating System	Supermicro	H13dsg-o-cpu-d Firmware	-	All	All	All
Operating System	Supermicro	H13dsg-o-cpu Firmware	-	All	All	All
Hardware	Supermicro	H13dsh	-	All	All	All
Operating System	Supermicro	H13dsh Firmware	-	All	All	All
Hardware	Supermicro	H13sae-mf	-	All	All	All
Operating System	Supermicro	H13sae-mf Firmware	-	All	All	All
Hardware	Supermicro	H13srd-f	-	All	All	All
Operating System	Supermicro	H13srd-f Firmware	-	All	All	All
Hardware	Supermicro	H13ssf	-	All	All	All
Operating System	Supermicro	H13ssf Firmware	-	All	All	All
Hardware	Supermicro	H13ssh	-	All	All	All
Operating System	Supermicro	H13ssh Firmware	-	All	All	All
Hardware	Supermicro	H13ssl-n	-	All	All	All
Hardware	Supermicro	H13ssl-nt	-	All	All	All
Operating System	Supermicro	H13ssl-nt Firmware	-	All	All	All
Operating System	Supermicro	H13ssl-n Firmware	-	All	All	All
Hardware	Supermicro	H13sst-g	-	All	All	All
Hardware	Supermicro	H13sst-gc	-	All	All	All
Operating System	Supermicro	H13sst-gc Firmware	-	All	All	All
Operating System	Supermicro	H13sst-g Firmware	-	All	All	All
Hardware	Supermicro	H13ssw	-	All	All	All
Operating System	Supermicro	H13ssw Firmware	-	All	All	All
Hardware	Supermicro	X11dac	-	All	All	All
Operating System	Supermicro	X11dac Firmware	-	All	All	All
Hardware	Supermicro	X11dai-n	-	All	All	All
Operating System	Supermicro	X11dai-n Firmware	-	All	All	All
Hardware	Supermicro	X11ddw-l	-	All	All	All

Operating System	Supermicro	X11ddw-I Firmware	-	All	All	All
Hardware	Supermicro	X11ddw-nt	-	All	All	All
Operating System	Supermicro	X11ddw-nt Firmware	-	All	All	All
Hardware	Supermicro	X11dgo-t	-	All	All	All
Operating System	Supermicro	X11dgo-t Firmware	-	All	All	All
Hardware	Supermicro	X11dgq	-	All	All	All
Operating System	Supermicro	X11dgq Firmware	-	All	All	All
Hardware	Supermicro	X11dpff-sn	-	All	All	All
Operating System	Supermicro	X11dpff-sn Firmware	-	All	All	All
Hardware	Supermicro	X11dpfr-s	-	All	All	All
Hardware	Supermicro	X11dpfr-sn	-	All	All	All
Operating System	Supermicro	X11dpfr-sn Firmware	-	All	All	All
Operating System	Supermicro	X11dpfr-s Firmware	-	All	All	All
Hardware	Supermicro	X11dpg-ot-cpu	-	All	All	All
Operating System	Supermicro	X11dpg-ot-cpu Firmware	-	All	All	All
Hardware	Supermicro	X11dpg-qt	-	All	All	All
Operating System	Supermicro	X11dpg-qt Firmware	-	All	All	All
Hardware	Supermicro	X11dpg-sn	-	All	All	All
Operating System	Supermicro	X11dpg-sn Firmware	-	All	All	All
Hardware	Supermicro	X11dph-i	-	All	All	All
Operating System	Supermicro	X11dph-i Firmware	-	All	All	All
Hardware	Supermicro	X11dph-t	-	All	All	All
Hardware	Supermicro	X11dph-tq	-	All	All	All
Operating System	Supermicro	X11dph-tq Firmware	-	All	All	All
Operating System	Supermicro	X11dph-t Firmware	-	All	All	All
Hardware	Supermicro	X11dpi-n	-	All	All	All
Hardware	Supermicro	X11dpi-nt	-	All	All	All
Operating System	Supermicro	X11dpi-nt Firmware	-	All	All	All
Operating System	Supermicro	X11dpi-n Firmware	-	All	All	All
Hardware	Supermicro	X11dpl-i	-	All	All	All
Operating System	Supermicro	X11dpl-i Firmware	-	All	All	All
Hardware	Supermicro	X11dps-re	-	All	All	All
Operating System	Supermicro	X11dps-re Firmware	-	All	All	All
Hardware	Supermicro	X11dpt-b	-	All	All	All
Hardware	Supermicro	X11dpt-bh	-	All	All	All
Operating System	Supermicro	X11dpt-bh Firmware	-	All	All	All

Operating System	Supermicro	X11dpt-b Firmware	-	All	All	All
Hardware	Supermicro	X11dpt-l	-	All	All	All
Operating System	Supermicro	X11dpt-l Firmware	-	All	All	All
Hardware	Supermicro	X11dpt-ps	-	All	All	All
Operating System	Supermicro	X11dpt-ps Firmware	-	All	All	All
Hardware	Supermicro	X11dpu	-	All	All	All
Hardware	Supermicro	X11dpu-v	-	All	All	All
Operating System	Supermicro	X11dpu-v Firmware	-	All	All	All
Hardware	Supermicro	X11dpu-x	-	All	All	All
Hardware	Supermicro	X11dpu-xll	-	All	All	All
Operating System	Supermicro	X11dpu-xll Firmware	-	All	All	All
Operating System	Supermicro	X11dpu-x Firmware	-	All	All	All
Hardware	Supermicro	X11dpu-ze	-	All	All	All
Operating System	Supermicro	X11dpu-ze Firmware	-	All	All	All
Hardware	Supermicro	X11dpu-z	-	All	All	All
Operating System	Supermicro	X11dpu-z Firmware	-	All	All	All
Operating System	Supermicro	X11dpu Firmware	-	All	All	All
Hardware	Supermicro	X11dpx-t	-	All	All	All
Operating System	Supermicro	X11dpx-t Firmware	-	All	All	All
Hardware	Supermicro	X11dsc	-	All	All	All
Operating System	Supermicro	X11dsc Firmware	-	All	All	All
Hardware	Supermicro	X11dsf-e	-	All	All	All
Operating System	Supermicro	X11dsf-e Firmware	-	All	All	All
Hardware	Supermicro	X11dsn-ts	-	All	All	All
Hardware	Supermicro	X11dsn-tsq	-	All	All	All
Operating System	Supermicro	X11dsn-tsq Firmware	-	All	All	All
Operating System	Supermicro	X11dsn-ts Firmware	-	All	All	All
Hardware	Supermicro	X11opi-cpu	-	All	All	All
Operating System	Supermicro	X11opi-cpu Firmware	-	All	All	All
Hardware	Supermicro	X11qph	-	All	All	All
Operating System	Supermicro	X11qph Firmware	-	All	All	All
Hardware	Supermicro	X11sae	-	All	All	All
Operating System	Supermicro	X11sae Firmware	-	All	All	All
Hardware	Supermicro	X11sae M	-	All	All	All
Operating System	Supermicro	X11sae M Firmware	-	All	All	All

Hardware	Supermicro	X11sat	-	All	All	All
Operating System	Supermicro	X11sat Firmware	-	All	All	All
Hardware	Supermicro	X11sba	-	All	All	All
Operating System	Supermicro	X11sba Firmware	-	All	All	All
Hardware	Supermicro	X11sca	-	All	All	All
Hardware	Supermicro	X11sca-f	-	All	All	All
Operating System	Supermicro	X11sca-f Firmware	-	All	All	All
Hardware	Supermicro	X11sca-w	-	All	All	All
Operating System	Supermicro	X11sca-w Firmware	-	All	All	All
Operating System	Supermicro	X11sca Firmware	-	All	All	All
Hardware	Supermicro	X11scl-f	-	All	All	All
Operating System	Supermicro	X11scl-f Firmware	-	All	All	All
Hardware	Supermicro	X11sch-f	-	All	All	All
Operating System	Supermicro	X11sch-f Firmware	-	All	All	All
Hardware	Supermicro	X11sch-ln4f	-	All	All	All
Operating System	Supermicro	X11sch-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X11scl-f	-	All	All	All
Operating System	Supermicro	X11scl-f Firmware	-	All	All	All
Hardware	Supermicro	X11scl-if	-	All	All	All
Operating System	Supermicro	X11scl-if Firmware	-	All	All	All
Hardware	Supermicro	X11scl-ln4f	-	All	All	All
Operating System	Supermicro	X11scl-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X11scm-f	-	All	All	All
Operating System	Supermicro	X11scm-f Firmware	-	All	All	All
Hardware	Supermicro	X11scm-ln8f	-	All	All	All
Operating System	Supermicro	X11scm-ln8f Firmware	-	All	All	All
Hardware	Supermicro	X11scw-f	-	All	All	All
Operating System	Supermicro	X11scw-f Firmware	-	All	All	All
Hardware	Supermicro	X11sdd-18c-f	-	All	All	All
Operating System	Supermicro	X11sdd-18c-f Firmware	-	All	All	All
Hardware	Supermicro	X11sdd-8c-f	-	All	All	All
Operating System	Supermicro	X11sdd-8c-f Firmware	-	All	All	All
Hardware	Supermicro	X11sds-12c	-	All	All	All
Operating System	Supermicro	X11sds-12c Firmware	-	All	All	All
Hardware	Supermicro	X11sds-16c	-	All	All	All
Operating System	Supermicro	X11sds-16c Firmware	-	All	All	All

Operating System	Supermicro	X11sds-1bc Firmware	-	All	All	All
Hardware	Supermicro	X11sds-8c	-	All	All	All
Operating System	Supermicro	X11sds-8c Firmware	-	All	All	All
Hardware	Supermicro	X11spa-t	-	All	All	All
Hardware	Supermicro	X11spa-tf	-	All	All	All
Operating System	Supermicro	X11spa-tf Firmware	-	All	All	All
Operating System	Supermicro	X11spa-t Firmware	-	All	All	All
Hardware	Supermicro	X11spg-tf	-	All	All	All
Operating System	Supermicro	X11spg-tf Firmware	-	All	All	All
Hardware	Supermicro	X11sph-nctf	-	All	All	All
Operating System	Supermicro	X11sph-nctf Firmware	-	All	All	All
Hardware	Supermicro	X11sph-nctpf	-	All	All	All
Operating System	Supermicro	X11sph-nctpf Firmware	-	All	All	All
Hardware	Supermicro	X11spi-tf	-	All	All	All
Operating System	Supermicro	X11spi-tf Firmware	-	All	All	All
Hardware	Supermicro	X11spl-f	-	All	All	All
Operating System	Supermicro	X11spl-f Firmware	-	All	All	All
Hardware	Supermicro	X11spm-f	-	All	All	All
Operating System	Supermicro	X11spm-f Firmware	-	All	All	All
Hardware	Supermicro	X11spm-tf	-	All	All	All
Operating System	Supermicro	X11spm-tf Firmware	-	All	All	All
Hardware	Supermicro	X11spm-tpf	-	All	All	All
Operating System	Supermicro	X11spm-tpf Firmware	-	All	All	All
Hardware	Supermicro	X11spw-ctf	-	All	All	All
Operating System	Supermicro	X11spw-ctf Firmware	-	All	All	All
Hardware	Supermicro	X11spw-tf	-	All	All	All
Operating System	Supermicro	X11spw-tf Firmware	-	All	All	All
Hardware	Supermicro	X11sra	-	All	All	All
Operating System	Supermicro	X11sra Firmware	-	All	All	All
Hardware	Supermicro	X11sri-if	-	All	All	All
Operating System	Supermicro	X11sri-if Firmware	-	All	All	All
Hardware	Supermicro	X11srl-f	-	All	All	All
Operating System	Supermicro	X11srl-f Firmware	-	All	All	All
Hardware	Supermicro	X11srm	-	All	All	All
Hardware	Supermicro	X11srm-f	-	All	All	All
Operating System	Supermicro	X11srm-f Firmware	-	All	All	All

Hardware	Supermicro	X11srm-vf	-	All	All	All
Operating System	Supermicro	X11srm-vf Firmware	-	All	All	All
Operating System	Supermicro	X11srm Firmware	-	All	All	All
Hardware	Supermicro	X11ssd-f	-	All	All	All
Operating System	Supermicro	X11ssd-f Firmware	-	All	All	All
Hardware	Supermicro	X11sse-f	-	All	All	All
Operating System	Supermicro	X11sse-f Firmware	-	All	All	All
Hardware	Supermicro	X11ssh-ctf	-	All	All	All
Operating System	Supermicro	X11ssh-ctf Firmware	-	All	All	All
Hardware	Supermicro	X11ssh-f	-	All	All	All
Operating System	Supermicro	X11ssh-f Firmware	-	All	All	All
Hardware	Supermicro	X11ssh-gf-1585	-	All	All	All
Hardware	Supermicro	X11ssh-gf-1585l	-	All	All	All
Operating System	Supermicro	X11ssh-gf-1585l Firmware	-	All	All	All
Operating System	Supermicro	X11ssh-gf-1585 Firmware	-	All	All	All
Hardware	Supermicro	X11ssh-gtf-1585	-	All	All	All
Hardware	Supermicro	X11ssh-gtf-1585l	-	All	All	All
Operating System	Supermicro	X11ssh-gtf-1585l Firmware	-	All	All	All
Operating System	Supermicro	X11ssh-gtf-1585 Firmware	-	All	All	All
Hardware	Supermicro	X11ssh-ln4f	-	All	All	All
Operating System	Supermicro	X11ssh-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X11ssh-tf	-	All	All	All
Operating System	Supermicro	X11ssh-tf Firmware	-	All	All	All
Hardware	Supermicro	X11ssi-ln4f	-	All	All	All
Operating System	Supermicro	X11ssi-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X11ssl	-	All	All	All
Hardware	Supermicro	X11ssl-cf	-	All	All	All
Operating System	Supermicro	X11ssl-cf Firmware	-	All	All	All
Hardware	Supermicro	X11ssl-f	-	All	All	All
Operating System	Supermicro	X11ssl-f Firmware	-	All	All	All
Hardware	Supermicro	X11ssl-nf	-	All	All	All
Operating System	Supermicro	X11ssl-nf Firmware	-	All	All	All
Operating System	Supermicro	X11ssl Firmware	-	All	All	All
Hardware	Supermicro	X11ssm	-	All	All	All
Hardware	Supermicro	X11ssm-f	-	All	All	All

Operating System	Supermicro	X11ssm-f Firmware	-	All	All	All
Operating System	Supermicro	X11ssm Firmware	-	All	All	All
Hardware	Supermicro	X11ssn	-	All	All	All
Operating System	Supermicro	X11ssn Firmware	-	All	All	All
Hardware	Supermicro	X11ssq	-	All	All	All
Hardware	Supermicro	X11ssql	-	All	All	All
Operating System	Supermicro	X11ssql Firmware	-	All	All	All
Operating System	Supermicro	X11ssq Firmware	-	All	All	All
Hardware	Supermicro	X11ssv	-	All	All	All
Hardware	Supermicro	X11ssv-lvds	-	All	All	All
Operating System	Supermicro	X11ssv-lvds Firmware	-	All	All	All
Hardware	Supermicro	X11ssv-q	-	All	All	All
Operating System	Supermicro	X11ssv-q Firmware	-	All	All	All
Operating System	Supermicro	X11ssv Firmware	-	All	All	All
Hardware	Supermicro	X11ssw-4tf	-	All	All	All
Operating System	Supermicro	X11ssw-4tf Firmware	-	All	All	All
Hardware	Supermicro	X11ssw-f	-	All	All	All
Operating System	Supermicro	X11ssw-f Firmware	-	All	All	All
Hardware	Supermicro	X11ssw-tf	-	All	All	All
Operating System	Supermicro	X11ssw-tf Firmware	-	All	All	All
Hardware	Supermicro	X11ssz	-	All	All	All
Hardware	Supermicro	X11ssz-f	-	All	All	All
Operating System	Supermicro	X11ssz-f Firmware	-	All	All	All
Hardware	Supermicro	X11ssz-tln4f	-	All	All	All
Operating System	Supermicro	X11ssz-tln4f Firmware	-	All	All	All
Operating System	Supermicro	X11ssz Firmware	-	All	All	All
Hardware	Supermicro	X12dai-n6	-	All	All	All
Operating System	Supermicro	X12dai-n6 Firmware	-	All	All	All
Hardware	Supermicro	X12ddw-a6	-	All	All	All
Operating System	Supermicro	X12ddw-a6 Firmware	-	All	All	All
Hardware	Supermicro	X12dgo-6	-	All	All	All
Operating System	Supermicro	X12dgo-6 Firmware	-	All	All	All
Hardware	Supermicro	X12dgq-r	-	All	All	All
Operating System	Supermicro	X12dgq-r Firmware	-	All	All	All
Hardware	Supermicro	X12dgu	-	All	All	All
Operating System	Supermicro	X12dgu Firmware	-	All	All	All

Operating System	Supermicro	X12dgm-6	-	All	All	All
Hardware	Supermicro	X12dgm-6	-	All	All	All
Operating System	Supermicro	X12dgm-6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpm-a6m25	-	All	All	All
Operating System	Supermicro	X12dpm-a6m25 Firmware	-	All	All	All
Hardware	Supermicro	X12dpm-an6	-	All	All	All
Operating System	Supermicro	X12dpm-an6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpm-ar	-	All	All	All
Operating System	Supermicro	X12dpm-ar Firmware	-	All	All	All
Hardware	Supermicro	X12dpm-oa6	-	All	All	All
Hardware	Supermicro	X12dpm-oa6-gd2	-	All	All	All
Operating System	Supermicro	X12dpm-oa6-gd2 Firmware	-	All	All	All
Operating System	Supermicro	X12dpm-oa6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpm-qbt6	-	All	All	All
Operating System	Supermicro	X12dpm-qbt6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpm-qr	-	All	All	All
Operating System	Supermicro	X12dpm-qr Firmware	-	All	All	All
Hardware	Supermicro	X12dpm-qt6	-	All	All	All
Operating System	Supermicro	X12dpm-qt6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpm-u6	-	All	All	All
Operating System	Supermicro	X12dpm-u6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpm-n6	-	All	All	All
Operating System	Supermicro	X12dpm-n6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpm-nt6	-	All	All	All
Operating System	Supermicro	X12dpm-nt6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpl-i6	-	All	All	All
Operating System	Supermicro	X12dpl-i6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpl-nt6	-	All	All	All
Operating System	Supermicro	X12dpl-nt6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpt-b6	-	All	All	All
Operating System	Supermicro	X12dpt-b6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpt-pt46	-	All	All	All
Operating System	Supermicro	X12dpt-pt46 Firmware	-	All	All	All
Hardware	Supermicro	X12dpt-pt6	-	All	All	All
Operating System	Supermicro	X12dpt-pt6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpu-6	-	All	All	All

Operating System	Supermicro	X12dpu-6 Firmware	-	All	All	All
Hardware	Supermicro	X12dsc-6	-	All	All	All
Operating System	Supermicro	X12dsc-6 Firmware	-	All	All	All
Hardware	Supermicro	X12qch	-	All	All	All
Operating System	Supermicro	X12qch Firmware	-	All	All	All
Hardware	Supermicro	X12sae	-	All	All	All
Hardware	Supermicro	X12sae-5	-	All	All	All
Operating System	Supermicro	X12sae-5 Firmware	-	All	All	All
Operating System	Supermicro	X12sae Firmware	-	All	All	All
Hardware	Supermicro	X12sca-5f	-	All	All	All
Operating System	Supermicro	X12sca-5f Firmware	-	All	All	All
Hardware	Supermicro	X12sca-f	-	All	All	All
Operating System	Supermicro	X12sca-f Firmware	-	All	All	All
Hardware	Supermicro	X12scq	-	All	All	All
Operating System	Supermicro	X12scq Firmware	-	All	All	All
Hardware	Supermicro	X12scv-lvds	-	All	All	All
Operating System	Supermicro	X12scv-lvds Firmware	-	All	All	All
Hardware	Supermicro	X12scv-w	-	All	All	All
Operating System	Supermicro	X12scv-w Firmware	-	All	All	All
Hardware	Supermicro	X12scz-f	-	All	All	All
Operating System	Supermicro	X12scz-f Firmware	-	All	All	All
Hardware	Supermicro	X12scz-qf	-	All	All	All
Operating System	Supermicro	X12scz-qf Firmware	-	All	All	All
Hardware	Supermicro	X12scz-tln4f	-	All	All	All
Operating System	Supermicro	X12scz-tln4f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-10c-sp6f	-	All	All	All
Operating System	Supermicro	X12sdv-10c-sp6f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-10c-spt4f	-	All	All	All
Operating System	Supermicro	X12sdv-10c-spt4f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-14c-spt8f	-	All	All	All
Operating System	Supermicro	X12sdv-14c-spt8f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-16c-spt8f	-	All	All	All
Operating System	Supermicro	X12sdv-16c-spt8f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-20c-spt8f	-	All	All	All
Operating System	Supermicro	X12sdv-20c-spt8f Firmware	-	All	All	All

Hardware	Supermicro	X12sdv-4c-sp6f	-	All	All	All
Operating System	Supermicro	X12sdv-4c-sp6f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-4c-spt4f	-	All	All	All
Operating System	Supermicro	X12sdv-4c-spt4f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-4c-spt8f	-	All	All	All
Operating System	Supermicro	X12sdv-4c-spt8f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-8c-sp6f	-	All	All	All
Operating System	Supermicro	X12sdv-8c-sp6f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-8c-spt4f	-	All	All	All
Operating System	Supermicro	X12sdv-8c-spt4f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-8c-spt8f	-	All	All	All
Operating System	Supermicro	X12sdv-8c-spt8f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-8ce-sp4f	-	All	All	All
Operating System	Supermicro	X12sdv-8ce-sp4f Firmware	-	All	All	All
Hardware	Supermicro	X12spa-tf	-	All	All	All
Operating System	Supermicro	X12spa-tf Firmware	-	All	All	All
Hardware	Supermicro	X12sped-f	-	All	All	All
Operating System	Supermicro	X12sped-f Firmware	-	All	All	All
Hardware	Supermicro	X12spg-nf	-	All	All	All
Operating System	Supermicro	X12spg-nf Firmware	-	All	All	All
Hardware	Supermicro	X12spi-tf	-	All	All	All
Operating System	Supermicro	X12spi-tf Firmware	-	All	All	All
Hardware	Supermicro	X12spl-f	-	All	All	All
Operating System	Supermicro	X12spl-f Firmware	-	All	All	All
Hardware	Supermicro	X12spl-ln4f	-	All	All	All
Operating System	Supermicro	X12spl-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X12spm-ln4f	-	All	All	All
Operating System	Supermicro	X12spm-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X12spm-ln6tf	-	All	All	All
Operating System	Supermicro	X12spm-ln6tf Firmware	-	All	All	All
Hardware	Supermicro	X12spm-tf	-	All	All	All
Operating System	Supermicro	X12spm-tf Firmware	-	All	All	All
Hardware	Supermicro	X12spo-f	-	All	All	All
Operating System	Supermicro	X12spo-f Firmware	-	All	All	All
Hardware	Supermicro	X12spo-ntf	-	All	All	All
Operating System	Supermicro	X12spo-ntf Firmware	-	All	All	All

Operating System	Supermicro	X12spt-hn-firmware	-	All	All	All
Hardware	Supermicro	X12spt-g	-	All	All	All
Hardware	Supermicro	X12spt-gc	-	All	All	All
Operating System	Supermicro	X12spt-gc Firmware	-	All	All	All
Operating System	Supermicro	X12spt-g Firmware	-	All	All	All
Hardware	Supermicro	X12spt-pt	-	All	All	All
Operating System	Supermicro	X12spt-pt Firmware	-	All	All	All
Hardware	Supermicro	X12spw-f	-	All	All	All
Operating System	Supermicro	X12spw-f Firmware	-	All	All	All
Hardware	Supermicro	X12spw-tf	-	All	All	All
Operating System	Supermicro	X12spw-tf Firmware	-	All	All	All
Hardware	Supermicro	X12spz-ln4f	-	All	All	All
Operating System	Supermicro	X12spz-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X12spz-spln6f	-	All	All	All
Operating System	Supermicro	X12spz-spln6f Firmware	-	All	All	All
Hardware	Supermicro	X12std-f	-	All	All	All
Operating System	Supermicro	X12std-f Firmware	-	All	All	All
Hardware	Supermicro	X12ste-f	-	All	All	All
Operating System	Supermicro	X12ste-f Firmware	-	All	All	All
Hardware	Supermicro	X12sth-f	-	All	All	All
Operating System	Supermicro	X12sth-f Firmware	-	All	All	All
Hardware	Supermicro	X12sth-ln4f	-	All	All	All
Operating System	Supermicro	X12sth-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X12sth-sys	-	All	All	All
Operating System	Supermicro	X12sth-sys Firmware	-	All	All	All
Hardware	Supermicro	X12stl-f	-	All	All	All
Operating System	Supermicro	X12stl-f Firmware	-	All	All	All
Hardware	Supermicro	X12stl-if	-	All	All	All
Operating System	Supermicro	X12stl-if Firmware	-	All	All	All
Hardware	Supermicro	X12stn-c	-	All	All	All
Hardware	Supermicro	X12stn-c-wohs	-	All	All	All
Operating System	Supermicro	X12stn-c-wohs Firmware	-	All	All	All
Operating System	Supermicro	X12stn-c Firmware	-	All	All	All
Hardware	Supermicro	X12stn-e	-	All	All	All
Hardware	Supermicro	X12stn-e-wohs	-	All	All	All
Operating System	Supermicro	X12stn-e-wohs Firmware	-	All	All	All

Operating System	Supermicro	X12stn-e Firmware	-	All	All	All
Hardware	Supermicro	X12stn-h	-	All	All	All
Hardware	Supermicro	X12stn-h-wohs	-	All	All	All
Operating System	Supermicro	X12stn-h-wohs Firmware	-	All	All	All
Operating System	Supermicro	X12stn-h Firmware	-	All	All	All
Hardware	Supermicro	X12stn-l	-	All	All	All
Hardware	Supermicro	X12stn-l-wohs	-	All	All	All
Operating System	Supermicro	X12stn-l-wohs Firmware	-	All	All	All
Operating System	Supermicro	X12stn-l Firmware	-	All	All	All
Hardware	Supermicro	X12stw-f	-	All	All	All
Operating System	Supermicro	X12stw-f Firmware	-	All	All	All
Hardware	Supermicro	X12stw-tf	-	All	All	All
Operating System	Supermicro	X12stw-tf Firmware	-	All	All	All
Hardware	Supermicro	X13dai-t	-	All	All	All
Operating System	Supermicro	X13dai-t Firmware	-	All	All	All
Hardware	Supermicro	X13ddw-a	-	All	All	All
Operating System	Supermicro	X13ddw-a Firmware	-	All	All	All
Hardware	Supermicro	X13deg-oa	-	All	All	All
Hardware	Supermicro	X13deg-oad	-	All	All	All
Operating System	Supermicro	X13deg-oad Firmware	-	All	All	All
Operating System	Supermicro	X13deg-oa Firmware	-	All	All	All
Hardware	Supermicro	X13deg-pvc	-	All	All	All
Operating System	Supermicro	X13deg-pvc Firmware	-	All	All	All
Hardware	Supermicro	X13deg-qt	-	All	All	All
Operating System	Supermicro	X13deg-qt Firmware	-	All	All	All
Hardware	Supermicro	X13dei	-	All	All	All
Hardware	Supermicro	X13dei-t	-	All	All	All
Operating System	Supermicro	X13dei-t Firmware	-	All	All	All
Operating System	Supermicro	X13dei Firmware	-	All	All	All
Hardware	Supermicro	X13dem	-	All	All	All
Operating System	Supermicro	X13dem Firmware	-	All	All	All
Hardware	Supermicro	X13det-b	-	All	All	All
Operating System	Supermicro	X13det-b Firmware	-	All	All	All
Hardware	Supermicro	X13dgu	-	All	All	All
Operating System	Supermicro	X13dgu Firmware	-	All	All	All

Hardware	Supermicro	X13dsf-a	-	All	All	All
Operating System	Supermicro	X13dsf-a Firmware	-	All	All	All
Hardware	Supermicro	X13qeh	-	All	All	All
Operating System	Supermicro	X13qeh Firmware	-	All	All	All
Hardware	Supermicro	X13sae	-	All	All	All
Hardware	Supermicro	X13sae-f	-	All	All	All
Operating System	Supermicro	X13sae-f Firmware	-	All	All	All
Operating System	Supermicro	X13sae Firmware	-	All	All	All
Hardware	Supermicro	X13san-c	-	All	All	All
Hardware	Supermicro	X13san-c-wohs	-	All	All	All
Operating System	Supermicro	X13san-c-wohs Firmware	-	All	All	All
Operating System	Supermicro	X13san-c Firmware	-	All	All	All
Hardware	Supermicro	X13san-e	-	All	All	All
Hardware	Supermicro	X13san-e-wohs	-	All	All	All
Operating System	Supermicro	X13san-e-wohs Firmware	-	All	All	All
Operating System	Supermicro	X13san-e Firmware	-	All	All	All
Hardware	Supermicro	X13san-h	-	All	All	All
Hardware	Supermicro	X13san-h-wohs	-	All	All	All
Operating System	Supermicro	X13san-h-wohs Firmware	-	All	All	All
Operating System	Supermicro	X13san-h Firmware	-	All	All	All
Hardware	Supermicro	X13san-l	-	All	All	All
Hardware	Supermicro	X13san-l-wohs	-	All	All	All
Operating System	Supermicro	X13san-l-wohs Firmware	-	All	All	All
Operating System	Supermicro	X13san-l Firmware	-	All	All	All
Hardware	Supermicro	X13saq	-	All	All	All
Operating System	Supermicro	X13saq Firmware	-	All	All	All
Hardware	Supermicro	X13sav-lvds	-	All	All	All
Operating System	Supermicro	X13sav-lvds Firmware	-	All	All	All
Hardware	Supermicro	X13sav-ps	-	All	All	All
Operating System	Supermicro	X13sav-ps Firmware	-	All	All	All
Hardware	Supermicro	X13saz-f	-	All	All	All
Operating System	Supermicro	X13saz-f Firmware	-	All	All	All
Hardware	Supermicro	X13saz-q	-	All	All	All
Operating System	Supermicro	X13saz-q Firmware	-	All	All	All
Hardware	Supermicro	X13sedw-f	-	All	All	All
Operating System	Supermicro	X13sedw-f Firmware	-	All	All	All

Operating System	Supermicro	X13seed-f Firmware	-	All	All	All
Hardware	Supermicro	X13seed-f	-	All	All	All
Operating System	Supermicro	X13seed-f Firmware	-	All	All	All
Hardware	Supermicro	X13seed-sf	-	All	All	All
Operating System	Supermicro	X13seed-sf Firmware	-	All	All	All
Hardware	Supermicro	X13sefr-a	-	All	All	All
Operating System	Supermicro	X13sefr-a Firmware	-	All	All	All
Hardware	Supermicro	X13sei-f	-	All	All	All
Operating System	Supermicro	X13sei-f Firmware	-	All	All	All
Hardware	Supermicro	X13sei-tf	-	All	All	All
Operating System	Supermicro	X13sei-tf Firmware	-	All	All	All
Hardware	Supermicro	X13sem-f	-	All	All	All
Operating System	Supermicro	X13sem-f Firmware	-	All	All	All
Hardware	Supermicro	X13sem-tf	-	All	All	All
Operating System	Supermicro	X13sem-tf Firmware	-	All	All	All
Hardware	Supermicro	X13set-g	-	All	All	All
Hardware	Supermicro	X13set-gc	-	All	All	All
Operating System	Supermicro	X13set-gc Firmware	-	All	All	All
Operating System	Supermicro	X13set-g Firmware	-	All	All	All
Hardware	Supermicro	X13sew-f	-	All	All	All
Operating System	Supermicro	X13sew-f Firmware	-	All	All	All
Hardware	Supermicro	X13sew-tf	-	All	All	All
Operating System	Supermicro	X13sew-tf Firmware	-	All	All	All
Hardware	Supermicro	X13sra-tf	-	All	All	All
Operating System	Supermicro	X13sra-tf Firmware	-	All	All	All
Hardware	Supermicro	X13srn-e	-	All	All	All
Hardware	Supermicro	X13srn-e-wohs	-	All	All	All
Operating System	Supermicro	X13srn-e-wohs Firmware	-	All	All	All
Operating System	Supermicro	X13srn-e Firmware	-	All	All	All
Hardware	Supermicro	X13srn-h	-	All	All	All
Operating System	Supermicro	X13srn-h Firmware	-	All	All	All

References

Reference	Source	Link	Tags
Supermicro Data Center Server, Blade, Data Storage, AI System	MISC	www.supermicro.com	
Variable Modification Due to Stack Overflow Supermicro	MISC	www.supermicro.com	

CVE Program record	CVE.ORG	www.cve.org	canonical
NVD vulnerability detail	NVD	nvd.nist.gov	canonical, analysis

No vendor comments have been submitted for this CVE.

There are currently no legacy QID mappings associated with this CVE.

© [CVE.report](http://cve.report) 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of The MITRE Corporation and the authoritative source of CVE content is MITRE's CVE web site. This site includes MITRE data granted under the following [license](#).

CVE.report and Source URL Uptime Status status.cve.report