



CVE-2023-35861

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF !\[\]\(e3f8612927870f2e0f9f5989e6dd3064_img.jpg\)](#)

Summary

CVE	CVE-2023-35861
State	PUBLIC
Assigner	cve@mitre.org
Source Priority	CVE Program / NVD first with legacy fallback
Published	2023-07-31 13:15:00 UTC
Updated	2023-08-07 19:19:00 UTC
Description	A shell-injection vulnerability in email notifications on Supermicro motherboards (such as H12DST-B before 03.10.35) allow

Risk And Classification

Problem Types: CWE-78

NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware	Supermicro	H12dgo-6	-	All	All	All
Operating System	Supermicro	H12dgo-6 Firmware	-	All	All	All
Hardware	Supermicro	H12dgg-nt6	-	All	All	All
Operating System	Supermicro	H12dgg-nt6 Firmware	-	All	All	All
Hardware	Supermicro	H12dsg-o-cpu	-	All	All	All
Operating System	Supermicro	H12dsg-o-cpu Firmware	-	All	All	All
Hardware	Supermicro	H12dsg-q-cpu6	-	All	All	All
Operating System	Supermicro	H12dsg-q-cpu6 Firmware	-	All	All	All
Hardware	Supermicro	H12dsi-n6	-	All	All	All
Operating System	Supermicro	H12dsi-n6 Firmware	-	All	All	All
Hardware	Supermicro	H12dsi-nt6	-	All	All	All
Operating System	Supermicro	H12dsi-nt6 Firmware	-	All	All	All
Hardware	Supermicro	H12dst-b	-	All	All	All
Operating System	Supermicro	H12dst-b Firmware	All	All	All	All
Operating System	Supermicro	H12dst-b Firmware	-	All	All	All
Hardware	Supermicro	H12dsu-in	-	All	All	All
Hardware	Supermicro	H12dsu-inr	-	All	All	All

Operating System	Supermicro	H12dsu-inr Firmware	-	All	All	All
Operating System	Supermicro	H12dsu-in Firmware	-	All	All	All
Hardware	Supermicro	H12ssff-an6	-	All	All	All
Operating System	Supermicro	H12ssff-an6 Firmware	-	All	All	All
Hardware	Supermicro	H12ssfr-an6	-	All	All	All
Operating System	Supermicro	H12ssfr-an6 Firmware	-	All	All	All
Hardware	Supermicro	H12ssg-an6	-	All	All	All
Operating System	Supermicro	H12ssg-an6 Firmware	-	All	All	All
Hardware	Supermicro	H12ssg-anp6	-	All	All	All
Operating System	Supermicro	H12ssg-anp6 Firmware	-	All	All	All
Hardware	Supermicro	H12ssl-c	-	All	All	All
Hardware	Supermicro	H12ssl-ct	-	All	All	All
Operating System	Supermicro	H12ssl-ct Firmware	-	All	All	All
Operating System	Supermicro	H12ssl-c Firmware	-	All	All	All
Hardware	Supermicro	H12ssl-i	-	All	All	All
Operating System	Supermicro	H12ssl-i Firmware	-	All	All	All
Hardware	Supermicro	H12ssl-nt	-	All	All	All
Operating System	Supermicro	H12ssl-nt Firmware	-	All	All	All
Hardware	Supermicro	H12sst-ps	-	All	All	All
Operating System	Supermicro	H12sst-ps Firmware	-	All	All	All
Hardware	Supermicro	H12ssw-an6	-	All	All	All
Operating System	Supermicro	H12ssw-an6 Firmware	-	All	All	All
Hardware	Supermicro	H12ssw-in	-	All	All	All
Hardware	Supermicro	H12ssw-inl	-	All	All	All
Operating System	Supermicro	H12ssw-inl Firmware	-	All	All	All
Hardware	Supermicro	H12ssw-inr	-	All	All	All
Operating System	Supermicro	H12ssw-inr Firmware	-	All	All	All
Operating System	Supermicro	H12ssw-in Firmware	-	All	All	All
Hardware	Supermicro	H12ssw-nt	-	All	All	All
Hardware	Supermicro	H12ssw-ntl	-	All	All	All
Operating System	Supermicro	H12ssw-ntl Firmware	-	All	All	All
Hardware	Supermicro	H12ssw-ntr	-	All	All	All
Operating System	Supermicro	H12ssw-ntr Firmware	-	All	All	All
Operating System	Supermicro	H12ssw-nt Firmware	-	All	All	All
Hardware	Supermicro	H13dsg-o-cpu	-	All	All	All

Hardware	Supermicro	H13dsg-o-cpu-d	-	All	All	All
Operating System	Supermicro	H13dsg-o-cpu-d Firmware	-	All	All	All
Operating System	Supermicro	H13dsg-o-cpu Firmware	-	All	All	All
Hardware	Supermicro	H13dsh	-	All	All	All
Operating System	Supermicro	H13dsh Firmware	-	All	All	All
Hardware	Supermicro	H13sae-mf	-	All	All	All
Operating System	Supermicro	H13sae-mf Firmware	-	All	All	All
Hardware	Supermicro	H13srd-f	-	All	All	All
Operating System	Supermicro	H13srd-f Firmware	-	All	All	All
Hardware	Supermicro	H13ssf	-	All	All	All
Operating System	Supermicro	H13ssf Firmware	-	All	All	All
Hardware	Supermicro	H13ssh	-	All	All	All
Operating System	Supermicro	H13ssh Firmware	-	All	All	All
Hardware	Supermicro	H13ssl-n	-	All	All	All
Hardware	Supermicro	H13ssl-nt	-	All	All	All
Operating System	Supermicro	H13ssl-nt Firmware	-	All	All	All
Operating System	Supermicro	H13ssl-n Firmware	-	All	All	All
Hardware	Supermicro	H13sst-g	-	All	All	All
Hardware	Supermicro	H13sst-gc	-	All	All	All
Operating System	Supermicro	H13sst-gc Firmware	-	All	All	All
Operating System	Supermicro	H13sst-g Firmware	-	All	All	All
Hardware	Supermicro	H13ssw	-	All	All	All
Operating System	Supermicro	H13ssw Firmware	-	All	All	All
Hardware	Supermicro	X12dai-n6	-	All	All	All
Operating System	Supermicro	X12dai-n6 Firmware	-	All	All	All
Hardware	Supermicro	X12ddw-a6	-	All	All	All
Operating System	Supermicro	X12ddw-a6 Firmware	-	All	All	All
Hardware	Supermicro	X12dgo-6	-	All	All	All
Operating System	Supermicro	X12dgo-6 Firmware	-	All	All	All
Hardware	Supermicro	X12dgq-r	-	All	All	All
Operating System	Supermicro	X12dgq-r Firmware	-	All	All	All
Hardware	Supermicro	X12dgu	-	All	All	All
Operating System	Supermicro	X12dgu Firmware	-	All	All	All
Hardware	Supermicro	X12dhm-6	-	All	All	All
Operating System	Supermicro	X12dhm-6 Firmware	-	All	All	All

Hardware	Supermicro	X12dpd-a6m25	-	All	All	All
Operating System	Supermicro	X12dpd-a6m25 Firmware	-	All	All	All
Hardware	Supermicro	X12dpfr-an6	-	All	All	All
Operating System	Supermicro	X12dpfr-an6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpg-ar	-	All	All	All
Operating System	Supermicro	X12dpg-ar Firmware	-	All	All	All
Hardware	Supermicro	X12dpg-oa6	-	All	All	All
Hardware	Supermicro	X12dpg-oa6-gd2	-	All	All	All
Operating System	Supermicro	X12dpg-oa6-gd2 Firmware	-	All	All	All
Operating System	Supermicro	X12dpg-oa6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpg-qbt6	-	All	All	All
Operating System	Supermicro	X12dpg-qbt6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpg-qr	-	All	All	All
Operating System	Supermicro	X12dpg-qr Firmware	-	All	All	All
Hardware	Supermicro	X12dpg-qt6	-	All	All	All
Operating System	Supermicro	X12dpg-qt6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpg-u6	-	All	All	All
Operating System	Supermicro	X12dpg-u6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpi-n6	-	All	All	All
Operating System	Supermicro	X12dpi-n6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpi-nt6	-	All	All	All
Operating System	Supermicro	X12dpi-nt6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpl-i6	-	All	All	All
Operating System	Supermicro	X12dpl-i6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpl-nt6	-	All	All	All
Operating System	Supermicro	X12dpl-nt6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpt-b6	-	All	All	All
Operating System	Supermicro	X12dpt-b6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpt-pt46	-	All	All	All
Operating System	Supermicro	X12dpt-pt46 Firmware	-	All	All	All
Hardware	Supermicro	X12dpt-pt6	-	All	All	All
Operating System	Supermicro	X12dpt-pt6 Firmware	-	All	All	All
Hardware	Supermicro	X12dpu-6	-	All	All	All
Operating System	Supermicro	X12dpu-6 Firmware	-	All	All	All
Hardware	Supermicro	X12dsc-6	-	All	All	All
Operating System	Supermicro	X12dsc-6 Firmware	-	All	All	All

Hardware	Supermicro	X12qch	-	All	All	All
Operating System	Supermicro	X12qch Firmware	-	All	All	All
Hardware	Supermicro	X12sae	-	All	All	All
Hardware	Supermicro	X12sae-5	-	All	All	All
Operating System	Supermicro	X12sae-5 Firmware	-	All	All	All
Operating System	Supermicro	X12sae Firmware	-	All	All	All
Hardware	Supermicro	X12sca-5f	-	All	All	All
Operating System	Supermicro	X12sca-5f Firmware	-	All	All	All
Hardware	Supermicro	X12sca-f	-	All	All	All
Operating System	Supermicro	X12sca-f Firmware	-	All	All	All
Hardware	Supermicro	X12scq	-	All	All	All
Operating System	Supermicro	X12scq Firmware	-	All	All	All
Hardware	Supermicro	X12scv-lvds	-	All	All	All
Operating System	Supermicro	X12scv-lvds Firmware	-	All	All	All
Hardware	Supermicro	X12scv-w	-	All	All	All
Operating System	Supermicro	X12scv-w Firmware	-	All	All	All
Hardware	Supermicro	X12scz-f	-	All	All	All
Operating System	Supermicro	X12scz-f Firmware	-	All	All	All
Hardware	Supermicro	X12scz-qf	-	All	All	All
Operating System	Supermicro	X12scz-qf Firmware	-	All	All	All
Hardware	Supermicro	X12scz-tln4f	-	All	All	All
Operating System	Supermicro	X12scz-tln4f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-10c-sp6f	-	All	All	All
Operating System	Supermicro	X12sdv-10c-sp6f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-10c-spt4f	-	All	All	All
Operating System	Supermicro	X12sdv-10c-spt4f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-14c-spt8f	-	All	All	All
Operating System	Supermicro	X12sdv-14c-spt8f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-16c-spt8f	-	All	All	All
Operating System	Supermicro	X12sdv-16c-spt8f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-20c-spt8f	-	All	All	All
Operating System	Supermicro	X12sdv-20c-spt8f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-4c-sp6f	-	All	All	All
Operating System	Supermicro	X12sdv-4c-sp6f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-4c-spt4f	-	All	All	All

Operating System	Supermicro	X12sdv-4c-spt4f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-4c-spt8f	-	All	All	All
Operating System	Supermicro	X12sdv-4c-spt8f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-8c-sp6f	-	All	All	All
Operating System	Supermicro	X12sdv-8c-sp6f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-8c-spt4f	-	All	All	All
Operating System	Supermicro	X12sdv-8c-spt4f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-8c-spt8f	-	All	All	All
Operating System	Supermicro	X12sdv-8c-spt8f Firmware	-	All	All	All
Hardware	Supermicro	X12sdv-8ce-sp4f	-	All	All	All
Operating System	Supermicro	X12sdv-8ce-sp4f Firmware	-	All	All	All
Hardware	Supermicro	X12spa-tf	-	All	All	All
Operating System	Supermicro	X12spa-tf Firmware	-	All	All	All
Hardware	Supermicro	X12sped-f	-	All	All	All
Operating System	Supermicro	X12sped-f Firmware	-	All	All	All
Hardware	Supermicro	X12spg-nf	-	All	All	All
Operating System	Supermicro	X12spg-nf Firmware	-	All	All	All
Hardware	Supermicro	X12spi-tf	-	All	All	All
Operating System	Supermicro	X12spi-tf Firmware	-	All	All	All
Hardware	Supermicro	X12spl-f	-	All	All	All
Operating System	Supermicro	X12spl-f Firmware	-	All	All	All
Hardware	Supermicro	X12spl-ln4f	-	All	All	All
Operating System	Supermicro	X12spl-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X12spm-ln4f	-	All	All	All
Operating System	Supermicro	X12spm-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X12spm-ln6tf	-	All	All	All
Operating System	Supermicro	X12spm-ln6tf Firmware	-	All	All	All
Hardware	Supermicro	X12spm-tf	-	All	All	All
Operating System	Supermicro	X12spm-tf Firmware	-	All	All	All
Hardware	Supermicro	X12spo-f	-	All	All	All
Operating System	Supermicro	X12spo-f Firmware	-	All	All	All
Hardware	Supermicro	X12spo-ntf	-	All	All	All
Operating System	Supermicro	X12spo-ntf Firmware	-	All	All	All
Hardware	Supermicro	X12spt-g	-	All	All	All
Hardware	Supermicro	X12spt-gc	-	All	All	All
Operating System	Supermicro	X12spt-gc Firmware	-	All	All	All

Operating System	Supermicro	X12spt-gc Firmware	-	All	All	All
Operating System	Supermicro	X12spt-g Firmware	-	All	All	All
Hardware	Supermicro	X12spt-pt	-	All	All	All
Operating System	Supermicro	X12spt-pt Firmware	-	All	All	All
Hardware	Supermicro	X12spw-f	-	All	All	All
Operating System	Supermicro	X12spw-f Firmware	-	All	All	All
Hardware	Supermicro	X12spw-tf	-	All	All	All
Operating System	Supermicro	X12spw-tf Firmware	-	All	All	All
Hardware	Supermicro	X12spz-ln4f	-	All	All	All
Operating System	Supermicro	X12spz-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X12spz-spln6f	-	All	All	All
Operating System	Supermicro	X12spz-spln6f Firmware	-	All	All	All
Hardware	Supermicro	X12std-f	-	All	All	All
Operating System	Supermicro	X12std-f Firmware	-	All	All	All
Hardware	Supermicro	X12ste-f	-	All	All	All
Operating System	Supermicro	X12ste-f Firmware	-	All	All	All
Hardware	Supermicro	X12sth-f	-	All	All	All
Operating System	Supermicro	X12sth-f Firmware	-	All	All	All
Hardware	Supermicro	X12sth-ln4f	-	All	All	All
Operating System	Supermicro	X12sth-ln4f Firmware	-	All	All	All
Hardware	Supermicro	X12sth-sys	-	All	All	All
Operating System	Supermicro	X12sth-sys Firmware	-	All	All	All
Hardware	Supermicro	X12stl-f	-	All	All	All
Operating System	Supermicro	X12stl-f Firmware	-	All	All	All
Hardware	Supermicro	X12stl-if	-	All	All	All
Operating System	Supermicro	X12stl-if Firmware	-	All	All	All
Hardware	Supermicro	X12stn-c	-	All	All	All
Hardware	Supermicro	X12stn-c-wohs	-	All	All	All
Operating System	Supermicro	X12stn-c-wohs Firmware	-	All	All	All
Operating System	Supermicro	X12stn-c Firmware	-	All	All	All
Hardware	Supermicro	X12stn-e	-	All	All	All
Hardware	Supermicro	X12stn-e-wohs	-	All	All	All
Operating System	Supermicro	X12stn-e-wohs Firmware	-	All	All	All
Operating System	Supermicro	X12stn-e Firmware	-	All	All	All
Hardware	Supermicro	X12stn-h	-	All	All	All
Hardware	Supermicro	X12stn-h-wohs	-	All	All	All

Operating System	Supermicro	X12stn-h-wohs Firmware	-	All	All	All
Operating System	Supermicro	X12stn-h Firmware	-	All	All	All
Hardware	Supermicro	X12stn-l	-	All	All	All
Hardware	Supermicro	X12stn-l-wohs	-	All	All	All
Operating System	Supermicro	X12stn-l-wohs Firmware	-	All	All	All
Operating System	Supermicro	X12stn-l Firmware	-	All	All	All
Hardware	Supermicro	X12stw-f	-	All	All	All
Operating System	Supermicro	X12stw-f Firmware	-	All	All	All
Hardware	Supermicro	X12stw-tf	-	All	All	All
Operating System	Supermicro	X12stw-tf Firmware	-	All	All	All
Hardware	Supermicro	X13dai-t	-	All	All	All
Operating System	Supermicro	X13dai-t Firmware	-	All	All	All
Hardware	Supermicro	X13ddw-a	-	All	All	All
Operating System	Supermicro	X13ddw-a Firmware	-	All	All	All
Hardware	Supermicro	X13deg-oa	-	All	All	All
Hardware	Supermicro	X13deg-oad	-	All	All	All
Operating System	Supermicro	X13deg-oad Firmware	-	All	All	All
Operating System	Supermicro	X13deg-oa Firmware	-	All	All	All
Hardware	Supermicro	X13deg-pvc	-	All	All	All
Operating System	Supermicro	X13deg-pvc Firmware	-	All	All	All
Hardware	Supermicro	X13deg-qt	-	All	All	All
Operating System	Supermicro	X13deg-qt Firmware	-	All	All	All
Hardware	Supermicro	X13dei	-	All	All	All
Hardware	Supermicro	X13dei-t	-	All	All	All
Operating System	Supermicro	X13dei-t Firmware	-	All	All	All
Operating System	Supermicro	X13dei Firmware	-	All	All	All
Hardware	Supermicro	X13dem	-	All	All	All
Operating System	Supermicro	X13dem Firmware	-	All	All	All
Hardware	Supermicro	X13det-b	-	All	All	All
Operating System	Supermicro	X13det-b Firmware	-	All	All	All
Hardware	Supermicro	X13dgu	-	All	All	All
Operating System	Supermicro	X13dgu Firmware	-	All	All	All
Hardware	Supermicro	X13dsf-a	-	All	All	All
Operating System	Supermicro	X13dsf-a Firmware	-	All	All	All
Hardware	Supermicro	X13qeh	-	All	All	All

Operating System	Supermicro	X13qeh Firmware	-	All	All	All
Hardware	Supermicro	X13sae	-	All	All	All
Hardware	Supermicro	X13sae-f	-	All	All	All
Operating System	Supermicro	X13sae-f Firmware	-	All	All	All
Operating System	Supermicro	X13sae Firmware	-	All	All	All
Hardware	Supermicro	X13san-c	-	All	All	All
Hardware	Supermicro	X13san-c-wohs	-	All	All	All
Operating System	Supermicro	X13san-c-wohs Firmware	-	All	All	All
Operating System	Supermicro	X13san-c Firmware	-	All	All	All
Hardware	Supermicro	X13san-e	-	All	All	All
Hardware	Supermicro	X13san-e-wohs	-	All	All	All
Operating System	Supermicro	X13san-e-wohs Firmware	-	All	All	All
Operating System	Supermicro	X13san-e Firmware	-	All	All	All
Hardware	Supermicro	X13san-h	-	All	All	All
Hardware	Supermicro	X13san-h-wohs	-	All	All	All
Operating System	Supermicro	X13san-h-wohs Firmware	-	All	All	All
Operating System	Supermicro	X13san-h Firmware	-	All	All	All
Hardware	Supermicro	X13san-l	-	All	All	All
Hardware	Supermicro	X13san-l-wohs	-	All	All	All
Operating System	Supermicro	X13san-l-wohs Firmware	-	All	All	All
Operating System	Supermicro	X13san-l Firmware	-	All	All	All
Hardware	Supermicro	X13saq	-	All	All	All
Operating System	Supermicro	X13saq Firmware	-	All	All	All
Hardware	Supermicro	X13sav-lvds	-	All	All	All
Operating System	Supermicro	X13sav-lvds Firmware	-	All	All	All
Hardware	Supermicro	X13sav-ps	-	All	All	All
Operating System	Supermicro	X13sav-ps Firmware	-	All	All	All
Hardware	Supermicro	X13saz-f	-	All	All	All
Operating System	Supermicro	X13saz-f Firmware	-	All	All	All
Hardware	Supermicro	X13saz-q	-	All	All	All
Operating System	Supermicro	X13saz-q Firmware	-	All	All	All
Hardware	Supermicro	X13sedw-f	-	All	All	All
Operating System	Supermicro	X13sedw-f Firmware	-	All	All	All
Hardware	Supermicro	X13seed-f	-	All	All	All
Operating System	Supermicro	X13seed-f Firmware	-	All	All	All
Hardware	Supermicro	X13seed-f	-	All	All	All

Hardware	Supermicro	X13seu-si	-	All	All	All
Operating System	Supermicro	X13seed-sf Firmware	-	All	All	All
Hardware	Supermicro	X13sefr-a	-	All	All	All
Operating System	Supermicro	X13sefr-a Firmware	-	All	All	All
Hardware	Supermicro	X13sei-f	-	All	All	All
Operating System	Supermicro	X13sei-f Firmware	-	All	All	All
Hardware	Supermicro	X13sei-tf	-	All	All	All
Operating System	Supermicro	X13sei-tf Firmware	-	All	All	All
Hardware	Supermicro	X13sem-f	-	All	All	All
Operating System	Supermicro	X13sem-f Firmware	-	All	All	All
Hardware	Supermicro	X13sem-tf	-	All	All	All
Operating System	Supermicro	X13sem-tf Firmware	-	All	All	All
Hardware	Supermicro	X13set-g	-	All	All	All
Hardware	Supermicro	X13set-gc	-	All	All	All
Operating System	Supermicro	X13set-gc Firmware	-	All	All	All
Operating System	Supermicro	X13set-g Firmware	-	All	All	All
Hardware	Supermicro	X13sew-f	-	All	All	All
Operating System	Supermicro	X13sew-f Firmware	-	All	All	All
Hardware	Supermicro	X13sew-tf	-	All	All	All
Operating System	Supermicro	X13sew-tf Firmware	-	All	All	All
Hardware	Supermicro	X13sra-tf	-	All	All	All
Operating System	Supermicro	X13sra-tf Firmware	-	All	All	All
Hardware	Supermicro	X13srn-e	-	All	All	All
Hardware	Supermicro	X13srn-e-wohs	-	All	All	All
Operating System	Supermicro	X13srn-e-wohs Firmware	-	All	All	All
Operating System	Supermicro	X13srn-e Firmware	-	All	All	All
Hardware	Supermicro	X13srn-h	-	All	All	All
Hardware	Supermicro	X13srn-h-wohs	-	All	All	All
Operating System	Supermicro	X13srn-h-wohs Firmware	-	All	All	All
Operating System	Supermicro	X13srn-h Firmware	-	All	All	All
Hardware	Supermicro	X13swa-tf	-	All	All	All
Operating System	Supermicro	X13swa-tf Firmware	-	All	All	All

References

Reference	Source	Link	Tags
Shell injection in the SMTP notifications Supermicro	MISC	www.supermicro.com	

Technologically Advanced High-End Motherboards Supermicro	MISC	www.supermicro.com	
Exploiting Supermicro BMCs So I Can Sleep At Night freax13's blog	MISC	blog.freax13.de	
CVE Program record	CVE.ORG	www.cve.org	canonical
NVD vulnerability detail	NVD	nvd.nist.gov	canonical, analysis

No vendor comments have been submitted for this CVE.

There are currently no legacy QID mappings associated with this CVE.

© [CVE.report](https://cve.report) 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](https://www.mitre.org) and the authoritative source of CVE content is [MITRE's CVE web site](https://www.mitre.org/cve). This site includes MITRE data granted under the following [license](#).

CVE.report and Source URL Uptime Status status.cve.report