



CVE-2023-4699

[MITRE](#)[NVD](#)[CVE.ORG](#)[Print: PDF](#)

Summary

CVE	CVE-2023-4699
State	PUBLIC
Assigner	Mitsubishielectric.Psirt@yd.MitsubishiElectric.co.jp
Source Priority	CVE Program / NVD first with legacy fallback
Published	2023-11-06 06:15:00 UTC
Updated	2023-11-14 19:10:00 UTC
Description	Insufficient Verification of Data Authenticity vulnerability in Mitsubishi Electric Corporation MELSEC-F Series main modules

Risk And Classification

Problem Types: CWE-345

NVD Known Affected Configurations (CPE 2.3)

Type	Vendor	Product	Version	Update	Edition	Language
Hardware	Mitsubishielectric	Fx3g-14mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-14mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-14mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mr/ds	-	All	All	All

Operating System	Mitsubishielectric	Fx3g-24mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-24mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-24mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-40mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-40mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mr/es-a	-	All	All	All

Operating System	Mitsubishielectric	Fx3g-60mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3g-60mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3g-60mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-24mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-24mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-24mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-24mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-40mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-40mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-40mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-40mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-60mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-60mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ga-60mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3ga-60mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3gc-32mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx3gc-32mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3gc-32mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3gc-32mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-24mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-24mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-24mt/dss Firmware	-	All	All	All

Operating System	Mitsubishielectric	Fx3ge-24mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-24mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-24mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-24mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3ge-40mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3ge-40mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-10mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-10mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-14mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-14mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-14mt/dss Firmware	-	All	All	All

Operating System	Mitsubishielectric	Fx3s-14mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-14mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-14mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-14mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-20mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-20mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mr/es-2ad	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mr/es-2ad Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/es-2ad	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/es-2ad Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/ess	-	All	All	All
Hardware	Mitsubishielectric	Fx3s-30mt/ess-2ad	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/ess-2ad Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3s-30mt/es Firmware	-	All	All	All

Hardware	Mitsubishielectric	Fx3sa-10mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-10mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-10mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-10mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-14mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-14mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-14mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-14mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-20mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-20mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-20mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-20mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-30mr-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-30mr-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3sa-30mt-cm	-	All	All	All
Operating System	Mitsubishielectric	Fx3sa-30mt-cm Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mt/e	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-128mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-128mt/e Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mr/es-a	-	All	All	All

Hardware	mitsubisnielectric	Fx3u-16mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-16mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-16mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mr/ua1	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mr/ua1 Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32ms/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32ms/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-32mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-32mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mr/es	-	All	All	All

Hardware	Mitsubishielectric	Fx3u-48mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-48mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-48mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mr/ua1	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mr/ua1 Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64ms/es	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64ms/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-64mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-64mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mr/ds Firmware	-	All	All	All

Hardware	Mitsubishielectric	Fx3u-80mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3u-80mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3u-80mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mr/d-t	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mr/d-t Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mr/ds-t	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mr/ds-t Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mt/d-p4	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mt/d-p4 Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mt/dss	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-16mt/dss-p4	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mt/dss-p4 Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-16mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-32mt-lt	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-32mt-lt-2	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-32mt-lt-2 Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-32mt-lt Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-32mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-32mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-32mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-32mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-64mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-64mt/dss	-	All	All	All

Hardware	Mitsubishielectric	Fx3uc-64mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-64mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-64mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-96mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx3uc-96mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-96mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx3uc-96mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-30mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-30mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-30mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-30mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-30mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-30mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-40mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-40mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-40mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-40mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-40mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-40mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-60mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-60mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-60mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-60mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-60mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-60mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-80mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-80mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-80mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5s-80mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-80mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5s-80mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-32mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-32mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-32mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-32mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-32mt/ds	-	All	All	All

Hardware	Mitsubishielectric	Fx5u-32mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-32mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-32mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-32mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-32mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-32mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-32mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-64mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-64mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-64mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-64mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-64mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-64mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-64mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-64mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-64mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-64mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-64mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-64mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-80mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-80mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-80mr/es	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-80mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-80mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-80mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-80mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-80mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-80mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5u-80mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-80mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5u-80mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uc-32mr/ds-ts	-	All	All	All
Operating System	Mitsubishielectric	Fx5uc-32mr/ds-ts Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uc-32mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx5uc-32mt/ds-ts	-	All	All	All

Operating System	Mitsubishielectric	Fx5uc-32mt/ds-ts Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uc-32mt/dss	-	All	All	All
Hardware	Mitsubishielectric	Fx5uc-32mt/dss-ts	-	All	All	All
Operating System	Mitsubishielectric	Fx5uc-32mt/dss-ts Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uc-32mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uc-32mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uc-64mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx5uc-64mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx5uc-64mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uc-64mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uc-96mt/d	-	All	All	All
Hardware	Mitsubishielectric	Fx5uc-96mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx5uc-96mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uc-96mt/d Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-24mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-24mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-24mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-24mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-24mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-24mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-24mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-24mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-24mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-24mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-24mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-24mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-24mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-24mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-24mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-24mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-40mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-40mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-40mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-40mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-40mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5ui-40mr/es Firmware	-	All	All	All

Operating System	Mitsubishielectric	Fx5uj-40mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-40mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-40mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-40mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-40mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-40mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-40mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-40mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-40mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-40mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-40mt/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-60mr/ds	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-60mr/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-60mr/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-60mr/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-60mr/es-a Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-60mr/es Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-60mt/ds	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-60mt/dss	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-60mt/dss Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-60mt/ds Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-60mt/es	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-60mt/es-a	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-60mt/es-a Firmware	-	All	All	All
Hardware	Mitsubishielectric	Fx5uj-60mt/ess	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-60mt/ess Firmware	-	All	All	All
Operating System	Mitsubishielectric	Fx5uj-60mt/es Firmware	-	All	All	All

References

Reference	Source	Link	Tags
www.mitsubishielectric.com/en/psirt/vulnerability/pdf/2023-013_en.pdf	MISC	www.mitsubishielectric.com	
Mitsubishi Electric MELSEC Series CISA	MISC	www.cisa.gov	
JVNVU#94620134: 三菱電機製MELSECシリーズにおける複数の脆弱性	MISC	jvn.jp	
CVE Program record	CVE.ORG	www.cve.org	canonical
NVD vulnerability detail	NVD	nvd.nist.gov	canonical, analysis

No vendor comments have been submitted for this CVE.

No vendor comments have been submitted for this CVE.

There are currently no legacy QID mappings associated with this CVE.

© [CVE.report](#) 2026 |

Use of this information constitutes acceptance for use in an AS IS condition. There are NO warranties, implied or otherwise, with regard to this information or its use. Any use of this information is at the user's risk. It is the responsibility of user to evaluate the accuracy, completeness or usefulness of any information, opinion, advice or other content. EACH USER WILL BE SOLELY RESPONSIBLE FOR ANY consequences of his or her direct or indirect use of this web site. ALL WARRANTIES OF ANY KIND ARE EXPRESSLY DISCLAIMED. This site will NOT BE LIABLE FOR ANY DIRECT, INDIRECT or any other kind of loss.

CVE, CWE, and OVAL are registered trademarks of [The MITRE Corporation](#) and the authoritative source of CVE content is [MITRE's CVE web site](#). This site includes MITRE data granted under the following [license](#).

CVE.report and Source URL Uptime Status [status.cve.report](#)